



BURKHART GROB Luft- und  
Raumfahrt GmbH & Co. KG  
Flugplatz / Mattsies  
D-86874 Tussenhausen  
West Germany  
Telefon 08268 / 998-0  
Telex 539 623

Airplane Flight Manual

GROB G 115C

Issue : 2

Airworthiness category: Utility

FAR compliance: FAR 23 incl. Amendment 32

This manual constitutes the approved airplane flight manual of the aircraft GROB G 115C and must be carried in the airplane at all times.

Scope and revised status can be seen from the Table of Contents or the Log of Revisions.

Airplane Serial No.: \_\_\_\_\_ Airplane Regist. No.: \_\_\_\_\_

Owner: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

As operating instruction in accordance with § 12(1) 2 LuftGerPo LBA - approved:

30. Dec. 1993





BURKHART GROB Luft- und  
Raumfahrt GmbH & Co. KG  
Flugplatz / Mattsies  
D-86874 Tussenhausen  
West Germany  
Telefon 08268 / 998-0  
Telex 539 623

Airplane Flight Manual

GROB G 115C

Issue : 2

Airworthiness category:           Utility / Acrobatic\*  
FAR compliance:                    FAR 23 incl. Amendment 32

This manual constitutes the approved airplane flight manual of the aircraft GROB G 115C and must be carried in the airplane at all times.

Scope and revised status can be seen from the Table of Contents or the Log of Revisions.

\* The supplement 2 is mandatory, if the airplane is operated acc. to acrobatic airworthiness category !

Airplane                                   Airplane  
Serial No.: \_\_\_\_\_                Regist. No.: \_\_\_\_\_

Owner: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

As operating instruction in accordance with § 12(1) 2 LuftGerPo LBA - approved:

THIS LBA APPROVED HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY THE FEDERAL AVIATION REGULATIONS AND ADDITIONAL INFORMATION PROVIDED BY THE MANUFACTURER AND CONSTITUTES THE FAA APPROVED AIRPLANE FLIGHT MANUAL FOR U.S. REGISTERED AIRPLANES IN ACCORDANCE WITH 14 CFR SECTION 21.29.



BURKHART GROB Luft- und  
Raumfahrt GmbH & Co. KG  
Flugplatz / Mattsies  
D-86874 Tussenhausen  
West Germany  
Telefon 08268 / 998-0  
Telex 539 623

Airplane Flight Manual  
GROB G 115C  
Issue : 2

Airworthiness category: Utility  
FAR compliance: FAR 23 incl. Amendment 32

This manual constitutes the approved airplane flight manual of the aircraft GROB G 115C and must be carried in the airplane at all times.

Scope and revised status can be seen from the Table of Contents or the Log of Revisions.

Airplane Serial No.: \_\_\_\_\_ Airplane Regist. No.: \_\_\_\_\_

Owner: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

As operating instruction in accordance with § 12(1) 2 LuftGerPo LBA - approved:

THIS LBA APPROVED HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY THE FEDERAL AVIATION REGULATIONS AND ADDITIONAL INFORMATION PROVIDED BY THE MANUFACTURER AND CONSTITUTES THE FAA APPROVED AIRPLANE FLIGHT MANUAL FOR U.S. REGISTERED AIRPLANES IN ACCORDANCE WITH 14 CFR SECTION 21.29.

## Table of Contents





Section 1	General
Section 2	Limitations
Section 3	Emergency procedures
Section 4	Normal procedures
Section 5	Performance
Section 6	Weight and balance, equipment
Section 7	Description and operation of the airplane and its systems
Section 8	Airplane Handling, servicing and maintenance
Section 9	Supplements

Log of Revisions

Airplane  
 GROB G115C Serial No.: \_\_\_\_\_ Airplane  
 Regist. No.: \_\_\_\_\_

All revision material must be inserted into the handbook without delay. Deleted pages shall be removed and destroyed. This page shall be replaced and the page check-list updated by handwriting in accordance with the revised data or replaced. Revisions are identified by a vertical black line on the side.

This aircraft must only be operated when the airplane flight manual is fully updated!



Revision No.	Date	Revised pages and text	German LBA approval:	Stamp and signature
1	11.07.1994	C, D, E, F, 1-6, 2-1, 2-6, 2-7, 2-8, 2-9, 2-12, 2-13, 2-15, 2-17, 3-2, 3-3, 3-7, 3-8, 3-9, 3-10, 3-12, 3-14, 3-15, 4-1, 4-2, 4-5, 4-8, 4-9, 4-10, 4-11, 4-12, 4-13, 4-14, 4-15, 4-16, 4-17, 4-18, 4-19, 4-20, 4-21, 4-22, 4-23, 4-24, 4-25, 4-26, 4-27, 4-28, 6-15, 6-19, 7-1, 7-3, 7-4, 7-6, 7-13, 7-15, 7-16, 7-17, 7-18, 7-19, 7-20, 7-21.	27. He of July 1994	 i.A. Fou 27. JULI 1994
2	10.10.1994	C, D, E, 4-5, 4-12, 4-14, 4-21, 4-22.		 i.A. Fou October 26, 1994
3	03.11.1994	C, D, E, F, 2-7, 2-8, 2-9, 2-16 3-14, 3-14a, 3-19, 4-5, 4-9, 4-10, 4-20, 7-12, 7-17, 7-20.	10. NOV. 1994	 i.A. Fou
4	12.12.1994	C, D, E, F, 2-5, 2-7, 2-8, 2-9, 2-16, 3-14a, 4-13, 4-22, 6-15, 7-9, 7-14, 7-14a, 7-16.	20. DEZ. 1994	 i.A. Fou

Log of Revisions

GROB G115 C                      Airplane                      Airplane  
 Serial No.: \_\_\_\_\_      Regist.No.: \_\_\_\_\_

All revision material must be inserted into the handbook without delay. Deleted pages shall be removed and destroyed. This page shall be replaced and the page check list updated by handwriting in accordance with the revised data or replaced. Revisions are identified by a vertical black line on the side.

This aircraft must only be operated when the airplane flight manual is fully updated !

Revision No.	Date	Revised pages and text	German LBA approval	Stamp and signature
5	08.09 1995	A, C2, D, F, 9-2, Supplement 2	18th of January 1996	i. A. Fla ✓ 
6	15.09 1997	C2, D, (refer to SB 1078-74)	NOV. 18, 1997	 Feb ✓

Log of Revisions

GROB G115C      Airplane Serial No.: \_\_\_\_\_      Airplane Regist. No.: \_\_\_\_\_

All revision material must be inserted into the handbook without delay. Deleted pages shall be removed and destroyed. This page shall be replaced and the page check-list updated by handwriting in accordance with the revised data or replaced. Revisions are identified by a vertical black line on the side.

This aircraft must only be operated when the airplane flight manual is fully updated!

Revision No.	Date	Revised pages and text	German LBA approval:	Stamp and signature
5	08.09.1995	A,C2,D,F,9-2, Supplement 2.	18. JAN. 1996	<i>i. A. Falw</i>
-----	-----	-----	-----	-----





Index of valid manual pages  
Page Checklist

Page	Date	Page	Date	Page	Date
A	09/95	2 - 1	07/94	3 - 3	07/94
B	12/93	2 - 2	12/93	3 - 4	12/93
C	12/94	2 - 3	12/93	3 - 5	12/93
C2	09/97	2 - 4	12/93	3 - 6	12/93
D	09/97	2 - 5	12/94	3 - 7	07/94
E	12/94	2 - 6	07/93	3 - 8	07/94
F	09/95	2 - 7	12/94	3 - 9	07/94
		2 - 8	12/94	3 - 10	07/94
1 - 1	12/93	2 - 9	12/94	3 - 11	12/93
1 - 2	12/93	2 - 10	12/93	3 - 12	07/94
1 - 3	12/93	2 - 11	12/93	3 - 13	12/93
1 - 4	12/93	2 - 12	07/94	3 - 14	11/94
1 - 5	12/93	2 - 13	07/94	3 - 14a	12/94
1 - 6	12/93	2 - 14	12/93	3 - 15	07/94
1 - 7	12/93	2 - 15	07/94	3 - 16	12/93
1 - 8	12/93	2 - 16	12/94	3 - 17	12/93
1 - 9	12/93	2 - 17	07/94	3 - 18	12/93
1 - 10	12/93			3 - 19	11/94
1 - 11	12/93			3 - 20	12/93
1 - 12	12/93			3 - 21	12/93
1 - 13	12/93				
1 - 14	12/93	3 - 1	12/93		
1 - 15	12/93	3 - 2	06/94	4 - 1	06/94



**Page Checklist**

Page	Date	Page	Date	Page	Date
4 - 2	07/94	4 - 27	07/94	6 - 2	12/93
4 - 3	12/93	4 - 28	07/94	6 - 3	12/93
4 - 4	12/93			6 - 4	12/93
4 - 5	11/94			6 - 5	12/93
4 - 6	12/93	5 - 1	12/93	6 - 6	12/93
4 - 7	12/93	5 - 2	12/93	6 - 7	12/93
4 - 8	07/94	5 - 3	12/93	6 - 8	12/93
4 - 9	11/94	5 - 4	12/93	6 - 9	12/93
4 - 10	11/94	5 - 5	12/93	6 - 10	12/93
4 - 11	07/94	5 - 6	12/93	6 - 11	12/93
4 - 12	10/94	5 - 7	12/93	6 - 12	12/93
4 - 13	12/94	5 - 8	12/93	6 - 13	12/93
4 - 14	10/94	5 - 9	12/93	6 - 14	12/93
4 - 15	07/94	5 - 10	12/93	6 - 15	12/94
4 - 16	07/94	5 - 11	12/93	6 - 16	12/93
4 - 17	07/94	5 - 12	12/93	6 - 17	12/93
4 - 18	07/94	5 - 13	12/93	6 - 18	12/93
4 - 19	07/94	5 - 14	12/93	6 - 19	07/94
4 - 20	11/94	5 - 15	12/93	6 - 20	12/93
4 - 21	10/94	5 - 16	12/93	6 - 21	12/93
4 - 22	12/94	5 - 17	12/93	6 - 22	12/93
4 - 23	07/94			6 - 23	12/93
4 - 24	07/94				
4 - 25	07/94				
4 - 26	07/94	6 - 1	12/93		



Page Checklist

Page	Date	Page	Date	Page	Date
7 - 1	07/94	8 - 3	12/93		
7 - 2	12/93	8 - 4	12/93		
7 - 3	07/94	8 - 5	12/93		
7 - 4	07/94	8 - 6	12/93		
7 - 5	12/93	8 - 7	12/93		
7 - 6	07/94				
7 - 7	12/93				
7 - 8	12/93				
7 - 9	12/94	9 - 1	12/93		
7 - 10	12/93	9 - 2	09/95		
7 - 11	12/93				
7 - 12	11/94				
7 - 13	07/94				
7 - 14	12/94				
7 - 14a	12/94				
7 - 15	07/94				
7 - 16	12/94				
7 - 17	11/94				
7 - 18	07/94				
7 - 19	07/94				
7 - 20	11/94				
7 - 21	07/94				
8 - 1	12/93				
8 - 2	12/93				



Section 1

General

	Page
1.1 Introduction	1 - 2
1.2 Warnings, Cautions and Notes	1 - 2
1.3 Three View	1 - 3
1.5 Dimensions	1 - 4
1.7 Engine	1 - 5
1.9 Propeller	1 - 5
1.11 Fuel	1 - 5
1.13 Oil	1 - 5
1.15 Maximum Weights	1 - 6
1.17 Symbols, Abbreviations and Terminology	1 - 7
1.19 Conversion Factors	1 - 11



## 1.1 Introduction

This manual is designed for as an operating guide for the pilot of the GROB G 115C. It includes the material required to be furnished to the pilot by FAR PART 23. It also contains supplemental data supplied by the airplane manufacturer.

This manual must be read carefully by the owner and/or the pilot to become acquainted with proper aircraft operation. This manual is not designed as a substitute for adequate and competent flight instruction, knowledge of current airworthiness directives, applicable federal air regulations or advisory circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in a current status.

Assurance that the airplane is in an airworthy condition is the responsibility of the owner. The pilot in command is responsible for determining that the airplane is safe for flight. The pilot is also responsible for remaining within the operating limitations as outlined by placards, instrument markings, and this manual.

This manual has been divided into 9 numbered sections, each provided with a "fingertip" tab divider for quick reference. The limitations and emergency procedures have been placed ahead of the normal procedures, performance and other sections to provide each access to information that may be required in flight.

## 1.2 Warnings, Cautions and Notes

The following definitions apply to warnings, cautions and notes in the flight manual.

### " WARNING "

means that the non-observation of the corresponding procedure leads to an immediate or important degradation of the flight safety.


### " CAUTION "

means that the non-observation of the corresponding procedure leads to a minor or to a more or less long term degradation of the flight safety.

### " NOTE "

draws the attention on any special item not directly related to safety but which is important or unusual.

1.3 Three-View



1.5 Dimensions
**Overall dimensions**

Wing span	10,0 m (32.81 ft)
Max. Length	7,53 m (24.70 ft)
Max. Height	2,82 m ( 9.25 ft)

**Wing**

Airfoil	Eppler E 696
Wing area	12,21 m <sup>2</sup> ; (131.43 sq.ft)
Dihedral	5 °
Angle of incidence	2 °

**Ailerons**

Area	0,562 m <sup>2</sup> (6.1 sq.ft)
------	----------------------------------

**Flaps**

Area	1,146 m <sup>2</sup> (12.3 sq.ft)
------	-----------------------------------

**Horizontal tail**

Airfoil	NACA 64010
Wing span	3,50 m (11.48 ft)
Area	2,723 m <sup>2</sup> (29.3 sq.ft)
Elevator surface	0,861 m <sup>2</sup> (9.3 sq.ft)

**Vertical tail**

Airfoil	NACA 64009
Area	1,692 m <sup>2</sup> (18.2 sq.ft)
Rudder area	0,642 m <sup>2</sup> (6.9 sq.ft)

**Landing gear**

Wheel track	2,50 m (8.2 ft)
Wheel base	1,61 m (5.3 ft)
Nose Wheel	5.00 - 5/6 PR
Main Wheel	15x6.00 - 6

Deflections see maintenance manual !

1.7 Engine

AVCO LYCOMING, Model O-320 D1A  
 4 Cylinder, direct drive, horizontally opposed, air-cooled  
 Displacement 319.8 cu.in.  
 Rated horsepower 160 HP  
 at rated speed 2700 RPM

1.9 Propeller

Two-blade fixed-pitch propeller 74 DM7S14-2-64  
 Propeller manufacturer Sensenich

1.11 Fuel

Avgas 100 or 100 LL  
 Total fuel capacity 150 liters 1)  
 39.63 U.S.gal.  
 33.00 Imp.gal.  
 Wing tank fuel capacity each 75 liters  
 Usable fuel 143 liters  
 37.77 U.S.gal.  
 31.46 Imp.gal.

1) Nominal value

1.13 Oil

Oil capacity 8 quarts/7,6 liters  
 Minimum requirement 6 quarts/5,7 liters  
 The following engine oils may be used:

Average ambient air	MIL-L-6082 Grades	MIL-L-22851 Ashless Dispersant Grades
above 27°C (80°F)	SAE 60	SAE 60
above 16°C (60°F)	SAE 50	SAE 40 or SAE 50
-1°C (30°F) to 32°C (90°F)	SAE 40	SAE 40
-18°C (0°F) to 21°C (70°F)	SAE 20	SAE 30 or SAE 40
below -12°C (10°F)	SAE 20	SAE 30

Also comply with the rules at AVCO LYCOMING specification No. 301 and AVCO LYCOMING Service Instruction No. 1014, latest issue.

Engine must be run for a minimum of 50 hours on aviation oil as per MIL-L-6082. Change oil after first 25 operating hours.

Until oil consumption has stabilized cruising performance must not be reduced to below 75 % to protect the cylinder liners from damage.

First filling: Aviation Oil as per MIL-L-6082

1.15 Maximum Weights

max. takeoff weight (utility category)	990 kg (2182 lbs)
max. landing weight (utility category)	990 kg (2182 lbs)
Standard empty weight	660 kg (1455 lbs)
max. useful load 1) (utility category)	330 kg (728 lbs)
max. permiss. baggage load	55 kg (121 lbs)

1) at standard empty weight

**WARNING**

The current information of Section 6 "Weight and balance" is applicable for the preflight action.

**Utility**

Wing loading at max. takeoff weight	81,08 kg/m <sup>2</sup> (16.60 lbs/sq.ft.)
Power loading at max. takeoff weight	6,19 kg/HP (13.64 lbs/HP)



### 1.17 Symbols, Abbreviations and Terminology

#### a) General Airspeed Terminology and Symbols

- CAS - Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. CAS is equal to true airspeed in standard atmosphere at sea level.
- KCAS - CAS, expressed in "Knots".
- GS - Ground Speed is the speed of an airplane relative to the ground.
- IAS - Indicated Airspeed is the speed of an airplane as shown on a pitot static airspeed indicator.
- KIAS - Indicated Airspeed expressed in "Knots".
- TAS - True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressibility.
- V<sub>A</sub> - Maneuvering Speed is the speed below which application of full available aerodynamic control is unlikely to overstress the airplane.
- V<sub>FE</sub> - Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
- V<sub>NE</sub> - Never Exceed Speed is the speed limit that may not be exceeded at any time.
- V<sub>NO</sub> - Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air and then only with caution.
- V<sub>S</sub> - Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
- V<sub>SO</sub> - Stalling Speed or the minimum steady flight speed at which the airplane is controllable in the landing configuration.
- V<sub>X</sub> - Best Angle-of-Climb speed is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
- V<sub>Y</sub> - Best Rate-of-Climb speed is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

## b) Meteorological Terminology

ISA - International Standard Atmosphere in which:

- the air is a dry perfect gas;
- the temperature at sea level is 15°C (59°F);
- the pressure at sea level is 1013.2 hpa (mb) (29.92 inches HG);
- the temperature gradient from sea level to the altitude at which the temperature is -56.5°C (-69.7°F) is -0.00198°C (-0.003566°F) per foot and zero above that altitude.

OAT - Outside Air Temperature.

## Indicated Pressure Altitude

- The number actually read from an altimeter when the barometric subscale has been set to 1013.2 hpa (mb) (29.92 in. HG).

## Pressure Altitude

- Altitude measured from standard sea level pressure (29.92 in. HG or 1013.2 hpa (mb)) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error. In this handbook altimeter instrument errors are assumed to be zero.

## Station Pressure

- Actual atmospheric pressure at field elevation.

## Wind

- The wind velocities recorded as variables on the charts of this handbook are to be understood as the headwind or tailwind components of the reported winds.



## c) Power Terminology

## Takeoff Power

- Maximum power permissible for takeoff.

## Maximum Continuous Power

- Maximum power permissible continuously during flight.

## Maximum Climb Power

- Maximum power permissible during climb.

## Maximum Cruise Power

- Maximum power permissible during cruise.

## CHT

- Cylinder Head Temperature.

## EGT

- Exhaust Gas Temperature.

## d) Airplane Performance and Flight Planning Terminology

## Climb Gradient

- The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval.

## Demonstrated Crosswind Velocity

- The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during take-off and landing was actually demonstrated during certification tests.

## e) Weight and Balance Terminology

## Reference Datum

- An imaginary vertical plane from which all horizontal distances are measured for balance purposes.

## Arm

- The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.

## Moment

- The product of the weight of an item multiplied by its arm.

## Center of Gravity (C.G.)

- The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.

## C.G. Arm

- The arm obtained by adding the airplane's individual moments and dividing the sum by the the total weight.

## C.G. Limits

- The extreme center of gravity locations within which the airplane must be operated at a given weight.

## Usable Fuel

- Fuel available for flight planning (without reserve fuel).

## Unusable Fuel

- Fuel remaining after a runout test has been completed in accordance with governmental regulations.

## Standard Empty Weight

- Weight of a standard airplane including unusable fuel, full operating fluids and full oil according to the actual weighing report.

## Maximum Takeoff Weight

- Maximum weight approved for the start of the takeoff run (according to the operating category of the aircraft).

**1.19 Conversion Factors**

MULTIPLY	BY	TO OBTAIN
atmospheres [atm]	760	mm Hg
	29.92	in. Hg
	1.0133	bar
	1.033	kg / cm <sup>2</sup>
	14.70	lb./sq. in.
	2116	lb./sq. ft.
bars [bar]	0.98692	atm
	14.503768	lb./sq. in
centimeters [cm]	0.3937	in.
	0.032808	ft.
cubic centimeters [cm <sup>3</sup> ]	0.03381	fl. oz.
	0.06102	cu. in.
	3.531 x 10 <sup>-5</sup>	cu.ft.
	0.001	l
	2.642 x10 <sup>-4</sup>	U.S. gal.
cubic feet [cu.ft.]	28317	cm <sup>3</sup>
	0.028317	m <sup>3</sup>
	1728	cu. in.
	0.037037	cu.yd.
	7.481	U.S. gal.
	28.32	l
cubic feet per minute [cu.ft./min.]	0.472	l/sec.
	0.028317	m <sup>3</sup> /min.
cubic inches [cu.in.]	16.39	cm <sup>3</sup>
	1.639 x 10 <sup>-5</sup>	m <sup>3</sup>
	5.787 x 10 <sup>-4</sup>	cu.ft.
	0.5541	fl.oz.
	0.01639	l
	4.329 x 10 <sup>-3</sup>	U.S.gal.
	0.01732	U.S.qt.
cubic meters [m <sup>3</sup> ]	61024	cu.in.
	1.308	cu.yd.
	35.3147	cu.ft.
	264.2	U.S.gal.
feet [ft.]	30.48	cm
	0.3048	m
	12	in.
	0.33333	yd.
	1.894 x 10 <sup>-4</sup>	st. M.
	1.645 x 10 <sup>-4</sup>	NM

feet per minute [ft./min.]	0.01136	mph
	0.01829	km/h
	0.508	cm/sec.
	0.00508	m/sec.
gallons, Imperial [Imperial gal.]	277.4	cu.in.
	1.201	U.S.gal.
	4.546	l
gallons, U.S. liquid [U.S.gal.]	231	cu.in.
	0.1337	cu.ft.
	$4.951 \times 10^{-3}$	cu.yd.
	3785.4	cm <sup>3</sup>
	$3.785 \times 10^{-3}$	m <sup>3</sup>
	3.785	l
	0.83268	Imperial gal.
grams [g]	128	fl.oz.
	0.001	kg
grams per cubic centimeter [g/cm <sup>3</sup> ]	$2.205 \times 10^{-3}$	lb.
	1000	kg/m <sup>3</sup>
	0.03613	lb./cu.in.
horsepower [hp]	62.43	lb./cu.ft.
	33000	ft.-lb./min.
	550	ft.-lb./sec.
	76.04	m•kg/sec.
	1.014	PS
horsepower, metric	0.7458	kW
	75	m•kg/sec.
	0.9863	hp
inches [in.]	0.7355	kW
	25.40	mm
	2.540	cm
	0.0254	m
	0.08333	ft.
inches of mercury at 0°C [in.Hg]	0.027777	yd.
	0.033421	atm
	0.4912	lb./sq.in.
	70.73	lb./sq.ft.
	345.3	kg/m <sup>2</sup>
	2.540	cm Hg
kilograms per cubic meter [kg/m <sup>3</sup> ]	25.40	mm Hg
	0.06243	lb./cu.ft.
	0.001	g/cm <sup>3</sup>

kilograms [kg]	2.204622	lb.
	1000	g
kilograms per square centimeter [kg/cm <sup>2</sup> ]	0.9678	atm
	28.96	in.Hg.
	14.22	lb./sq.in.
	2048	lb.sq.ft.
kilograms per square meter [kg/m <sup>2</sup> ]	2.896 x10 <sup>-3</sup>	in.Hg
	1.422 x10 <sup>-3</sup>	lb./sq.in
	0.2048	lb./sq.ft.
kilometers [km]	1 x 10 <sup>-5</sup>	cm
	3280.8	ft.
	0.6214	st. M.
	0.53996	NM
kilometers per hour [km/h]	0.9113	ft./sec.
	58.68	ft./min.
	0.53996	kts
	0.6214	mph
	0.27778	m/sec.
	16.67	m/min.
kilowatts [kW]	1.3596	PS
	1.341	hp
knots [kts]	1	nautical mph
	1.689	ft./sec.
	1.1516	statute mph
	1.852	km/h
	0.51444	m/sec.
liters [l]	1000	cm <sup>3</sup>
	61.02	cu.in.
	0.03531	cu.ft.
	33.814	fl.oz.
	0.264172	U.S.gal.
	0.2200	Imperial gal.
	1.05669	qt.
liters per second [l/sec.]	2.12	cu.ft./min.
meters [m]	39.37	in.
	3.280840	ft.
	1.0936	yd.
	6.214 x10 <sup>-4</sup>	st. M.
	5.3996 x 10 <sup>-4</sup>	NM
meter-kilograms [m•kg]	7.23301	ft.-lb.
	86.798	in.-lb.

meters per second [m/sec.]	3.280840 196.8504 2.237 3.6	ft./sec. ft./min. mph km/h
miles, statute [st.M.]	5280 1.6093 1609.3 0.8684	ft. km m NM
miles per hour [mph]	44.7041 4.470 x 10 <sup>-1</sup> 1.467 88 1.6093 0.8684	cm/sec. m/sec. ft./sec. ft./min. km/h kt
nautical miles per hour [NMph]	51.446 5.145 x 10 <sup>-1</sup> 1.688 101.271 1.852	cm/sec. m/sec. ft./sec. ft./min. km/h
millibars [mb]	2.953 x 10 <sup>-2</sup>	in.Hg
millimeters [mm]	0.03937	in.
millimeters of mercury at 0°C [mm Hg]	0.03937	in.Hg
nautical miles [NM]	6080 1.1516 1852 1.852	ft. st. M. m km
ounces, fluid [fl.oz.]	29.57 1.805 0.0296 0.0078	cm <sup>3</sup> cu.in. l U.S.gal.
pounds [lb.]	0.453592 453.6	kg g
pounds per cubic inch [lb./cu.in.]	1728 27.68	lb./cu.ft. g/cm <sup>3</sup>
pounds per square foot [lb./sq.ft.]	0.01414 4.88243 4.725 x 10 <sup>-4</sup>	in.Hg kg/m <sup>2</sup> atm



pounds per square inch [psi oder lb./sq.in.]	5.1715	cm Hg
	2.036	in.Hg
	0.06804	atm
	0.0689476	bar
	703.1	kg/m <sup>2</sup>
quart, U.S.[qt.]	0.94635	l
	57.749	cu.in.
revolutions per minute [RPM or rev./min.]	0.1047	rad./se/sec.
square centimeters [cm <sup>2</sup> ]	0.1550	sq.in.
	0.001076	sq.ft.
square feet [sq.ft.]	929	cm <sup>2</sup>
	0.092903	m <sup>2</sup>
	144	sq.in.
	0.1111	sq.yd.
	2.296 x 10 <sup>-5</sup>	acres
square inches [sq.in.]	6.4516	cm <sup>2</sup>
	6.944 x 10 <sup>-3</sup>	sq.ft.
square kilometers [km <sup>2</sup> ]	0.3861	(st.M.) <sup>2</sup>
square meters [m <sup>2</sup> ]	10.76391	sq.ft.
	1.196	sq.yd.
square miles [sq.mi.]	2.590	km <sup>2</sup>
yards [yd.]	0.9144	m
	3	ft.
	36	in.




## Table of Contents

## Section 2

## Limitations

	Page
2.1 General	2 - 2
2.3 Airspeed Limitations	2 - 3
2.5 Airspeed Indicator Markings	2 - 3
2.7 Power Plant Limitations	2 - 4
2.11 Power Plant Instrument Markings	2 - 5
2.13 Weight Limits	2 - 6
2.15 Center of Gravity Limits	2 - 6
2.17 Maneuver Limits	2 - 6
2.19 Flight Maneuvering Load Factors	2 - 6
2.21 Seating Capacity	2 - 7
2.23 Kinds of Operation Limits	2 - 7
2.25 Fuel Limitations	2 - 10
2.41 Placards	2 - 11
2.43 Colour	2 - 17



### 2.1 General

This section provides the "German LBA-approved" operating limitations, instrument markings, color coding and basic placards necessary for the safe operation of the airplane and its systems.

Limitations associated with those optional systems and equipment which require handbook supplements can be found in Section 9 (Supplements).

### 2.3 Airspeed Limitations

Speed	IAS km/h (kts)	Remarks
V <sub>A</sub> Design Maneuvering Speed Utility	212 (114)	Do not make full or abrupt control movements above this speed.
V <sub>FE</sub> Max. Flaps Extended Speed	208 (112)	Do not exceed this speed with the flaps extended.
V <sub>NE</sub> Never Exceed Speed	341 (184)	Do not exceed this speed in any operation.
V <sub>NO</sub> Maximum Structural Cruising Speed	248 (134)	Do not exceed this speed except in smooth air and then only with caution.

### 2.5 Airspeed Indicator Markings

Marking	IAS		Meaning
	km/h	kts	
white arc	95 - 208	51 - 112	Flap down Operating Range
blue radial line	145	78	Recommended climb speed
green arc	97 - 248	52 - 134	Normal Operating Range
yellow arc	248 - 341	134 - 184	Caution Range "only in smooth air"
red radial line	341	184	Never Exceed

**2.7 Power Plant Limitations**

- |    |  |                               |
|----|--|-------------------------------|
| a) | Number of engines  | 1                             |
| b) | Engine manufacturer  | Lycoming                      |
| c) | Engine model   | O - 320 D1A                   |
| d) | Engine operating limits  |                               |
|    | Rated output power   | 160 HP/119.3 KW               |
|    | Rated output rotation speed  | 2700 RPM                      |
|    | Max. continous horsepower  | 160 HP/119.3 KW               |
|    | Max. continous rotation speed  | 2700 RPM                      |
| e) | Oil pressure   |                               |
|    | minimum  | 1,7 bar (25 PSI)              |
|    | normal (green arc)   | 4,1 - 6,2 bar (60 - 90 PSI)   |
|    | maximum  | 6,9 bar (100 PSI)             |
| f) | Fuel pressure  |                               |
|    | minimum  | 0,04 bar (0.5 PSI)            |
|    | normal (green arc)   | 0,04 - 0,55 bar (0.5 - 8 PSI) |
|    | maximum  | 0,55 bar (8 PSI)              |
| g) | Oil temperature  |                               |
|    | minimum (not for continuous operation)   | 40 - 60 °C                    |
|    | normal (green arc)   | 60 - 118 °C                   |
|    | maximum  | 118 °C                        |
| h) | suction indicator (if installed)   |                               |
|    | normal (green arc)   | 4.5-5.4 inch HG               |
| i) | Cylinder head temperature<br>(if installed)                                      |                               |
|    | minimum  | 66 °C                         |
|    | normal (green arc)   | 66 - 260 °C                   |
|    | maximum  | 260 °C                        |
|    | For maximum engine service life avoid temperatures<br>during continous operation | 204 - 260 °C                  |
| j) | Fuel grade (min. 100 octane)   | Avgas 100<br>or 100 LL        |
| k) | Oil specification<br>(see page 1 - 5)  | MIL-L-6082<br>or MIL-L-22851  |
| l) | Number of propellers   | 1                             |
| m) | Propeller manufacturer   | Sensenich                     |
| n) | Propeller model  | 74 DM7S14-2-64                |

- o) Propeller diameter 1,83 m (6.00 ft)
- p) Propeller pitch at 0,75•R 1,63 m (5.35 ft)
- q) Propeller rotation speed limitations
  - during take-off 2800 RPM
  - maximum continuous 2800 RPM

**2.11 Power Plant Instrument Markings**

	red line	yellow arc caution-	green arc normal- R a n g e	yellow arc caution-	red line
Tachometer [RPM]			1800- 2700		2700
Oil tempe- rature [°C]		40 - 60	60-118		118
Oil pressure [bar] (PSI)	1,7 (25)	1,7-4,1 (25-60)	4,1-6,2 (60-90)	6,2-6,9 (90-100)	6,9 (100)
Fuel pressure [bar] (PSI)	0,04 (0.5)		0,04 - 0,55 (0.5 - 8.0)		0,55 (8.0)
Fuel capacity [ltr] (US.gal) (Imp.gal.)		0 - 22 (0 - 5.81) (0 - 4.84)			
Suction [inch HG](PSI)			4,5-5,4 (2.2 - 2.65)		
Cylinder head temperature [°C]		0 - 66	66-260		260
Voltmeter [V]		16 - 20	20-30	30-32	32
Amperemeter [A]	-20	-20 to -10	-10 to +10	10-20	20

### 2.13 Weight Limits

Maximum take-off and landing weight	Utility 990 kg (2182 lbs)
Maximum baggage in baggage compartment	55 kg (121 lbs)

### 2.15 Center of Gravity Limits

Utility		Distance from Datum [mm] (ft)
forward limit		
at 990 kg (2182 lbs)	18.3 % $l_{\mu}$	227 (.745)
at 750 kg (1653 lbs)	15.9 % $l_{\mu}$	197 (.646)
Utility		
aft limit		
at 990 kg (2182 lbs)	24.0 % $l_{\mu}$	298 (.978)
at 750 kg (1653 lbs)	23.2 % $l_{\mu}$	288 (.945)

Datum: Wing leading edge = QE 2480  
 $l_{\mu}$ : Mean aerodynamic chord = 1,242 m (4.075 ft)

Horizontal reference : Canopy sill

### 2.17 Maneuver Limits

Utility	Entry Speed (km/h) [kts]
Lazy Eight	245 [132]
Chandelle	245 [132]
Steep turns	245 [132]

#### **WARNING**

At airspeeds in excess of  $V_A$  do not apply abrupt and full control inputs! Acrobatic maneuvers are not approved!

#### **Utility Category:**

Intentional spins with flap setting at 0° are approved only. Spins without wheel fairings are not approved. For intentional spinning a MTOW of 920 kg (2028 lbs) may not be exceeded! Recommended entry speed:  $\approx$  100 km/h [54 kts]

### 2.19 Flight Maneuvering Load Factors

Utility (990 kg) [2182 lbs]	Maximum load factor
Flaps retracted	+ 4,4 g - 1,76 g
Flaps extended	+ 3,8 g

### 2.21 Seating Capacity

Number: 2

The seat of the pilot in command is the left hand seat or may be determined by the owner of the aircraft !

### 2.23 Kinds of Operation Limits

VFR / IFR day and night (with required equipment).  
Flights in known icing conditions are not approved.

Compliance with cooling requirements according to FAR 23 have been demonstrated up to 40°C.

#### **NOTE**

The attitude indicator will show an incorrect or false indication during flight maneuvers ( e.g. spinning ). To achieve a faultless function of the instrument, a level flight of approx. 20 min. will be recommended. Check that the attitude indicator is stabilized. During this period of time use only the turn coordinator and/or the directional indicator. This is advisable during abnormal flight maneuvers ( e.g. high rate of roll during turbulence ).

The combination of the aircraft crew must refer to national regulations.  
(in Germany: " Betriebsordnung für Luftfahrtgerät § 32 ")

### Kinds of Operation Equipment List

This airplane may be operated in VFR / IFR day and night when the appropriate equipment is installed and operable.

It is not intended to install an autopilot for IFR operation. (in Germany: " observe § 32 [4] Luft BO ! ")

The following equipment list identifies the systems and equipment upon which type certification for each kind of operation was predicated. The following systems and items of equipment must be installed and operable for the particular kind of operation indicated.

The ATA numbers refer to equipment classifications of Air Transport Association Specification Code 100.



	VFR- Day SR-SS	VFR- Night	IFR acc. FAR *	IFR- Day	IFR- Night
<u>Communications</u> (ATA-23)					
1. Communication Radio (VHF)	1	1	1	2	2
<u>Electrical Power</u> (ATA-24)					
1. Battery	1	1	1	1	1
2. D.C. Generator	1	1	1	1	1
3. D.C. Loadmeter	1	1	1	1	1
4. D.C. Generator Warning Light	1	1	1	1	1
<u>Flight Controls</u> (ATA-27)					
1. Flap System	1	1	1	1	1
2. Flap Position Indicator	1	1	1	1	1
3. Horizontal Stabilizer Trim System	1	1	1	1	1
4. Stall Warning Horn	1	1	1	1	1
<u>Fuel</u> (ATA-28)					
1. Fuel Boost Pumps	1	1	1	1	1
2. Fuel Quantity Indicator	1	1	1	1	1
3. Fuel Pressure	1	1	1	1	1
<u>Ice and Rain Protection</u> (ATA-30)					
1. Pitot Heat	0	0	1	1	1
2. Alternate Static Air Source	0	0	1	1	1
<u>Instruments</u> (ATA-31)					
1. Clock	0	0	1	1	1
<u>Lights</u> (ATA-33)					
1. Cockpit and Instruments (Required Illumination)	0	1	1	0	1
2. Anti-Collision Light	3	3	3	3	3
3. Landing Light	0	0	0	0	2
4. Position Light	0	3	3	0	3

	VFR- Day SR-SS	VFR- Night	IFR acc. FAR *	IFR- Day	IFR- Night
<u>Navigation (ATA-34)</u>					
1. Altimeter	1	1	1	2	2
2. Airspeed	1	1	1	1	1
3. Magnetic Compass	1	1	1	1	1
4. Outside Air Temperature	1	1	1	1	1
5. Attitude Indicator	0	0	1	1	1
6. Directional Indicator	0	0	1	1	1
7. Turn and Bank Indicator	0	0	1	1	1
8. Vertical Speed Indicator	0	0	1	1	1
9. ADF	0	0	0	1	1
10. Navigation Radio (VOR)	0	1	1	2	2
11. DME	0	0	0	1	1
12. Transponder (ATC)	0	1	0	1	1
<b>Only for ILS-Approach:</b>					
13. Localizer	0	0	0	1	1
14. Glide slope	0	0	0	1	1
15. Marker	0	0	0	1	1
<u>Vacuum System (ATA-37)</u>					
1. Suction or Pressure Gauge	0	0	1	1	1
<u>Engine Indicating (ATA-77)</u>					
1. Tachometer Indicator (Engine)	1	1	1	1	1
2. Cylinder Head Temperature	0	0	1	1	1
3. Carburetor Heat Temperature	0	0	0	1	1
<u>Engine Oil (ATA-79)</u>					
1. Oil Temperature Indicator	1	1	1	1	1
2. Oil Pressure Indicator	1	1	1	1	1

**NOTE**

The valid operational requirements have priority over this list. The zeros (0) used in the above list mean that the equipment and/or system is not required for that kind of operation.

\* IFR-equipment and instrument requirements according to FAR Part 91 § 91.205 (b) through (f).

2.25 Fuel Limitations

Total capacity (nominal value)	150 liters (39.63 US.gal.)/(33.00 Imp.gal.)
Wing tank capacity	each 75 liters (19.81 US.gal.)/(16.50 Imp.gal.)
Unusable fuel	7 liters (1.85 US.gal.)/(1.54 Imp.gal.)
Usable fuel	143 liters (37.77 US.gal.)/(31.46 Imp.gal.)
Tank asymmetry	max. 20 liters (5.3 US.gal.)/(4.4 Imp.gal.)

**Never takeoff when fuel gauge indication of the tank in use is in yellow arc!**



2.41 Placards

On LH cabin wall:

L i m i t a t i o n s	
Category	Utility-airplane
Max. weight	990 kg (2182 lbs)
Max. flight maneuvering load factors (flaps UP)	+4,40 g -1,76 g
	(flaps DOWN)
Never exceed speed V <sub>NE</sub> [IAS]	341 km/h (184 kts)
Max. structural cruising speed V <sub>NO</sub> [IAS]	248 km/h (134 kts)
Design maneuvering speed V <sub>A</sub> [IAS]	212 km/h (114 kts)
Max. flaps extended speed V <sub>FE</sub> [IAS]	208 km/h (112 kts)
Intentional spins without wheel fairings or with extended flaps are not approved ! For intentional spinning a MTOW of 920 kg (2028 lbs) may not be exceeded !	


RH and LH on canopy frame:

**NO SMOKING**


On instrument panel:

<b>Design maneuvering speed V<sub>A</sub></b> Utility :           212 km/h IAS (114 kts)
--


On instrument panel: e.g.



On flap indicator and carburetor preheat:





On parking brake lever:





On trim indicator:


At the headset plugs between the seats:




On fuel filler cap:



On fuel cock:



On fuel tank selector:



On baggage compartment:

Baggage max. 55 kg (121 lbs)  
No Baggage during spin maneuvers!

On access hole in the top cowling:

<b>Oil capacity:</b>	min. 5,7 Liter (1.51 US.gal.) (1.25 Imp.gal.)
	max. 7,6 Liter (2.0 US.gal.) (1.67 Imp.gal.)
Oil grades see airplane flight manual	

On external power plug:

External power supply  
24 V DC

On fuel filler cap:

<b>AVGAS 100, 100 LL</b>
Total 75 liters
(19.81 US.gal. )
(16.50 Imp.gal.)


On main wheel fairing or on landing gear shock strut:

<b>3,0 bar</b>
(43.5 PSI)


On nose wheel fairing or on nose wheel fork:

<b>2,5 bar</b>
(36 PSI)


On throttle and mixture:



On ignition switch:



At the circuit breaker panels:




Button on the magnetic compass:

Calibration was made with the radios ON !

Deviation table (in vicinity of magnetic compass):

TO FLY	N	30	60	E	120	150
STEER						
TO FLY	S	210	240	W	300	330
STEER						
DATE	GROB					

On toggle switch for alternate static (if equipped):



On both flaps:

NO  
STEP

On canopy lock (inside and outside):

OPEN

CLOSED

On canopy lever (outside):

PULL TO OPEN

On both sides of the rudder (bottom):

DO  
NOT LIFT

Near the VHF-Transceiver:

COM I


COM II

Beside the lower instrument panel switches:


ON

OFF

Lower instrument panel switches / (as equipped) identification (as standard up to S/N 82014) :




Lower instrument panel switches / (as equipped) identification (optional up to S/N 82014 / as standard as of S/N 82015):





LH instrument panel switch identification (as equipped):

Above master switch:



MASTER SWITCH

All toggle switches are function-identified.

On brake fluid reservoir:

MIL-H 5606

On right hand cabin wall:

The markings and placards installed in this airplane contain operating limitations which must be complied with when operating this airplane in the UTILITY category. Other operating limitations which must be complied with are contained in the Airplane Flight Manual G 115C.

On right hand cabin wall:

This airplane is certified for the following flight operations:  
 VFR/IFR day and night (with required equipment).  
 Flights into known icing conditions are prohibited.

At the lower cowling near the exhaust:



Control lock:

REMOVE LOCKING PIN  
BEFORE STARTING ENGINE


On hourmeter:

FLIGHT HOURS


On engine hour meter:

ENGINE HOURS


On annunciator panel (as standard up to S/N 82014):



On annunciator panel (optional up to S/N 82014 / as standard as of S/N 82015):



On heating lever:



On instrument panel:

**SPIN RECOVERY :**

1. Throttle	IDLE
2. Rudder	FULL OPPOSITE
3. Aileron	NEUTRAL OR INTO SPIN DIRECTION
4. Elevator	NEUTRAL

On instrument panel:

Never take-off if fuel gauge  
indication is in yellow arc !

2.43 Colour

Painting of the GROB G 115C must accord to the colour specification GPS 1078/1.

Changing the paint colour and the paint thickness is only permissible after prior approval by the manufacturer of the airplane.



## Table of Contents

## Section 3

Emergency Procedures

	Page
3.1 General	3 - 4
3.3 Airspeeds for Emergency Operations	3 - 5
3.5 Emergency Procedures Check List	3 - 6
ENGINE FAILURE	3 - 6
During Take Off (roll)	3 - 6
During Take Off (if airborne)	3 - 6
In Flight	3 - 7
EMERGENCY LANDINGS	3 - 8
Power Off Landing	3 - 8
Power On Landing	3 - 8
Ditching	3 - 9
FIRE	3 - 9
Engine Fire During Start (not airborne)	3 - 9
Engine Fire in Flight	3 - 10
Electrical Fire in Flight	3 - 10
Cabin Fire in Flight	3 - 11
Wing Fire in Flight	3 - 11
ICING	3 - 11
LANDING WITH FLAT MAIN LANDING GEAR TIRE	3 - 12
SPIN RECOVERY	3 - 12
ABANDONING THE AIRCRAFT BY PARACHUTE	3 - 12

## Table of Contents (continued)

ENGINE ROUGHNESS OR POWER LOSS	3 - 12
Iced air intake filter	3 - 12
Fouled Ignition Plugs	3 - 12
Magneto Failure	3 - 13
Low Oil Pressure	3 - 13
ELECTRICAL SYSTEM FAILURE	3 - 13
Overvoltage (exceeding 30 V)	3 - 14
Excessive Charging	3 - 14
Alternator Failure	3 - 14
Main Bus Failure	3 - 14
Starter Relay Failure	3 - 15
3.7 AMPLIFIED EMERGENCY PROCEDURES	3 - 15
ENGINE FAILURE	3 - 15
EMERGENCY LANDINGS	3 - 17
LANDING WITHOUT ELEVATOR CONTROL	3 - 17
LANDING WITHOUT AILERON CONTROL	3 - 17
FIRE	3 - 18
ICING	3 - 18
SPIN RECOVERY	3 - 18
ABANDONING THE AIRCRAFT BY PARACHUTE	3 - 19
ENGINE ROUGHNESS OR POWER LOSS	3 - 19
Carburetor Icing	3 - 19
Iced air intake filter	3 - 19
Fouled Ignition Plugs	3 - 20
Magneto Failure	3 - 20



Table of Contents (continued)

Low Oil Pressure	3 - 20
<b>ELECTRICAL SYSTEM FAILURE</b>	3 - 20
Excessive Charging	3 - 21
Alternator Failure	3 - 21
Starter Relay Failure	3 - 21
Auxiliary Fuel Pump Failure	3 - 21



### 3.1 General

This section contains procedures in the form of checklists and amplified emergency procedures for coping with an emergency situation.

Emergency situations due to aircraft or engine malfunctioning are extremely rare, as long as the preflight inspection and maintenance tasks have been carried out properly. Inflight emergencies due to inclement weather conditions are very seldom and can practically be precluded as long as the flight has been carefully planned in advance and changes in the weather duly anticipated.

Should, however, an emergency situation arise, the procedures must be in accordance with the directives of this section to the extent necessary to overcome the situation.

All data of this section are referred to a flight mass of 990 kg (2182 lbs) unless other masses are stated.

3.3 Airspeeds for Emergency Operations

	VIAS	
	[km/h]	[kts]
Engine Failure after Take Off		
Flaps retracted	135	73
Flaps in take off position	130	70
Recommended gliding speed (flaps retracted / 990 kg / 2182 lbs)	135	73
Precautionary landing (power on)	130	70
Emergency landing (power off)		
Flaps retracted	135	73
Flaps extended (60°)	130	70

**WARNING**

The stall warning horn will not function with the master switch in position "OFF".

3.5 Emergency Procedures Check List

## ENGINE FAILURE

## DURING TAKE OFF (roll)

- |             |                         |
|-------------|-------------------------|
| 1. Throttle | IDLE                    |
| 2. Brakes   | OPERATE AS<br>NECESSARY |

Actions in case the aircraft  
is departing from the runway:

- |                  |                 |
|------------------|-----------------|
| 3. Mixture       | LEAN<br>CUT-OFF |
| 4. Fuel cock     | OFF             |
| 5. Ignition      | OFF             |
| 6. Master switch | OFF             |

## DURING TAKE OFF (if airborne)

## I. Engine power insufficient to continue flight

- |                         |                                 |
|-------------------------|---------------------------------|
| 1. Airspeed             | 130 - 135 km/h<br>(70 - 73 kts) |
| 2. Fuel cock            | ON                              |
| 3. Fuel tank selection  | CHECK                           |
| 4. Both magnetos        | ON                              |
| 5. Electrical fuel pump | ON                              |
| 6. Fuel pressure        | CHECK                           |
| 7. Mixture              | CHECK                           |
| 8. Throttle             | CYCLE                           |

If there is no improvement

- |               |                 |
|---------------|-----------------|
| 9. Mixture    | LEAN<br>CUT-OFF |
| 10. Fuel cock | OFF             |
| 11. Ignition  | OFF             |





If sure that the chosen landing area will be reached:

- 12. Flaps 60°
- 13. Emergency radio call IF POSSIBLE
- 14. Master switch OFF

**Make emergency landing as straight ahead if possible!**

II. Engine failure

- 1. Fuel cock OFF
- 2. Throttle FULL THROTTLE

Shortly before touchdown:

- 3. Flaps 60°
- 4. Mixture LEAN CUT-OFF
- 5. Ignition OFF
- 6. Master switch OFF

**IN FLIGHT**

Restart of the failed engine:

- 1. Airspeed MAINTAIN BLUE LINE  
MAX. 120 kts
- 2. Fuel cock CHECK / ON
- 3. Fuel tank selection CHECK / MOST CONTENT
- 4. Throttle 1/4 OPEN
- 5. Mixture FULL RICH
- 6. Carburetor heat ON / PULL FULLY
- 7. Electrical fuel pump ON
- 8. Ignition (if the propeller  
is not windmilling) BOTH / START

**NOTE**

In case of "high speed restart", set the throttle full idle and mixture in the normal range. If the prop has stopped, give an impulse with the starter.

**Engine Roughness**

- |                           |                              |
|---------------------------|------------------------------|
| 1. Carburetor heat        | ON / PULL FULLY              |
| 2. Mixture                | FULL RICH OR<br>AS NECESSARY |
| 3. Electrical fuel pump   | ON                           |
| 4. Magnetos               | CHECK                        |
| 5. If roughness not cured | LAND AS SOON<br>AS POSSIBLE  |

**EMERGENCY LANDINGS**
**POWER OFF LANDING**

- |   |  |
|---|--|
| 1. Airspeed<br>(flaps up)<br>(flaps down) | 135 km/h (73 kts)<br>130 km/h (70 kts) |
| 2. Fuel cock                              | OFF                                    |
| 3. Ignition                               | OFF                                    |
| 4. Mixture                                | LEAN / CUT-OFF                         |
| 5. Electrical fuel pump                   | OFF                                    |
| 6. Flaps                                  | AS REQUIRED                            |
| 7. Emergency radio call                   | IF POSSIBLE                            |
| 8. Master switch                          | OFF                                    |

**POWER ON LANDING**

- |  |                    |
|--|--------------------|
| 1. Emergency landing location  | SEEK               |
| 2. Announce your emergency landing intention and the position of the landing location on the radio to a suitable authority, if possible. |                    |
| 3. Speed   | 135 km/h (73 kts)  |
| 4. Flaps   | 15°/Flaps in START |
| 5. Fly over selected area, check prevailing conditions and over shoot suitability.   |                    |
| 6. Seat belts and harness  | TIGHT              |
| 7. Flaps (final approach)  | 60°                |



## SECTION 3 :

Emergency  
Procedures

- |                              |  |
|------------------------------|--|
| 8. Airspeed                  | 130 km/h (70 kts)                      |
| 9. Master switch             | OFF                                    |
| 10. Touch down at min. speed | MAIN WHEELS FIRST<br>108 km/h (58 kts) |
| 11. Ignition                 | OFF                                    |
| 12. Brakes                   | AS REQUIRED                            |

## DITCHING

- |  |                          |
|--|--------------------------|
| 1. Radio   | MAYDAY                   |
| 2. Heavy objects                                       | SECURE                   |
| 3. Flaps   | 60°                      |
| 4. Seat belts and harness tight                        | CHECK                    |
| 5. Approach in prevailing strong<br>wind and high seas | AGAINST THE WIND         |
| Approach in prevailing gentle<br>wind and strong swell | PARALLEL TO<br>THE SWELL |
| 6. Touch down  | AT MIN. SPEED            |
| 7. Canopy  | OPEN                     |
| 8. Seat belts and harness                              | RELEASE                  |
| 9. Airplane  | ABANDON                  |
| 10. Life jackets and dinghy                            | INFLATE                  |

## FIRE

## ENGINE FIRE DURING START (not airborne)

- |                                  |                |
|----------------------------------|----------------|
| 1. Fuel cock                     | OFF            |
| 2. Electrical fuel pump          | OFF            |
| 3. Mixture                       | LEAN / CUT-OFF |
| 4. Throttle                      | FULL THROTTLE  |
| 5. Ignition                      | OFF            |
| 6. Master switch                 | OFF            |
| 7. Combat fire with extinguisher |                |



ENGINE FIRE IN FLIGHT

- 1. Fuel cock OFF
- 2. Electrical fuel pump OFF
- 3. Mixture LEAN  
CUT-OFF
- 4. Throttle FULL THROTTLE
- 5. Ignition OFF
- 6. Cabin heating OFF
- 7. Power off emergency landing REFER TO PROCEDURE

ELECTRICAL FIRE IN FLIGHT

- 1. Master switch OFF
- 2. Vents CLOSED
- 3. Cabin heating OFF
- 4. Fire extinguisher (if provided) APPLY

**NOTE** Ventilate cabin after using fire extinguisher in closed cabin. The canopy can be opened below 150 km/h (81 kts).

If fire is extinguished and electric power is required to continue the flight:

- 1. Avionics switch OFF
- 2. All other switches, including all avionics switches (without the ignition switch) OFF
- 3. Master switch ON
- 4. Turn on all other switches as well as all circuit breaker in slow sequence until the short-circuit has been located.



## CABIN FIRE IN FLIGHT

1. Master switch OFF
2. Vents CLOSED
3. Cabin heating OFF
4. Fire extinguisher (if provided) APPLY

**NOTE**        **Ventilate cabin after using  
extinguisher in closed cabin**

5. Land as soon as possible  
and examine damage

## WING FIRE IN FLIGHT

1. Position lights (if installed) OFF
2. Strobe lights (if installed) OFF
3. Perform side slip to keep  
flames away from cabin
4. Land as soon as possible

## ICING

## INADVERTANT FLIGHT INTO ICING CONDITIONS

1. Pitot heat ON
2. Change heading and/or altitude  
to leave icing conditions
3. Cabin heating to windshield ON
4. Increase RPM to prevent icing  
on prop blades (monitor RPM)
5. Carburetor heat ON
6. Prepare for landing at nearest airport.
7. If there is fast ice built up, search  
for emergency landing location.
8. In case of heavy icing on wing leading edge,  
higher stall speeds may be expected. The  
stall warning may give no or an incorrect  
warning.



LANDING WITH FLAT MAIN LANDING GEAR TIRE

1. Carry out normal approach
2. Flaps 60°
3. Touch down on good tire first and keep flat tire from ground contact as long as possible.
4. Maintain direction by braking suitably with good tire.

SPIN RECOVERY

- |             |                                |
|-------------|--------------------------------|
| 1. Rudder   | OPPOSITE TO SPIN DIRECTION     |
| 2. Aileron  | NEUTRAL OR INTO SPIN DIRECTION |
| 3. Elevator | NEUTRAL                        |

ABANDONING THE AIRCRAFT BY PARACHUTE

- |                   |          |
|-------------------|----------|
| 1. Engine         | SHUT OFF |
| 2. Canopy         | OPEN     |
| 3. Safety harness | RELEASE  |
| 4. Cockpit        | ABANDON  |

ENGINE ROUGHNESS OR POWER LOSS

The cause of engine roughness is not normally obvious. The following list of possibilities should be checked in the order listed.

ICED AIR INTAKE FILTER

- |                    |        |
|--------------------|--------|
| 1. Carburetor heat | ON     |
| 2. Mixture         | ADJUST |

FOULED IGNITION PLUGS

1. Set engine power 75 % BHP
2. Set the mixture to the recommended "best power up to best economy" position
3. Observe exhaust and cylinder head temperature
4. Check engine roughness after few minutes

5. Continue flight, if the engine is running smooth.
6. Land at the nearest airport, if the engine is running rough.

## MAGNETO FAILURE

1. Use a richer mixture setting and check the engine characteristics.
2. Use different power settings and check engine characteristics.
3. Switch from "BOTH" to "L" and check engine roughness and/or misfiring.
4. Switch from "L" to "R" and check engine roughness and/or misfiring.
5. Use the good magneto.
6. Adjust mixture setting.
7. Avoid extended use of power settings above 65 %
8. Observe CHT and EGT
9. Land at the nearest airport.

## LOW OIL PRESSURE

1. Check oil pressure
2. Check oil temperature
3. If the oil pressure is low (out of green arc) and oil temperature "NORMAL":
  - Land at the nearest airport.

If a complete loss of oil pressure with increasing of oil temperature is observed:

- Reduce engine power to a minimum.
- Search an emergency landing field.
- Use the minimum power to attain the emergency landing field.

## ELECTRICAL SYSTEM FAILURE

- |                                |                          |
|--------------------------------|--------------------------|
| 1. Generator warning light     | CHECK                    |
| 2. Voltmeter<br>(Normal value) | CHECK<br>24 through 28 V |

## OVERVOLTAGE (exceeding 30 V)

1. Avionic switch OFF
2. All lamps (incl. landing lights, if installed) ON
3. Electrical fuel pump ON
4. Voltmeter CHECK
5. As soon as voltage drops below 30 V, switch on avionics.

## ALTERNATOR FAILURE

(Indicated by red generator warning light and by ammeter fluctuating and/or pointer is at discharged position)

1. Alternator circuit breaker PULL
2. Turn off all non-essential electrical equipment
3. Reset alternator circuit breaker and terminate flight as soon as possible

## EXCESSIVE CHARGING

1. Alternator circuit breaker PULL
2. Non-essential electrical equipment OFF
3. Terminate flight as soon as possible

## MAIN BUS FAILURE

Should all indications show a Main Bus failure, the Essential Bus and the Avionic Bus I are further active.



**Description of the electrical buses / Pull push circuit breakers**

A description of the break down of each electrical bus and a function description after pulling a circuit breaker are as follows.

**This description only supplies with the "Engine in operation" !**  
The circuit breakers, located in LH lower instrument panel, are of a push/pull-design. To interrupt pull and to reset push the circuit breaker.

The circuit breakers, located in the RH instrument panel, should be reset only. When interrupted a red-white ring on the circuit breaker is visible.

Break down of electrical bus :**Main Bus :**

Fuel pump / Generator Control / Nav. Lights / Engine Instr.1 / Turn&Bank / Starter Relay / Engine Instr.2 / Pitot Heat / Avionic Blower / ACL Light / Panel Lights / Taxi Light / Hi&Lo Volt Warning.

**Essential Bus :**

Flaps / Ess Bus / RPM Ind. / Stall Warning / Landing Light / Instr. Lights / Elect. Horizon.

**Avionic Bus I :**

Main Bus / Generator / Avionic Bus / Com/Nav 1 / XPDR / Encoder / Audio / **Audio 2 only for IFR-operation.**

**Avionic Bus II :**

RMI / Com/Nav 2 / ADF / DME / Audio 2 / GPS / Compass System.

**Circuit breaker "Flaps" :**

After pulling this circuit breaker, the flaps are inoperable.

**Circuit breaker "Ess Bus" :**

During full power supply this circuit breaker is still in a "Stand-by-mode".

**Circuit breakers "Ess Bus & Avionic Bus" :**

The Avionic Buses I and II will be switched off.

**Circuit breaker "Main Bus" :**

After pulling the Main Bus-Circuit breaker, all electrical buses are supplied from the generator.

**Circuit breaker "Generator" :**

After pulling the Generator-Circuit breaker, all electrical buses are supplied from the battery .

**Circuit breaker "Avionic Bus" :**

The Avionic Bus I will be supplied with power; the Avionic Bus II will be switched off.

**Circuit breakers "Main Bus & Generator" :**

After pulling together the Main Bus- and the Generator-Circuit breakers, the Essential Bus and the Avionic Bus I will be supplied with power.

## STARTER RELAY FAILURE

(only if starter relay control lamp is installed)

Starter relay control lamp remains "ON" after the start-up procedure !

On ground

- |                    |       |
|--------------------|-------|
| 1. Start procedure | ABORT |
| 2. Starter relay   | CHECK |

In flight

Terminate flight as soon as possible and check for starter relay failure!

3.7 AMPLIFIED EMERGENCY PROCEDURES

## ENGINE FAILURES

If engine failure occurs before take off, it is the most important thing to bring the airplane to a stop on the remaining runway. The check list procedures enhance safety, should an emergency of this kind occur.


If engine failure occurs after take off, the first requirement is to lower the nose, because speed may have been lost during recognition of the failure it may be necessary to lower the nose more than expected. It is vital to regain safe glide speed promptly.

In most cases you proceed to a straight ahead landing with slight and gentle deviations to avoid obstacles. Altitude and speed are only seldom sufficient to carry out the necessary 180° turn in glide flight to return to the runway. The check list procedures assume that sufficient time remains to switch off the fuel supply and ignition prior to touchdown.

If engine failure occurs in flight the best glide flight speed (see also Fig. 3.1) must be attained as quickly as possible. In glide flight approach to a suitable landing location attempt to establish the cause of engine failure. If time permits, attempt to restart the engine with the aid of the check list procedures. Should the engine fail to restart, execute a power off emergency landing.

Should the restart be successful and the cause is not identified, further failures are likely and the continuation of the flight should be planned accordingly.

Fig. 3.1 Maximum Glide Distance



- windmilling propeller
- Flaps up
- Calm air
- Standard altitude

Best glide speed	
Airplane weight	V (IAS)
990 kg (2182 lbs)	135 km/h (73 kts)
920 kg (2028 lbs)	130 km/h (70 kts)
850 kg (1874 lbs)	125 km/h (68 kts)
800 kg (1764 lbs)	121 km/h (66 kts)
750 kg (1653 lbs)	118 km/h (64 kts)

**EMERGENCY LANDINGS**

If all attempts to restart the engine have failed and an emergency landing is imminent, select a suitable landing location and prepare for landing in accordance with the check list procedures "Power Off Landing".

Before attempting to land with engine power outside of an airport, fly over the most suitable landing area at a safe height, but low enough to be able to inspect the condition of the field and to spot possible obstacles. Proceed in accordance with the check list "Power On Landing".

In preparing for ditching strap down heavy objects in the baggage compartment. Transmit " Mayday " on a frequency of 121.5 MHz indicating position and intended action. Set transponder, if provided, to 7700. Do not attempt to flare prior to touchdown, since it is difficult to assess the height of the aircraft above water.

During an emergency landing do not switch off the avionics switch and the master switch until an emergency landing is a dead certainty. Switching off too early will shut off the altimeter with coding device (if installed) and the electrical systems of the aircraft.

**LANDING WITHOUT ELEVATOR CONTROL**

The G 115C can be controlled from a descending attitude into a normal landing attitude by use of the elevator trim. This applies to all flap settings; a flap setting of 60° is preferable. For landings with lost elevator control, it is recommended to choose an airfield with sufficient length. Execute an approach with a RPM setting of approx. 1500 RPM. Control flaring with elevator trim and reduce power to idle shortly prior to touch down or shortly thereafter. This ensures good controllability of the nosedown pitching moment resulting from the power reduction. This procedure should be practised beforehand at a safe altitude.

**LANDING WITHOUT AILERON CONTROL**

If an aileron control failure occurs it is possible to enter and also to complete turns using the rudder, making sure that the speed does not drop below 130 km/h (70 kts). Should the airspeed decrease while in a turn, increase speed prior to leaving the turn. In addition the throttle can be positioned to idle to accelerate leaving the turn. Avoid bank angles in excess of 30°. If a landing must be made without lateral control, the approach must be made on idle power and without using full flaps. Such an approach should be exercised beforehand at a safe altitude.



**FIRE**

Although the possibility of an engine fire in flight is extremely remote, proceed in accordance with the check list should the situation arise and then proceed with an emergency landing. Never attempt to restart the engine under such conditions.

The first sign of a fire in the electric system is normally the smell of burning or smoldering insulation. Proceeding in accordance with the check list "Electrical Fire in Flight" is sufficient to remedy the fire.

**ICING**

**INADVERTANT FLIGHT INTO ICING CONDITIONS**

Flying into icing conditions is generally forbidden. Should this happen inadvertantly, however, the situation can be best handled by proceeding according to the check list. The best thing to do, of course, is to return, change heading and/or altitude to avoid icing.

**SPIN RECOVERY (UNINTENTIONAL SPIN)**

Intentional spins without wheel fairings or with extended flaps are not approved !  
Should a spin be entered unintentionally, the following procedure for spin recovery should be initiated:

1. Apply and maintain full rudder opposite the direction of rotation.
2. Aileron NEUTRAL OR INTO SPIN DIRECTION
3. Elevator control NEUTRAL UNTIL ROTATION STOPS

and then

4. Rudder NEUTRAL

Ease back on control wheel (optional control stick) to recover smoothly from the dive (Anticipated altitude loss during spin recovery is 300 m / 1000 ft).

**ABANDONING THE AIRCRAFT BY PARACHUTE**

The G 115C is not equipped with a special emergency jettison system. During spinning emergency exit is possible by means of opening the sliding canopy, because the airspeed and acceleration forces are quite low.

Before leaving the aircraft, the engine must be shut down (pull mixture lever, ignition off) and the safety harness should be released. Egress from the cockpit can be assisted by using the fuselage frame and the frame handles.

As soon as the engine has been shut down, it is recommended that the pilot attempts to exit in the area of the wing root aiming in the direction of spin. A safe slide over the wing leading edge is then possible. If an emergency occurs at high altitude, it is advised that a delay in pulling the release lanyard be made (to avoid the possibility of the airplane fouling the parachute), at low altitude the lanyard must be pulled as soon as possible.

**NOTE**

Although egress from the G 115C is possible even in the most difficult circumstances (outside of the normal spin conditions), it can be flown safely in accordance with the recovery procedure. An emergency exit is under normal circumstances not necessary and should only be attempted in extreme pilots difficulties and/or damaged airaircraft (for example blocked or jammed moveable surfaces; crash).

**ENGINE ROUGHNESS OR POWER LOSS****CARBURETOR ICING**

A sudden loss of engine power or engine roughness could be attributed to carburetor icing. To remove the ice switch to full power and apply full carburetor heat until engine returns to smooth operation. Then select carburetor heat OFF and reset the throttle. Should conditions require repeated use of carburetor heat in cruising, use the preheat to prevent icing and lean mixture for smoothest engine operation.

**NOTE**

For continuous operation, keep the needle for approx. 5°C out of yellow arc (carburetor temperature).

**ICED AIR INTAKE FILTER**

Inexplicable loss of power can be caused by ice in the air filter (monitor RPM !)

Air filter icing : Operate the carburetor heating ON and leave it operated / set a suitable mixture.

## FOULED IGNITION PLUGS

Slight engine roughness can be caused by one or more of the ignition plugs being coked or leaded up. Remedy by turning the ignition switch briefly from the "BOTH" position to either "L" or "R". A perceptible drop in power when operating on a single magneto is a sign that an ignition plug or magneto is defective. Since an ignition plug defect is more probable, it is good practice to set the mixture to the lean value as recommended for cruising. Should this not remedy the situation within a few minutes, select a somewhat richer mixture to obtain smoother engine operation. If everything else fails, get expert advice at the nearest airport and keep the ignition switch in the "BOTH" position, unless exceptional engine roughness necessitates using only a single magneto.

## MAGNETO FAILURE

Sudden engine roughness or misfiring are usually a sign of a defective magneto. Switching the ignition switch from "BOTH" to either "L" or "R" will indicate which of the two magnetos is not working properly. If this is not the case, switch to the good magneto and have repair done at the nearest airport.

## LOW OIL PRESSURE

If low oil pressure occurs in conjunction with normal oil temperature, this is indicating the possibility of the oil gauge or the relief pressure valve being defective. In this case, landing at the nearest airport is recommended to have the system inspected to find out the cause of the trouble. Should a complete loss of oil pressure occur together with an increase in oil temperature, this is reason enough to suspect an imminent engine power failure. Therefore, reduce engine power without delay and search for a suitable landing field for an emergency landing, using only the minimum power to attain the field.

## ELECTRICAL SYSTEM FAILURE

Trouble in the electrical system can be noticed by regularly monitoring to the ammeter and voltmeter readings, however, it is normally very difficult to find out the cause of such disturbances. The most probable cause for alternator failure is a broken alternator drive-belt or open circuits, although other factors may cause the failure too. For instance, a faulty voltage regulator may cause the trouble. Disturbances of this kind create an "electrical emergency" requiring emergency procedures without delay.

Electrical system failures usually fall under two categories:

- excessive charging or
- inadequate charging

The following sections describe how to remedy both of these problems.

#### EXCESSIVE CHARGING

Should the ammeter read an excessive charging current, the alternator circuit breaker must be pulled and flight terminated as soon as possible.

#### ALTERNATOR FAILURE

When the red generator warning light is on, this means that the alternator is not working. The battery voltage is dropping below 24 volt. In this case, all consuming devices not essential for safe flight operations must be switched off to save the battery. Current must be saved for later operation of the flaps. Terminate flight as soon as possible.

#### STARTER RELAY FAILURE

(only if starter relay control lamp is installed)

Should the starter relay control lamp remain "ON" after the ignition sequence, the start-up procedure must be aborted and the starter relay has to be checked. Should a starter relay failure occur during flight, the flight must be terminated as soon as possible.

#### AUXILIARY FUEL PUMP FAILURE

(only if fuel pump control lamp is installed)

If the green auxiliary fuel pump control lamp is not illuminated with the switch in ON, this may be an indication of an auxiliary fuel pump failure. Terminate flight as soon as possible and check for fault.



## Table of Contents

## Section 4

Normal Procedures

	Page
4.1 General	4 - 3
4.3 Airspeeds for Normal Operations	4 - 4
4.4 Approved Maneuvers	4 - 5
4.5 Normal Procedures Checklist	4 - 5
Preflight Inspection	4 - 5
I. Cockpit	4 - 5
II. Walk-around Inspection	4 - 6
Before Engine Start	4 - 9
Engine Start	4 - 10
Warm-up	4 - 11
Before Taxi	4 - 11
Taxi	4 - 12
Ground Check	4 - 12
Before Take Off	4 - 12
Take Off	4 - 13
Climb	4 - 14
Cruise	4 - 14
Spin	4 - 15
Descent	4 - 15
Before Landing	4 - 16
Balked Landing	4 - 16
Normal Landing	4 - 16
After Landing	4 - 16

## Table of Contents (continued)

	Before Leaving the Airplane	4 - 17
	Parking	4 - 17
4.9	Amplified Normal Procedures	4 - 17
	Preflight Inspection	4 - 17
	Cockpit	4 - 18
	Walk-around Inspection	4 - 18
	Before Engine Start	4 - 20
	Engine Start	4 - 20
	Warm-Up	4 - 21
	Before Taxi	4 - 21
	Taxi	4 - 21
	Ground Check	4 - 21
	Before Take Off	4 - 22
	Take Off	4 - 22
	Climb	4 - 22
	Cruise	4 - 22
	Descent	4 - 23
	Before Landing	4 - 23
	Balked Landing	4 - 23
	Normal Landing	4 - 23
	After Landing	4 - 23
	Before Leaving the Airplane	4 - 24
	Parking	4 - 24
	Stalls	4 - 24
	Approved Maneuvers	4 - 24
4.11	Mixture Setting	4 - 27



#### 4.1 General

This section describes the recommended procedures for normal operations for the GROB G 115C and presents all of the required procedures.

Normal procedures associated with those optional systems and equipment which require handbook supplements are provided by section 9 "Supplements".

Pilots should familiarize themselves with the procedures given in this section in order to become proficient in normal operations of the airplane.

The first portion of this section consists of a short form checklist which supplies an action sequence for normal operations of the airplane.

The remainder of the section is devoted to amplified normal procedures which provide detailed information and explanations of the procedures and how to perform them. This portion of the section is not intended for use as an in-flight reference due to the lengthy explanations. The short form checklist should be used for this purpose.

All data of this section are referred to a flight mass of 990 kg (2182 lbs) unless other masses are stated.

4.3 Airspeeds for Normal Operations

Unless stated otherwise the following airspeeds apply to maximum permissible takeoff and landing weight, but can also be used for a lesser weight. To achieve the Performance stated in section 5, however, the speed as indicated for the corresponding weight must be selected.

**Takeoff**V<sub>IAS</sub>

990 kg (2182 lbs)

Climb speed under normal takeoff conditions up to 50 ft obstacle (flaps + 15°) 120 km/h (65 kts)

Best rate of climb speed (flaps 0°) at sea level V<sub>y</sub> 150 km/h (81 kts)

Best rate of climb speed (flaps 0°) at 10 000 ft V<sub>y</sub> 135 km/h (73 kts)

Angle of climb speed 1,3 V<sub>S1</sub> (flaps 15°) at sea level V<sub>x</sub> 120 km/h (65 kts)

Angle of climb speed 1,3 V<sub>S1</sub> (flaps 15°) at 10 000 ft V<sub>x</sub> 120 km/h (65 kts)

**Landing**

Landing final approach speed under normal landing conditions (flaps 60°) 130 km/h (70 kts)

Minimum balked landing speed (flaps 60°) 116 km/h (63 kts)

Maximum demonstrated crosswind at takeoff and landing 37 km/h (20 kts)

**Cruise**

Speed limit for operating in turbulent air 248 km/h (134 kts)

Maximum maneuvering speed  
990 kg (2182 lbs) 212 km/h (114 kts)

Maximum flaps extended speed 208 km/h (112 kts)

4.4 Approved Maneuvers

Utility	Entry Speed (km/h) [kts]	
Lazy Eight	245	[132]
Chandelle	245	[132]
Steep turns	245	[132]

**WARNING**

Do not make full or abrupt control movements above  $V_A$  !  
 Acrobatic maneuvers are not approved !  
 At airspeeds in excess of 180 km/h (97 kts) do not apply  
 combined full control inputs (i.e. full rudder deflection  
 combined with full elevator deflection).

4.5 Normal Procedures Checklist

## Preflight Inspection

## I. Cockpit


For night operation check necessary equipment (see chapter 2,  
 Kinds of operation equipment list); functioning flashlight  
 available.

- |                              |                              |
|------------------------------|------------------------------|
| a) Pilots license and papers | CHECKED                      |
| b) Checklist                 | IN COCKPIT                   |
| c) Control lock              | REMOVE                       |
| d) Parking brake             | AS REQUIRED                  |
| e) Ignition key              | REMOVE                       |
| f) Windows                   | CHECK CLEAN AND<br>UNDAMAGED |
| g) Circuit breakers          | IN                           |
| h) All switches              | OFF                          |
| i) Master switch             | ON                           |
| j) Fuel quantity gauge       | CHECK                        |
| k) Master switch             | OFF                          |
| l) Throttle                  | IDLE                         |
| m) Mixture                   | LEAN CUT-OFF                 |
| n) Foreign objects           | REMOVE                       |
| o) ELT (if installed)        | POSITION "ARMED"             |

Green lamp on the remote control (if installed) must be shine!

II. Walk-around Inspection

Fig. 4.1. Visual Inspection



1. Fuselage

- |                          |                  |
|--------------------------|------------------|
| a) Damage                | CHECK            |
| b) All antennas          | CHECK            |
| c) Static pressure ports | CHECK BOTH CLEAN |

**2. Empennage**

- |                              |       |
|------------------------------|-------|
| a) Fins and control surfaces | CHECK |
| b) Mass balances             | CHECK |
| c) Trim tab                  | CHECK |
| d) Beacon                    | CHECK |
| e) Position light            | CHECK |

**3. Right wing**

- |                                  |                 |
|----------------------------------|-----------------|
| a) Flap and hinges               | CHECK           |
| b) Aileron and hinges            | CHECK           |
| c) Tie-down                      | REMOVE          |
| d) Position light (if installed) | CHECK           |
| e) Strobe light (if installed)   | CHECK           |
| f) Wing tip                      | CHECK           |
| g) Fuel vent                     | CHECK           |
| h) Standing water in filler well | REMOVE          |
| Fuel quantity                    | CHECK           |
| Fuel filler cap tight            | CHECK TIGHT     |
| i) Wing surface                  | CHECK CONDITION |

**4. RH main landing gear**

- |                          |                   |
|--------------------------|-------------------|
| a) Tire, wheel and brake | VISUAL INSPECTION |
| b) Wheel chock           | REMOVE            |
| c) Slip mark (red paint) | VISUAL INSPECTION |
| d) Wheel fairing         | CHECK             |
| e) Tire pressure         | CHECK             |

**5. Nose section**

- |  |                   |
|--|-------------------|
| a) Oil<br>(minimum quantity 5.7 liters / 6 quarts) | CHECK QUANTITY    |
| b) Cowling   | PROPERLY ATTACHED |





j) Wing tip	CHECK
k) Tie-down	REMOVE
l) Position light	CHECK
m) Strobe light	CHECK
n) Beacon (if installed)	CHECK
o) Aileron and hinges	CHECK
p) Flap and hinges	CHECK
q) Fuel tanks : RH wing	DRAIN
LH wing	DRAIN

**Before Engine Start**

1. Preflight check	COMPLETE
2. Fuel and oil levels	CHECKED
3. Seatbelts and harnesses	APPLIED AND FASTENED
4. Pedals	ADJUSTED
5. Seatbelts and harnesses on empty seat	FASTEN
6. Canopy closed and locked	CHECK
7. Parking brake	SET
8. Primary flight controls	FREE TO MOVE PROPER DIRECTION
9. Fuel cock	ON
10. Trim	FREE TO MOVE
11. Trim	NEUTRAL
12. Throttle and mixture lever	CHECK FREE MOVEMENT & TRAVEL
13. Operating levers	SET FRICTION
14. Avionics master switch	OFF
<b>WARNING</b>	
To avoid damage to the electronic equipment always switch off the avionics master switch during start up.	
15. Master switch	ON

- |   |          |
|---|----------|
| 16. Engine instruments                      | CHECK    |
| 17. Fuel quantity for the<br>planned flight | ADEQUATE |
| 18. Annunciator panel lamp test             | CHECK    |

**NOTE**

During "lamp-test" all lights will illuminate with full brightness.

**Engine Start**

- |                         |   |
|-------------------------|---|
| 1. Mixture              | FULL RICH   |
| 2. Carburetor heat      | COLD, PUSHED IN   |
| 3. Electrical fuel pump | ON (Activity audible /<br>light on / fuel<br>pressure increase) |

**NOTE**


If instrument panel lighting is switched ON, all green annunciator lights are dimmed.

- |                                   |  |
|-----------------------------------|--|
| 4. Strobe light/Beacon/Pos.-light | ON   |
| 5. Throttle                       | IDLE<br>pump 2-3 times when<br>engine cold then set<br>to 1/4 travel |
| 6. Primer button                  | PUSH<br>for approx. 5 sec  |

**NOTE**

The primer button may be operated a maximum of 3 times. If the engine fails to start switch off the ignition / set throttle idle / set mixture open and turn the propeller by hand several times. Wait for 15 minutes and then repeat the starting procedure.

- |                       |  |
|-----------------------|--|
| 7. Parking brake      | SET  |
| 8. Propeller vicinity | CLEAR  |
| 9. Ignition           | START, position<br>to BOTH, as soon<br>as engine running |
| 10. Throttle          | 1000 - 1200 RPM<br>ADJUST                                |



- |                          |  |
|--------------------------|--|
| 11. Oil pressure         | OIL PRESSURE MUST<br>RISE WITHIN 30 SEC  |
| 12. Electrical fuel pump | OFF, as soon as<br>engine running stable |

**WARNING**

If oil pressure is not 1.7 bar (24.7 PSI) within 30 sec of engine running, shut off engine and do not repeat starting procedure until cause of trouble has been eliminated.

- |                      |       |
|----------------------|-------|
| 13. Anunciator Panel | Check |
| DURING ENGINE START: |       |
| Starter light        | RED   |

**Warm-up**

- |   |               |
|---|---------------|
| 1. When engine running smoothly   | MAX. 1500 RPM |
| 2. Ammeter  | POSITIVE SIDE |
| 3. Fully extend and retract flaps<br>(indication and visual inspection<br>checking at each stage<br>flaps symmetry) | COMPLETED     |
| 4. Anunciator Panel   | NO RED LIGHTS |

**WARNING**

No " RED-LIGHTS " must be illuminated ! If not, shut off engine and do not repeat starting procedure until cause of trouble has been eliminated !

**Before Taxi**

- |   |                |
|---|----------------|
| 1. Flight instruments                           | CHECK / ADJUST |
| 2. Engine instruments                           | CHECK          |
| 3. Avionics master switch                       | ON             |
| 4. Avionics switches                            | ON             |
| 5. Avionics frequency, volume,<br>test position | CHECK          |
| 6. Maneuvering area                             | CHECK          |
| 7. Parking brake                                | RELEASE        |

**Taxi**

- |                       |       |
|-----------------------|-------|
| 1. Nose wheel control | CHECK |
|-----------------------|-------|

**CAUTION !** When taxiing tight turns it may be necessary to assist the nose wheel by the toe-brakes.

- |  |       |
|--|-------|
| 2. Braking action                            | CHECK |
| 3. Compass                                   | CHECK |
| 4. Turn-and-bank indicator<br>(if installed) | CHECK |
| 5. Directional gyro                          | CHECK |
| 6. Attitude indicator                        | CHECK |

**Ground Check / Run Up**

- |   |                      |
|---|----------------------|
| 1. Parking brake                                    | SET                  |
| 2. Oil pressure (must be at least in yellow sector) | CHECK                |
| 3. Throttle   | 1800 RPM             |
| 4. Carburetor heat                                  | HOT / FULLY OUT      |
| 5. RPM drop<br>Carburetor heat temp. rise up        | MIN. 50 RPM<br>CHECK |
| 6. Carburetor heat                                  | COLD / AND ARREST    |
| 7. Ignition switch set to L                         | RPM MUST DROP        |
| 8. Ignition switch set to BOTH                      | 1800 RPM             |
| 9. Ignition switch set to R                         | RPM MUST DROP        |
| Maximum RPM drop                                    | 175 RPM              |
| Minimum RPM drop                                    | 50 RPM               |
| Maximum RPM drop difference                         | 50 RPM               |
| 10. Ignition switch set to BOTH                     | 1800 RPM             |
| 11. Throttle<br>(min. oil temperature 40°C)         | IDLE / 600 - 700 RPM |
| 12. Throttle, recommended                           | 1100 - 1500 RPM      |

**Before Take Off**

- |                            |                               |
|----------------------------|-------------------------------|
| 1. Seatbelts and harnesses | FASTEN AND<br>CHECK TIGHTNESS |
|----------------------------|-------------------------------|

**SECTION 4 :**
**Normal  
Procedures**

- |   |   |
|---|---|
| 2. Canopy closed and locked                     | CHECK   |
| 3. Fuel cock                                    | ON  |
| 4. Trim   | SET FOR TAKEOFF                               |
| 5. Mixture                                      | ADJUST  |
| 6. Fuel tank selector                           | MOST CONTENT                                  |
| 7. Flaps  | 15° (TAKE OFF)                                |
| 8. Carburetor heat                              | COLD / FULLY PUSHED<br>IN AND ARREST          |
| 9. Electrical fuel pump                         | ON  |
| 10. Ignition key set to BOTH                    | CHECK   |
| 11. Vacuum gauge<br>(if installed)              | IN GREEN RANGE                                |
| 12. Flight instruments                          | CHECK   |
| 13. Engine instruments                          | IN GREEN RANGE (EXCEPT<br>OIL IN YELLOW ARC)  |
| 14. Oil temperature<br>(minimum 40°C or more !) | CHECK   |
| 15. All control surfaces<br>for full deflection | CHECK   |
| 16. Parking brake                               | RELEASE                                       |
| 17. Tank asymmetry                              | MAXIMUM 20 ltr.<br>(5.3 US.gal./4.4 Imp.gal.) |

**Take Off**

- |                  |               |
|------------------|---------------|
| 1. Brakes        | HOLD          |
| 2. Full throttle | MIN. 2200 RPM |
| 3. Mixture       | FULL RICH     |

**NOTE**

For 5000 ft density altitude or above or high ambient temperatures, roughness or reduction of power may occur at full rich mixture. The mixture may be adjusted to obtain smooth engine operation.

- |           |         |
|-----------|---------|
| 4. Brakes | RELEASE |
|-----------|---------|



- 5. Nose gear relieve AT MIN. 60 km/h (32 kts)
- 6. Nose gear lift-off 100 km/h (54 kts)
- 7. Speed at flaps 15° at height of 15 m (50 ft) 120 km/h (65 kts)
- 8. Flaps RETRACT 150 ft ABOVE GROUND
- 9. Speed at flaps 0° 145 km/h (78 kts)
- 10. Electrical fuel pump OFF (APPROX. 1000 FT ABOVE GROUND)

**Climb**

- 1. Climb power CHECK
- 2. Mixture FULL RICH

**NOTE**

For 5000 ft density altitude or above or high ambient temperatures, roughness or reduction of power may occur at full rich mixture. The mixture may be adjusted to obtain smooth engine operation.

- 3. Engine instruments CHECK

**NOTE**

Check the cylinderhead temperature. In the case of too high temperature, increase airspeed and/or fuel flow.

- 4. Airspeed BLUE LINE or higher
- 5. Trim SET
- 6. Altimeter setting CHECK

**Cruise**

- 1. Power AS REQUIRED
- 2. Carburetor heat CHECK

**NOTE**

Keep needle out of yellow arc during possible carburetor icing conditions.

- 3. Mixture ADJUST
- 4. Trim SET

**Spin**

## SPIN ENTRY

- |                             |  |
|-----------------------------|--|
| 1. Loose items              | STOW   |
| 2. Seat belts and harnesses | TIGHTEN  |
| 3. Electrical fuel pump     | OFF  |
| 4. Engine                   | IDLE   |
| 5. Wings                    | LEVEL  |
| 6. Recommended entry speed  | ≈ 100 km/h (54 kts)<br>(max. 180 km/h [97kts]) |
| 7. Rudder                   | FULLY IN DIRECTION                             |
| 8. Elevator                 | FULL UP  |

## DURING SPIN

- |             |                            |
|-------------|----------------------------|
| 1. Elevator | FULL UP                    |
| 2. Aileron  | NEUTRAL                    |
| 3. Rudder   | FULLY IN SPIN<br>DIRECTION |

## RECOVERY

- |             |  |
|-------------|--|
| 1. Rudder   | OPPOSITE TO SPIN<br>DIRECTION            |
| 2. Aileron  | NEUTRAL OR <u>INTO</u><br>SPIN DIRECTION |
| 3. Elevator | RELEASE FORCE                            |

**Descent**

- |  |             |
|--|-------------|
| 1. Altimeter                             | SET         |
| 2. Power setting<br>(avoid lengthy idle) | AS REQUIRED |
| 3. Carburetor heat                       | CHECK       |

**NOTE**

Keep needle out of yellow arc during possible carburetor icing conditions.

- |                       |              |
|-----------------------|--------------|
| 4. Fuel tank selector | MOST CONTENT |
|-----------------------|--------------|

**Before Landing**

- |  |              |
|--|--------------|
| 1. Seatbelts and harnesses                       | FASTEN TIGHT |
| 2. Electrical fuel pump                          | ON           |
| 3. Carburetor heat temperature out of yellow arc | CHECK        |
| 4. Mixture                                       | AS REQUIRED  |
| 5. Fuel selector valve                           | MOST CONTENT |
| 6. Flaps   | EXTEND       |

**WARNING:**  $V_{max}$  with extended flaps  
208 km/h (112 kts)

- |   |                   |
|---|-------------------|
| 7. Recommended final approach speed with flaps 60° (990 kg) | 130 km/h (70 kts) |
| 8. Trim   | SET               |

**Balked Landing**

- |                    |                         |
|--------------------|-------------------------|
| 1. Throttle        | FULL THROTTLE           |
| 2. Mixture         | RICH                    |
| 3. Carburetor heat | COLD / FULLY PUSHED IN  |
| 4. Flaps           | RETRACT TO 0° or 15°    |
| 5. Climb           | CHECK SPEED (blue line) |

**Normal Landing**

- |                      |  |
|----------------------|--|
| 1. Flaps             | 60°  |
| 2. Airspeed to flare | 130 km/h (70 kts)                              |
| 3. Touchdown         | MAIN GEAR FIRST AT LESS THAN 108 km/h (58 kts) |
| 4. Nose wheel        | LOWER GENTLY                                   |
| 5. Brakes            | AS REQUIRED                                    |

**After Landing**

- |                         |                        |
|-------------------------|------------------------|
| 1. Electrical fuel pump | OFF                    |
| 2. Carburetor heat      | COLD / FULLY PUSHED IN |





- |          |                      |
|----------|----------------------|
| 3. Flaps | RETRACT              |
| 4. Trim  | SET TO TAKEOFF RANGE |

**Before Leaving the Airplane**

- |                                    |   |
|------------------------------------|---|
| 1. Parking brake                   | SET   |
| 2. ELT                             | CHECK FREQ. 121.5 MHz<br>for unintentional function |
| 3. Avionics master switch          | OFF   |
| 4. All electrical aircraft systems | OFF   |
| 5. Short circuit test              | COMPLETE ( 1000 RPM )                               |
| 6. Throttle                        | IDLE  |
| 7. Mixture                         | LEAN CUT-OFF  |
| 8. Ignition switch                 | OFF   |
| 9. Ignition key                    | REMOVE  |
| 10. Fuel selector valve            | MOST CONTENT  |
| 11. Master switch                  | OFF   |
| 12. Control lock                   | APPLY   |

**Parking**

- |                            |          |
|----------------------------|----------|
| 1. Wheel chocks            | POSITION |
| 2. Parking brake           | RELEASE  |
| 3. Tie-downs (if required) | SECURE   |
| 4. Pitot tube cap          | APPLY    |

**4.9 Amplified Normal Procedures****Preflight Inspection**

The airplane should be given a thorough preflight and walk around check. These procedures can be amplified accordingly when deemed necessary by the pilot. The preflight inspection should include at least the following:

- Check airworthiness of airplane
- Check papers for completeness and validity
- Computation of weight and C.G. limits
- Determination of take-off distance
- Determination of flight performance

Before refuelling, make sure that water collected near the tank filler is removed !

The baggage should be weighed, properly stowed and strapped down.

The passenger should be instructed on the use of safety harnesses and the ventilation system, and should be informed that smoking is prohibited. Warn the passenger not to obstruct the controls, not to touch the instruments and not to tamper with the canopy mechanism.

#### COCKPIT

Commence internal checking by removing the control lock and setting the parking brake. Remove ignition key if still inserted. Check for unobstructed visibility and clean windows. Check guide rails and lock mechanism of the canopy for proper functioning.

After switching on the master switch the fuel gauge reading must show a sufficient quantity (incl. reserve) for the intended flight. Then turn the master switch OFF, to save the battery. Make sure that throttle and mixture are full aft (idle, lean cut-off) to prevent unintentional firing of the engine when checking the propeller.

Check the cockpit for foreign objects both on the left and right seat and in the baggage compartment. If the right seat is vacant, close and lock the seatbelt and harness.

#### WALK-AROUND INSPECTION

Check fuselage for damage. Check fins and control surfaces for damage. Make sure horizontal tail is firmly in place. Operate both elevators and rudder to check freedom of movement, free play and hinge pins secure. Check elevator mass balance tips for damage. Check connection and play of the trim tab. Check beacon and position light for damage. Make sure all antennas are tightly in place.

**Check pitot static system :**

Check both drilled plates provided for pick-up of the static pressure are open and un-obstructed; these are located at the LH and RH side of the fuselage.

Remove the pitot tube cap at the left wing lower side and ensure that the tube is open and unobstructed. This system requires no drainage. The pitot heat system is not active on ground. To test the proper function of the system, press test button on annunciator panel approximately 5 to 10 seconds, the pitot tube should warm up.

Check right wing flap for damage. Inspect RH aileron for full freedom of movement, free play, hinge pins and proper attachment of the actuator. Remove tie-down from tie-down point.

Check position light and strobe light (if installed) for damage. Inspect wing tip and complete wing surface for damage.

Inspect RH landing gear strut, tire, wheel and brake disk for damage. Check tire and brake lining wear. Remove chocks and inspect slip mark. Inspect wheel fairing for secure fitting and damage. Check correct tire pressure (3.0 bar; 43.5 PSI).

Open the access hole in the top cowling and check the engine oil level (5.7 - 7.6 liters = 6 - 8 quarts).

**NOTE**

For a flight of full range of the engine requires 7.6 liters (8 quarts).

Check the cowling for damage and make sure it is firmly in place. Ensure that the air intake opening is free of debris and dirt and is undamaged. The air filter must be securely attached. Check the landing light (if installed) for damage. Make sure that the propeller is securely attached. Check leading edge and propeller surface for damage and inspect the trailing edge for chipping. Also make sure the propeller spinner is tight and check for cracks.

Excercise the stroke of the nose gear. Visually inspect nose wheel and nose wheel tire. Nose wheel tire pressure should be 2.5 bar (36 PSI). Check the nose gear fairing for damage and make sure it is firmly in place. Also remove towbar if necessary and stow safely.

Inspect LH main gear and LH wing same as for the right-hand side. To functionally check the stall warning and pitot heat switch on the master switch. Push the test button of the annunciator panel for a few seconds. The pitot tube must warm up. Position tab upwards - stall warning must sound. Return master switch OFF. Check LH aileron and LH flap same as described for right-hand side.

Drain the water of all fuel tanks.

### Before Engine Start

After completing the preflight inspection and checking the fuel and oil level, enter the cockpit. If two heavy people stand simultaneously on the wing trailing edge the airplane may nose-up. Set the pedals to a comfortable position and fasten seatbelts and harnesses. If the RH seat is vacant, latch and secure this belt and harness also. Make sure the canopy is closed and locked. Then set the parking brake and check easy movement of the control surfaces and make sure that the deflection is in the correct direction. Check position of the fuel shutoff valve ("ON") and then check that trimming is possible over the full range before setting it to the range for take off. Check free movement and travel of throttle and mixture lever and set the friction. Make sure the avionics master switch is positioned "OFF". Switch on the master switch and check the engine instruments, paying particular attention to an adequate fuel quantity.

### Engine Start

Set mixture to full rich and push in the carburetor heat (cold). Switch on the electrical fuel pump (if equipped: Activity audible / electrical warning light on / fuel pressure increase).

Switch on the position lights, the beacon and the strobe lights.

When the engine is cold move the throttle two to three times up to full throttle before setting it to roughly a quarter of its travel. Press the primer button for approx. 5 sec..

When the engine is warm move the throttle one time up to full throttle before setting it to roughly a quarter of its travel.

#### NOTE

The primer button may be operated a maximum of 3 times. If the engine fails to start switch off the ignition and turn the propeller by hand several times. Wait for 15 minutes and then repeat the starting procedure.

Do not press the primer if the engine is warm !

Make sure that the propeller area is clear. Start engine by turning the ignition key to the "START" position. As soon as the engine is running return the ignition key to "BOTH". Using the throttle, adjust an engine speed of 1000 - 1200 RPM. Oil pressure must increase to min. 1.7 bar (24.7 PSI) within 30 seconds.

#### WARNING

If the oil pressure does not attain 1.7 bar (24.7 PSI) within 30 sec. after starting the engine, shut down the engine and do not attempt to restart until the cause for the trouble has been eliminated.

If it is suspected that the starter motor is still energized, put master switch "OFF" to prevent electrical fire.

**Warm-Up**

Switch off the electrical fuel pump when warming up.

**WARNING**

If the engine shuts off after the first time the electrical fuel pump is switched off, a failure of the mechanical fuel pump might be the reason. Do not take off, before this malfunction has been eliminated !

As long as the engine has still not attained its operating temperature, do not exceed 1500 RPM. The ammeter must show a charging current, i.e. on the positive side. During warm-up extend and retract the flaps by using the flap switch and check the flap indication and actual flap position by observing from the cockpit.

**Before Taxi**

Set flight instruments such as altimeter, directional gyro and attitude indicator. Read the engine instruments regularly. Switch on the avionics master switch and the necessary avionics switches. Set the necessary frequencies and adjust the volume, testing if necessary. Make sure the taxi area is clear and then release the parking brake.

**Taxi**

During taxi check nosewheel control and brake effectiveness. Check functioning of compass, turn and bank indicator, attitude indicator.

**CAUTION !** When taxiing tight turns it may be necessary to assist the nose wheel by the toe-brakes.

**Ground Check / Run Up**

Set the park brake and pump the brake pedals once. The oil pressure must be at least in the yellow sector. Set an engine speed of approx. 1800 RPM. Pull the carburetor heat knob to "HOT" and watch for drop in RPM which must be at least 50 RPM. Check the carburetor temperature rise up. Return carburetor heat to "COLD". To check the magnetos turn the ignition key to position "L" and observe drop in RPM. Return ignition key to the "BOTH" position and check that the original RPM is reattained. Check the RH magneto. Minimum RPM drop must be 50 RPM, but not exceed a max. of 175 RPM. The difference in the RPM drop of the LH and RH magnetos must not exceed 50 RPM. Return ignition switch to "BOTH", set for idle and check the idling RPM. Idling RPM must be between 600 and 700 RPM, if the oil temperature is min. 40°C. Then use the throttle to set a RPM of 1100 - 1500 RPM. Use the tank with the most content (take notice of the tank asymmetry !).

### Before Take Off

Fasten seatbelts and shoulder harnesses (on empty seat also). Make sure the canopy is properly closed and locked. The fuel shut off valve must be set to "ON", the trim in the take off range and the mixture set "FOR SMOOTH OPERATION". Flap position for take off is 15°. The carburetor heat must be set to "COLD" (fully pushed in). Switch electrical fuel pump "ON" and make sure that the ignition key is positioned to "BOTH". If a vacuum system is installed, its indicator should read the green sector. Recheck all flight and engine instruments. In case the engine was run only for a short time, check the attitude indicator is stabilized. The oil temperature must be exceed 40°C or more before take off. Exercise all control surfaces for full response, before finally releasing the parking brake. The max. allowable fuel asymmetry is 20 l. (5.28 US.gal./4.4 Imp.gal.).

### Take Off

Precisely aim the aircraft on the runway in the direction of take off. Operate the brakes and apply full power. This must produce an engine speed of at least 2200 RPM. Then release the brakes and at a speed of 60 km/h (32 kts) take the load off the nose wheel. Lift the nose wheel at a speed of 100 km/h (54 kts). Climb speed for a flap position of 15° is 120 km/h (65 kts).

When the airplane has attained a height of 150 ft above ground the flaps can be retracted. The recommended climb speed in flap position 0° is at an airspeed of ≈ 145 km/h (78 kts) [blue line] at lower altitude. When the aircraft is approx. 1000 ft above ground the electrical fuel pump can be switched "OFF".

### Climb

Make sure the throttle is positioned to "FULL OPEN" for max. climb and the mixture to "FULL RICH" (MSL up to density altitude 5000 ft). Regularly read the engine instruments. The airspeed for climbing should be according to chart on Fig. 5.3.8. Trim the airplane accordingly. Check the altimeter setting (standard setting ?).

### Cruise

Set desired engine RPM and power according to cruise charts. This speed should not be allowed to drop below 1800 RPM or exceed the maximum of 2700 RPM. To avoid laboring the engine do not set the power to exceed 75 % over lengthy periods. Lean the mixture according to altitude. Trim the airplane as required. Set the carburetor heating as required: Keep the needle out of yellow arc during possible icing conditions.

### Descent

Set the altimeter to the QNH of the airfield. Select power and engine RPM as required, avoiding lengthy idling. Exercise carburetor heat as required, noting that intermediate positions are possible: Keep the needle out of yellow arc during possible icing conditions.

### Before Landing

Make sure seatbelt and harnesses are tight. Reduce air-speed to less than 208 km/h (112 kts). Switch on the electrical fuel pump and pull the carburetor heat as required. Then position the mixture control as required (see Chapter 4-11) and extend the flaps.

### WARNING

$V_{max}$  with extended flaps  
208 km/h (112 kts)  
[Upper limit of white range]

The recommended final approach speed with a mass of 990 kg (2182 lbs.) and the 60° flap position is 130 km/h (70 kts) for normal landings. Under cross wind or strong turbulence conditions as well as in rain or icy weather suitable higher speeds are necessary. Trim the airplane to the desired range.

### Balked Landing

Set the throttle to full power and the mixture according to the table. Fully press the carburetor heat control to "COLD". Set the flaps to 0° or 15° depending on flight altitude. Start transition to climb.

### Normal Landing

Set the flaps to 60°. The final approach speed until flare out should be 130 km/h (70 kts) unless additional speed is required due to cross wind, gusts, rain or icy weather.

Touch down with the main landing gear first when the speed indicator reads less than 108 km/h (58 kts). Gently lower the nose and apply the brakes accordingly.

### After Landing

Position the carburetor heat to "COLD" as soon as possible after landing to prevent debris gaining access to the engine. Switch off the electrical fuel pump, retract flaps and retrim the airplane for the take off condition.



### Before Leaving the Airplane

Before climbing out, set the parking brake and pump the brake pedals once. Switch off the avionics master switch and all aircraft electrical systems. To carry out a magneto ground test select a speed of max. 1000 RPM. Then briefly turn the ignition switch to the "OFF" position before immediately returning it to the "BOTH" position. This must produce a clear tendency for the engine to stop. Then shut down the engine using the normal procedure by pulling the mixture control back to the "LEAN CUT-OFF" position. When the engine has stopped, turn the ignition key to the "OFF" position and remove the ignition key. Then switch off the master switch and apply control lock. Turn the fuel selector valve to the fullest tank to prevent fuel asymmetries.

### Parking

If the airplane is to be parked for a lengthy period, chock the wheels and tie down the aircraft at the prescribed locations. Release the parking brake. Apply pitot tube cap.

### Stalls

An approaching stall is indicated by a stall warning horn and a stall warning lamp which are activated between 19 km/h (10 kts) and 9,2 km/h (5 kts) above stall speed in calm air. Mild airframe buffeting may also precede the stall. The loss of altitude at low altitude is approx. 300 ft. With increasing altitude, the losses will also increase.

#### WARNING

The stall warning system is inoperative with the master switch OFF.

During preflight, the stall warning system should be checked by turning the master switch ON, lifting the detector and checking to determine if the horn is actuated. The master switch should be returned to the OFF position after the check is complete.

### Approved Maneuvers

The airplane is approved for certain maneuvers, provided it is loaded within the approved weight and center of gravity limits (See Section 2 - Limitations).

The approved maneuvers are:  
Chandelles, Lazy Eights and Steep turns.  
Entry speeds, refer to Section 2 - Limitations.



Before performing maneuvers, check for:

Fuel shutoff valve	: ON
Fuel selection	: MOST CONTENT
Fuel asymmetry	: max. 20 liters (5.3 U.S.gal./4.4 Imp.gal.)
Electrical fuel pump	: OFF
Seatbelts and harnesses	: APPLIED AND FASTENED
Seatbelts on empty seat	: FASTENED
Canopy	: CLOSED AND LOCKED
Loose objects	: STOWED
Baggage	: <u>NO BAGGAGE</u> IN BAGGAGE COMPARTMENT

Aerobatic maneuvers are not approved.

## SPIN

### General

Prior to intentional spinning the maximum weight of 920 kg (2028 lbs) must not be exceeded !

Before starting this maneuver, tighten the safety harnesses and make sure that all loose objects are securely stowed. Start this maneuver at a safe height. The electrical fuel pump must be switched off and the flaps must be retracted.

### ENTRY

Slow the airplane with engine at IDLE and the wings level. At stall speed (approx. 100 km/h [54 kts] IAS) enter the spin by applying full rudder deflection into the desired spin direction and simultaneously pull the elevator full up with aileron in neutral position. In a fully developed spin the aircraft rotates at a 2 sec. rate per turn.

**DURING SPIN**

During spinning, hold the control wheel (optional control stick) in the full back position and keep the ailerons neutral. Full rudder deflection in direction of spin must be maintained.

The indicated airspeed will stabilize at:

- 111 - 160 km/h IAS ( 60 - 86 kts) IAS

**RECOVERY**

For spin recovery check throttle position is at IDLE. Then deflect rudder fully opposite to direction of yaw rotation and put the elevator into the neutral position. Apply no opposite aileron but hold control wheel (optional control stick) in neutral or in direction of spin. The control wheel (optional control stick) held in this position will greatly assist spin recovery even from the most extreme spin conditions (not described in this handbook). For the described normal spin, aileron in position NEUTRAL is sufficient to recover. For simpler handling, this position is preferable. As soon as rotation has stopped, move all controls to neutral position and dive smoothly. The airplane will recover in about one additional turn within 1 - 2 sec. If pulling out at 3g the maximum speed will be 240 km/h (130 kts) IAS. Apply normal power. For altitude loss refer to figure 4.1.


**WARNING**

- Do not attempt recovery with ailerons against spin direction or elevator up.
- With ailerons against spin direction and fully pushed elevator during the recovery, the airplane will continue to spin faster and flutter (despite fully opposite rudder).
- If engine stops during spin, recovery has to start immediately and the pilot has to act according to Section 3 " Restart of the failed engine " (if required, start engine with mixture lever in "LEAN").
- During spin, the auxiliary fuel pump must not be switched on (Danger of fire due to flooding of carburetor)!
- The recovery sequence is important for certain types of spin. For this reason, never push the wheel forwards before opposite rudder is applied.
- To recover from difficult types of spin, use the following procedure :
  - Opposite rudder
  - Full in-spin aileron
  - Control wheel fully back

During the recovery phase (transition from a flat spin to a steep spin), move the elevators back to the neutral position to prevent the spin continuing in the opposite direction.

- Applying full power always encourages the aircraft's readiness to recover.

Fig. 4.1 Altitude Loss Including Recovery



#### NOTE

If the aircraft faults to recover, the recommended control position must be applied:  
Rudder against yaw rotation, aileron neutral, elevator release force.

Fig. 4.1 shows maximum values for altitude loss obtained from flight test using the recommended spin and recovery procedure in airspace about 5000 ft MSL. At higher altitude the altitude loss will be greater.

#### 4.11 Mixture Setting

##### General:

Leaning the fuel mixture within approved marginal conditions is necessary for full engine life, best performance, economic consumption and for safe operation of the engine, noting:

- Never exceed the maximum red line cylinder head temperature limit.

- For continuous operation cylinder head temperature should be maintained below 204°C (400°F).
- Maintain mixture control in "best power mix" position under normal conditions for rated take off, rated maximum continuous, climb and cruise powers above 75% performance.
- During take off from high elevation airport or during climb (as of approx. 5000 ft density altitude), roughness or loss of power may result from over-richness. In such a case lean mixture control only enough to obtain smooth operation - not for economy (peak EGT).
- Running the engine too rich will prove all the more unfavourable, the higher the altitude.
- Always check the mixture before increasing power.

#### Leaning procedures

1. Standard procedure with mixture control (75% power or less without flowmeter or EGT gauge):
  - Slowly move mixture control from the "FULL RICH" position to the "LEAN" position until first indication of engine roughing.
  - Then enrich for smooth engine running.
  
2. Alternative method (only in calm air !):
  - For the fixed-pitch propeller version the mixture can be leaned by means of the engine speed stroboscope.
  - Slowly move mixture control from the "FULL RICH" position toward "LEAN" position while closely watching tachometer. Continue leaning until RPM decreases.
  - At this point enrich until RPM just peaks.

**WARNING** Smooth engine running is always more important than the engine speed indication!

3. Leaning with the EGT indication  
(if EGT indications provided)

**CAUTION** Single EGT-Indicators will work correctly only in certain areas of the whole flight envelope. For this reason the lean procedure with a single EGT-Indicator is practicable only under limited conditions !

- Above 75% power - Never lean beyond 150°F on rich side of peak EGT of lean cylinder.
- 75% power and below - Operate at peak EGT of lean cylinder.
- Always keep an eye on the cylinder head temperature !

**WARNING** Smooth engine running is always more important than the EGT readings !



Table of Contents

Section 5

Performance

	Page
5.1 <b>General</b>	5 - 2
5.3 <b>Using the Performance Tables and Charts</b>	5 - 2
Fig. 5.3.1 <b>Airspeed Calibration                   Normal static source</b>	5 - 3
Fig. 5.3.2 <b>Airspeed Calibration                   Alternate static source</b>	5 - 4
Fig. 5.3.3 <b>Pressure and Density                   Altitude</b>	5 - 5
Fig. 5.3.4 <b>Stall Speed at Various                   Flap Settings</b>	5 - 6
Fig. 5.3.5 <b>Stall Speed at Load                   Factor or Banking</b>	5 - 7
Fig. 5.3.6 <b>Wind Components</b>	5 - 8
Fig. 5.3.7 <b>Take Off Distance</b>	5 - 9
Fig. 5.3.8 <b>Rate of Climb</b>	5 - 10
Fig. 5.3.9 <b>Time, Fuel and Distance                   to Climb</b>	5 - 11
Fig. 5.3.10 <b>Cruise                   (Fuel Consumption)</b>	5 - 12
Fig. 5.3.11 <b>Cruise (RPM)</b>	5 - 13
Fig. 5.3.12 <b>Cruise (True Airspeed)</b>	5 - 14
Fig. 5.3.13 <b>Range Profile</b>	5 - 15
Fig. 5.3.14 <b>Endurance Profile</b>	5 - 16
Fig. 5.3.15 <b>Landing Distance</b>	5 - 17



### 5.1 General

The performance charts on the following pages are presented in a way, that they indicate the performance you can expect from the airplane under various conditions, whilst also facilitating complete and sufficiently accurate flight planning. The values in these charts were attained by flight testing with the airplane and engine in good operating condition and corrected to International Standard Atmosphere (ISA 15°C (59°F) and 1013.2 mb (29.92 in. HG) at sea level).

The performance charts do not take into account various pilots' experiences or bad condition of the airplane. The stated performances may be achieved, if the mentioned procedures are used and the airplane is in good condition.

Cruising fuel consumption is based on the recommended lean mixture setting (best economy). Some non-determinable factors such as mixture setting procedure, operating condition of the engine and propeller as well as turbulence can effect range and endurance. Therefore, it is important to consider all available information when computing required fuel quantity for a flight.


### 5.3 Using the Performance Tables and Charts

The performance data are presented in form of tables and graphs which consider the effect of each variable. Performance data are of sufficient detail to prepare flights with the required accuracy and to stay on the safe side.

As first step of a flight preparation it is important to confirm the weight and center of gravity being in limits. Refer to Section 6.7 for details.


Fig. 5.3.1 Airspeed Calibration  
Normal static source

System Pitot-tube at wing, static pressure at fuselage



Example: Flap setting 0°  
 V IAS 119 kts  
 V CAS 116 kts


Fig. 5.3.2 Airspeed Calibration  
Alternate static source



Example:            V IAS    119 kts  
                          V CAS    115 kts



Fig.5.3.3 Pressure and Density Altitude



Example:

1. Set altimeter to 1013.25 hPa (29.92 in.HG) and read off pressure altitude (1000 ft).
2. Establish outside air temperature (+30°C)
3. Read off density altitude (3000 ft).

Result:

The airplane has a power-related altitude of 3000 ft.

**Fig. 5.3.4 Stall Speed at Various Flap Settings**





Fig. 5.3.5 Stall Speed at Load Factor or Banking



Example: Stall speed when banking 30° or 1.15 g respectively is 99 km/h (53 kts) for an aircraft weight of 850 kg (1874 lbs).

**Fig. 5.3.6 Wind Components**

Demonstrated Side Wind Component: 37 km/h (20 kts)




Fig. 5.3.7 Take Off Distance




Fig. 5.3.8 Rate of Climb





Fig. 5.3.9 Time, Fuel and Distance to Climb



Conditions:

- Full throttle
- Max. power mixture
- Flaps 0°
- V = V<sub>y</sub>
- Standard Atmosphere
- Max. Takeoff weight
- Most forward C.G.

Example: - Climb from 5700 ft DA to 12000 ft DA

Result:

- Time to climb (28-9)	19.0 min.
- Fuel to climb (17.3-6.0)	11.3 ltr.
- Distance to climb (39.0-12.0)	27 Nm

Fig. 5.3.10 Cruise (Fuel Consumption)

Example: - Pressure Altitude 6000 ft  
 - OAT 0°C  
 - Power 55 %

Conditions: - Recommended Mixture (refer to Section 4)  
 - Good condition of airplane

Result: - Fuel consumption 24.2 ltr/h  
 - NM per liter 4.1  
 - Density Altitude 5700 ft










Fig. 5.3.13 Range Profile

- Conditions:**
- No wind
  - Standard Atmosphere
  - Takeoff Weight 990 kg (2182 lbs)
  - Most forward C.G.
  - Flaps 0°
  - Good airplane condition
  - Usable fuel: 143 ltr.
  - Mixture for climb: best performance
  - Mixture for cruise: (refer to Section 4)


**Example:**

- Pressure Altitude 8000 ft
- OAT + 5°C
- Power 65 %

**Result:**


- Range 471 NM
- Density Altitude 8600 ft

**Note:** Range includes fuel for engine warm-up, takeoff, climb and a reserve of 45 min. at 45% power setting.



**Fig. 5.3.14 Endurance Profile**

Condition: - cruise  
 - recommended mixture leaning (see chapter 4.11)



**Example:**

- Fuel	85 ltr.
- Power	55 %

**Result:**

- Endurance with 45 min. reserve	2 h 43 min.
- Endurance without reserve	3 h 28 min.

**Note**

Datas for time to climb see Fig. 5.3.9

Fig. 5.3.15 Landing Distance




Table of Contents  
Section 6  
Weight and Balance

	Page
6.1 General	6 - 2
6.3 Airplane Weighing Procedure	6 - 3
Fig. 6.1 Weighing Form	6 - 4
6.5 Weight and Balance Record	6 - 5
Fig. 6.2 Weight and Balance Record	6 - 6
6.7 Weight and Balance Determination for Flight	6 - 7
Fig. 6.3 Center of Gravity Limits	6 - 8
Fig. 6.4 Weight Moment Limits	6 - 9
Fig. 6.5 Loading diagram	6 - 10
Fig. 6.6 Calculation of Weight Breakdown	6 - 11
6.9 Equipment List	6 - 12 to 6 - 23



### 6.1 General

In order to achieve the flight-performance, safety and good flight characteristics which are designed into the airplane, it must be flown with the weight and center of gravity position within the approved operating range.

The pilot in command must make sure of this before taking off, and also take into account that the center of gravity will shift with fuel consumption.

The approved center of gravity locations in flight are determined in section 2.

Airplane attitude: Bottom edge of canopy frame (fuselage)  
horizontal

Before the airplane will be delivered, it will be weighed, and basic empty weight and center of gravity location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment installed at the delivery).

The empty weight and the corresponding center of gravity location are entered in the Weighing Form (see Fig. 6.1).

Whenever new equipment is added or any modification work is done, the mechanic or inspector responsible for the work is required to compute a new basic empty weight and center of gravity position through calculating and weighing. Then he has to write down the results in the Weight and Balance record.

A weight and balance calculation is always required to determine how much fuel or baggage can be boarded, so as to keep within allowable limits.

The following pages serve as prescribed forms used in the weighing and the calculation of the basic empty weight process, center of gravity and useful load.

Note that the useful load includes usable fuel, crew, passenger and baggage.

### 6.3 Airplane Weighing Procedure

Computing the center of gravity location requires establishing the basic empty weight center of gravity location by weighing. For this purpose the airplane is placed on 3 scales (2 under the main wheels, 1 under the nose wheel) so that the bottom edge of the canopy frame is horizontal.

When rolling the main wheels onto the scales make sure that the shock-absorbing struts do not put side-load on the scales which would otherwise result in an erroneous reading.

The datum level is the wing leading edge for a span of 1.15m [3.8 ft] (outside of the skew wing-fuselage transition). The distances a and b are determined using a plumb line. The empty weight is determined from the sum of the single weights  $G_2$ ,  $G_{1ri}$  and  $G_{1le}$ .

Weight at nose wheel  $G_2 =$  kg [lbs]

Weight at RH main wheel  $G_{1ri} =$  kg [lbs]

Weight at LH main wheel  $G_{1le} =$  kg [lbs]

Empty weight  $G = G_{1ri} + G_{1le} + G_2$   
 $G =$  kg [lbs]

Distance nose wheel - datum level a = mm [in.]

Distance nose wheel - LH main wheel  $b_{le} =$  mm [in.]

Distance nose wheel - RH main wheel  $b_{ri} =$  mm [in.]

#### **Empty weight C. G. position**

$$x_s = \frac{G_{1le} \cdot b_{le} + G_{1ri} \cdot b_{ri}}{G} - a = \text{mm [in.] aft of datum}$$

Establishing the empty weight and the corresponding C. G. location is always done without baggage but with a full oil tank and with the unusable amount of fuel.

When computing the useful load it is important to ensure that the maximum permissible weight is not exceeded.

Following repairs, varnishing, installing additional equipment or at periodical times after the last weighing the new empty weight must be determined.

Empty weight, corresponding C. G. location and useful load must all be certified by the inspector in the Weight and Balance record.





Fig. 6.1 Weighing Form

BURKHART GROB
LUFT- UND RAUMFAHRT GmbH & Co. KG
LBA-No. I - B 21

WEIGHT AND BALANCE REPORT

Date: \_\_\_\_\_



A/C Type: \_\_\_\_\_ Reg.: \_\_\_\_\_ S/N : \_\_\_\_\_

Datum line/point (BE/BP): Wing leading edge at QE 2480 / BMET 1150
Level Means (BL): Edge of doorframe horizontal

Table with 4 columns: Airworthiness category, Gross weight [lbs], Flight weight from (inch), C.G. range up to (inch). Rows include Normal (N), Utility (U), and Acrobatic (A).

Weighing:

Weighing condition: with engine oil, brake fluid and unusable fuel.



Empty weight C.G. Determination:

Table for empty weight C.G. determination with columns: Weighing point, Gross (lbs), Tare (lbs), Net (lbs), Moment arm (inch). Includes rows for G1 LH, G1 RH, G2, and a summary row for Empty weight centre of gravity (EWCG).

Equation: G1 LH x b LH + G1 RH x b RH / Gempty - a = xs

\_\_\_\_\_ = \_\_\_\_\_ inch

Table for weight and balance summary with columns: Airworthiness category, Normal (lbs), and Empty weight momentum (in.lbs). Rows include Empty weight, Max. payload, Max. gross weight, and Empty weight momentum.

Equipment by weighing see equipment list of:

Date

(Stamp)

Inspector

GROB Form F6/EG.K1




6.5 Weight and Balance Record

The basic empty weight and the corresponding C.G. location are the first entries made in the Weight and Balance record. This form is provided to present the current status of the airplane basic empty weight, empty weight C.G. location, empty weight moment and a complete history of previous structural or equipment modifications.

Any change to the permanently installed equipment or modification or aircraft repair which affects empty weight, empty weight C. G. or empty weight moment must be entered in the Weight and Balance record.

For the calculation of the gross weight and corresponding C.G. location or the weight moment respectively always use the basic empty weight, current empty weight C.G. location and the corresponding empty weight moment.





### 6.7 Weight and Balance Determination for Flight

The following information is intended to assist you in operating your GROB G 115C within the prescribed weight and center of gravity envelope. To determine the weight and center of gravity location for the flight use the graphs Fig. 6.3 "Center of Gravity Limits", Fig. 6.4 "Massmoment Limits", Fig 6.5 "Loading Diagram" and Fig. 6.6 "Calculation of Weight Breakdown" as follows:

First obtain the basic weight and the corresponding C.G. location of your aircraft from the weighing form and the Weight and Balance Record and enter them in the corresponding columns headed "Your Airplane" of Fig. 6.6 "Calculation of Weight Breakdown".

And then, using the "Loading Diagram" (Fig. 6.5) determine the moment of all payload items and enter these moments into the corresponding column of Fig. 6.6.

#### Note

The baggage indication applies to baggage stowed in the center of the baggage compartment. Loading conditions deviating from these assumptions must be taken into account accordingly by changing the arm entries. The moments of loads which may deviate from their indicated location in the aircraft according to the loading diagram, must be additionally computed on the basis of their actual weight and arm.

Add the weights and moments of each column (item 4 and item 6 in Fig. 6.6) and enter the resulting sums in Fig. 6.4 "Massmoment Limits" to check whether they are within the envelope so that the loading condition is permissible.

Fig. 6.3 Center of Gravity Limits




Fig. 6.4 Massmoment Limits





Fig. 6.5 Loading Diagram



**Fig. 6.6 Calculation of Weight Breakdown**

CALCULATING USEFUL LOAD	SAMPLE AIRPLANE (EXAMPLE)		YOUR AIRPLANE	
	MASS kg (lbs)	MOMENT kg m (lbs in)	MASS kg (lbs)	MOMENT kg m (lbs in)
1. Basic empty weight (use the values for your airplane as currently equipped incl. nonusable fuel and full oil capacity)	697.80 (1538.4)	157.73 (13691)		
2. Pilot and passenger (Arm: 0.25 m / 9.84 in)	160.00 (352.74)	40.00 (3472)		
3. Baggage (Arm: 0.99 m / 38.98 in)	35.00 (77.16)	34.65 (3008)		
4. Total weight and total moment but fuel tank empty (total of 1. thru 3.)	892.80 (1968.3)	232.38 (20170)		
5. Usable fuel (0.72 kg/l = 6.0 lbs/US.gal.) Maximum 143 l = 37.8 US.gal. Example: 135 l = 35.7 US.gal. (Arm: 0.335 m / 13.19 in)	97.20 (214.29)	32.56 (2826)		
6. Total weight and total moment with full tank (total of 4. thru 5.)	990.00 (2182.59)	264.94 (22996)		
7. Find the computed values for the total weight 990 kg (2182.59 lbs) and the total moment 264.94 kg m (22996 lbs in) in C.G. envelope graph. Since they are within the envelope, the loading condition is permissible.				

The Center of Gravity envelope of the G 115 C is such, that the landing C.G. (even after consumption of all usable fuel) will be within the approved envelope if the take-off C.G. has been within the limits.



### 6.9 Equipment List

The following is a list of equipment available le at this time. All of the items installed in your airplane are identified in the corresponding column.

The present equipment list contains the following details:

- The item number consists of a letter identification for the associated group and a sequence number.

Letter identification is as follows:

A	Avionics
E	Electrical
F	Landing gear
I	Instrumentation
T	Engine
Z	Airframe

- The column "Code" identifies whether the equipment item is a mandatory, standard or optional equipment item according to the following abbreviations:

A	Mandatory equipment item
B	Standard equipment item
C	Optional equipment item
D	Additional optional equipment item
E	Loose item of equipment, not included in the airplane empty weight.

#### NOTE

When an optional equipment item is incorporated, this must be in agreement with the corresponding installation drawing, equipment instructions or in compliance with special approval of the Civil Aviation Authorities.

The columns "Weight" and "Arm" list the weight and and C.G. location relative to the datum of the equipment item, positive relating to distances aft of the datum, and vice versa.

Equipment List

Date of installation :			Stamp of Inspector:		
Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
A 1	B	ADF Antenna, KING KA 0044B		2.799	+4.724
A 2	B	ADF Antenna, BECKER ANT 2070		3.748	+4.724
A 3	B	ADF Indicator, KING KI227		0.683	-0.951
A 4	B	ADF Indicator, BECKER ID 2070		1.102	-0.951
A 5	B	ADF Receiver, BECKER ADF 2070		2.205	-0.951
A 6	B	ADF Receiver, BECKER ADF 2079		2.205	-0.951
A 7	B	ADF-Receiver, KING KR 87		3.197	-0.951
A 8	B	ATC Transponder, BECKER ATC 2000		2.646	-0.951
A 9	D	Audio Control Console KING KA 134		1.700	-0.951
A 10	D	Audio Control Console, KING KMA 24H		1.700	-0.951
A 11	D	Audio Control Marker Receiver KING KMA 24		1.697	-1.148
A 12	D	Audio Control Panel AEE ACP 2700		.....	-0.951
A 13	B	Avionic Blower, KING KA 33		1.257	-1.148
A 14	B	Blindencoder, ACK A-30		0.397	-0.951
A 15	A	COM-1 Antenna, Dittel SPERRTOPF		0.573	+15.42
A 16	D	COM-2 Antenna, Command Ind. CI 122		0.485	+2.854

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
A 17	B	COM/NAV 1 Receiver, KING KX 155-35		4.739	-0.951
A 18	D	COM/NAV 2 Receiver, KING KX 155-34		4.739	-0.951
A 19	A	COM, BECKER AR3201		1.984	-0.951
A 20	D	COM BECKER AR 4201		.....	.....
A 21	D	COM/NAV, KING KX 125		3.880	-0.951
A 22	D	DC/DC Converter AEE SR 6900		0.360	-0.951
A 23	D	DME Antenna, KING KA 60		0.022	-0.984
A 24	D	DME KING, KN 63		2.799	-0.951
A 25	D	DME, KING KN 62A		2.601	-0.951
A 26	D	DME Indicator, KING KDI 572		0.794	-0.951
A 27	D	ELT, POINTER 3000		1.900	-0.951
A 28	D	ELT, ACK E-01		3.300	-0.951
A 29	D	Flux Transmitter, KING KMT 112		0.331	-0.951
A 30	D	Glide slope, KING KN 75		1.600	-0.951
A 31	D	GPS Antenna MOTOROLA EK 568		0.265	-0.951
A 32	D	GPS Antenna, SENSOR SYSTEM S67-1575-39		0.313	.....
A 33	D	GPS GARMIN 100 AVD		1.700	-0.951
A 34	D	Gyro Mount, KING KG 102A		9.400	-0.951
A 35	D	HSI, KING KI 525A		9.500	-0.951
A 36	B	Marker Antenna, Command Ind. CI-102		0.595	-0.754

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
A 37	D	Marker Receiver, KING KR 21		0.600	.....
A 38	B	NAV Antenna, Command Indust. CI 157P		0.353	+4.101
A 39	D	RMI Indicator, KING KI229		2.866	-0.951
A 40	D	Slaving Unit, KING KA51B		0.198	-0.951
A 41	B	Transponder Antenna, KING KA 60		0,022	-4.724
A 42	B	Transponder, KING KT 76A		3.108	-0.951
A 43	D	Universal Converter, KING KN 72		1.323	-0.951
A 44	D	VHF Com.-Transceiver, KING KY 96A		2.800	-0.951
A 45	D	VOR/LOC Indicator, KING KI 203		1.609	-0.951
A 46	D	VOR/LOC Indicator, KING KI 208		1.000	.....
A 47	B	VOR/LOC/GS Indicator, KING KI 204		1.697	-0.951
A 48	D	Intercom-Unit SIGTRONICS SPA-400		.....	.....
A 49	D	NAV-Receiver BECKER NR 3301S		.....	.....
A 50	D	Power-Converter BECKER VR 2011		.....	.....
A 51	D	GPS TRIMBLE TNL 2000 A/C (only for VFR)		.....	.....
A 52	D	GPS/COM KING KLX 135 (only for export)		.....	.....
A 53	D	Blindencoder (only for export)  AMERI-KING AK 350		.....	.....

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
E 1	A	ACL Light, WHELEN A470A-D-W		0.300	+15.42
E 2	A	ACL Power Supply, WHELEN A490 T, DF-14/28		1.200	+15.42
E 3	A	Batterie, GILL G-243		27.99	+3.592
E 4	A	Engine run hour counter, KÜBLER HK 15.20.52		0.110	-0.951
E 5	C	External Power Connector, AIRCRAFT 4621B		0.816	+5.807
E 6	A	Flap Motor, MOTION 85262		4.189	+2.526
E 7	A	Flight hour counter, KÜBLER HK 15.20.52		0.110	-0.951
E 8	A	Fuel Pump, WELDON B8120-H		1.808	-3.035
E 9	A	Generator, BOSCH 28V 10/35A 0120 488 269		9.259	-5.233
E 10	A	Generator Control Lamp BOSCH 0 310 152 006		0.044	-0.754
E 11	D	Hi&Lo Volt Indicator, BOSCH 0 310 152 006		0.044	-0.754
E 12	A	Ignition Switch, TELEDYNE/ BENDIX 10-357200-1		0.353	-0.754
E 13	B	Landing Light 100W GENERAL ELECTRIC GE 4591		0.441	-5.315
E 14	A	Lift Detector, SAFE FLIGHT P/N 164		0.132	.....
E 15	A	Master Switch, HERTH&BUSS 70.579.481		0.066	-0.754
E 16	B	NAV Light left, WHELEN W1285-PR-28		0.200	+0.230



Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
E 17	B	NAV Light right, WHELEN W1285-PG-28		0.200	+0.230
E 18	A	NAV+STROBE Light left, WHELEN A650-PR-D-28		0.400	-0.754
E 19	A	NAV+STROBE Light right, WHELEN A650-PG-D-28		0.400	-0.754
E 20	A	Pitot Heat Tube, AERO INSTR. AN5812-1 (24 VDC)		0.838	+0.328
E 21	B	Position Light Tail, WHELEN A500A-H-D-28		0.307	+16.72
E 22	A	Stall Warning Light, BOSCH 0 310 152 006		0.044	-0.754
E 23	A	Stall Warning Horn, BÜRKLIN 36M434		0.044	-0.441
E 24	B	Taxi Light 150W General Electric GE 4626		0.441	.....

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
F 1	A	Brake Calliper, Cleveland 30-63a with Linings		1.378	+2.051
F 2	A	Brake Fluid Aeroshell Fluid 41			
F 3	A	Main Wheel Rim, CLEVELAND 6.00-6 40-97a incl. Brake Disc		6.063	+1.804
F 4	A	Main Wheel Tire, Goodyear 15x6.00-6 06 TT FSL II Tire		7.275	+1.804
F 5	A	Main Wheel Fairing		3.307	+1.804
F 6	A	Main Wheel Tube, Goodyear G15x6.00-6 reg Tube TR20		1.499	+1.804
F 7	A	Master Brake Cylinder Cleveland 10 - 30		1.389	-2.428
F 8	A	Nose Wheel Rim, Tost		3.042	-3.494
F 9	D	Nose Wheel Rim, 115C-5205		.....	-3.494
F 10	A	Nose Wheel Tire, Goodyear G380x150-5/6 PR		4.960	-3.494
F 11	D	Nose Wheel Tire, Goodyear 5.00-5/6PR 505C61-8		4.960	-3.494
F 12	A	Nose Wheel Tube, Goodyear 5.00 - 5 Tube TR 67		1.499	-3.494
F 13	A	Nose Wheel Fairing		2.646	-3.494
F 14	A	Parking Brake Valve, Cleveland 60 - 5		0.331	-2.723
F 15	A	Supply Bin, FAG 2334845		0.419	-3.117

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
I 1	D	Accelerometer, App.-GAUTING Typ 470L P/N 620747-1		0.660	-0.951
I 2	D	Accelerometer 3", BENDIX 10-101		.....	-0.951
I 3	A	Air Vakuum Pump, SIGMA-TEK 1U128-006		2.200	.....
I 4	A	Airspeed Indicator, SIGMA-TEK EA 5175-05L		0.992	-0.951
I 5	A	Altimeter 1 UNITED INSTR. 5934()-()		1.543	-0.951
I 6	D	Altimeter 1 UNITED INSTR. 5934()-()-L		1.543	-0.951
I 7					
I 8					
I 9	D	Ampere & Volts Indicator, IGVA 3101000		0.353	-0.754
I 10	D	CHT & Fuel pressure Indicat. ICFP 3106000		0.353	-0.754
I 11	A	Clock, BENZ-MICRO		.....	.....
I 12	D	Clock, SINN NABO 25/8		0.882	-0.951
I 13	A	Directional Gyro Air, SIGMA-TEK 1U262-001-52		2.400	.....
I 14	D	Directional Gyro Air, SIGMA-TEK 1U262-002-51		2.400	.....
I 15	D	Directional Gyro Air R.C.ALLEN RCA11A-13		2.888	-0.951
I 16	A	Directional gyro R.C.ALLEN RCA 11A-8		2.646	-0.951



Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
I 17	D	Electrical Horizon R.C.ALLEN RCA26BK-9		2.712	-0.951
I 18	D	Horizon Air Driven R.C.ALLEN RCA22-41		2.756	-0.951
I 19	A	Horizon Air Driven R.C.ALLEN RCA 22-40		2.756	-0.951
I 20	D	Horizon Air Driven KING KG 258		2.756	-0.951
I 21	D	Horizon Air, SIGMA-TEK 23-501-06-19		1.800	-0.951
I 22	D	Horizon Air, SIGMA-TEK 1U-149-010-3		1.800	-0.951
I 23	A	Kompass Lighted, AIRPATH C2300L4		0.882	-0.754
I 24	A	Manifold Pressure & Fuel flow Indicator, SIGMA-TEK 1U028-005-28		.....	-0.951
I 25	D	Manifold Pressure & Fuel flow Indicator, SIGMA-TEK 1U028-005-60		.....	-0.951
I 26	D	Manifold pressure & fuel flow gauge R.C.ALLEN 21-1000-3		1.000	-0.951
I 27	D	Manifold pressure & fuel flow Indicator UNITED INSTR. UI-6333 Code H54		1.200	-0.951
I 28	D	EGT & EGT Indicator, I EET 3107000		0.371	-0.754
I 29	D	OAT & Carburetor Temperature Indicator IOCT 3103000		0.362	-0.754
I 30	D	Oel pressure & Oel temperat. Indicator IOTP 3104000		0.362	-0.754

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
I 31	A	RPM Indicator, MOTOMETER 646.012.9994		0.772	-0.853
I 32	D	Suction Indicator SUP.INC. 4101-0001		0.110	-0.951
I 33	A	Suction Indicator VARGA ENTERPRISES, INC. 5001		0.110	-0.951
I 34	A	Suction filter AIRBORNE 1J7-1		0.419	-0.951
I 35	A	Suction regulator AIRBORNE 2H3-12		0.353	-0.951
I 36	D	Tank left/right Indicator, IFFQ 3102000		0.369	-0.754
I 37	B	Turn Coordinator, R.C. ALLEN RCA 82A.11		1.250	-0.951
I 38	D	Turn Coordinator, S-TEC 6407-XX		.....	-0.951
I 39	D	Turn & Slip Indicator, R.C. ALLEN RCA 56-3		1.300	-0.951
I 40	A	Vertical Speed Indicator UNITED INSTR. 7000		0.992	-0.951
I 41	D	Vertical Speed Indicator UNITED INSTR. 7000-L		0.992	-0.951

Equipment List

Item No.	C o d e	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
T 1	A	Air Filter, 115C-6600.14		0.198	-4.396
T 2	A	Engine Lycoming O-320 D1A		306.0	-4.560
T 3	A	Exhaust System, ROLA VI B5 115C-6401/-6402		13.23	-4.462
T 4	A	Fuel pump, WELDON B-8120-H		0.820	-3.035
T 5	A	Fuel Pressure Sensor, MOTOMETER 675.003.1002		0.220	-2.772
T 6	A	Fuel Quantity Sensor MOTOMETER 608.010.1003		0.331	+2.887
T 7	A	Fuel Shutoff Valve, 115-6249		0.168	+0.754
T 8	A	Oilcooler, 23.073.20.005		.....	.....
T 9	A	Oil Pressure Sensor MOTOMETER 675.004.1018		0.220	-5.381
T 10	A	Oil Temperature Sensor VDO TM 014-4		0.066	-3.445
T 11	D	Oil Temperature Sensor MOTOMETER 642.009.1014		0.066	-3.445
T 12	A	Propeller, Sensenich 74DM7-S14-2-64		30.49	-6.004
T 13	D	Starter, B+C, BC 315-100-4		.....	.....
T 14	A	V-Belt, Lycoming 76026		0.176	-5.495

Equipment List

Item No.	Code	Item, Manufacturer, Type	Mark if instl.	Weight (lbs)	Arm (ft)
Z 1	D	Alternate Static System 115-6207		0.265	-2.789
Z 2	E	Back Pad, Grob			
Z 3	B	Defroster Nozzles, VW 443 819 635 01C or -636 01C		0.088	-1.378
Z 4	A	Emergency Hammer, 274004 3C		0.485	-0.656
Z 5	D	Fire Extinguisher TOTAL EHAL		4.629	+2.297
Z 6	B	Handle, VW KA 15-959 659 251 857 607 01C			
Z 7	A	Harnesses, Schugu 2700 No. 40071/05		2.094	+2.231
Z 8	D	Heating Mixing Box, 115-6030		3.836	-3.379
Z 9	D	Legstrap, Bogu 1402 No. 40.072/4		0.243	+2.231
Z 10	B	Pitot Tube Cap		-	-
Z 11	A	Seatbelts, Bagu 5202 No. 40.070/32		3.086	+0.919
Z 12	E	Seat Pad, Grob			
Z 13	B	Side Fairing, complete		5.622	+1.411 -1.476
Z 14	B	Textile,			
Z 15	B	Vent Nozzles Wemac 2550		0.022	-0.787
Z 16	A*	Harnesses, Schugu FAG-7H/O AUTOFLUG AFG 0178943		2.094	+2.231
	D*	Legstrap, Bogu FAG-7D/O AUTOFLUG AFG 0525734		0.243	+2.231
	A*	Setbelts, Bagu AFG-7D/O AUTOFLUG AFG 0478931 * only if ÄM 1078-10 is installed		3.086	+0.919



## Table of Contents

## Section 7

## Airplane and System Description

	Page
7.1 General	7 - 2
7.3 Airframe	7 - 2
7.5 Flight Controls	7 - 3
7.7 Instrument Panel	7 - 4
7.11 Ground Control	7 - 6
7.13 Wing Flaps	7 - 6
7.15 Landing Gear	7 - 6
7.17 Baggage Compartment	7 - 7
7.19 Seats, Seat Belts, and Shoulder Harnesses	7 - 7
7.21 Canopy	7 - 8
7.23 Control Lock	7 - 8
7.25 Engine	7 - 9
7.27 Propeller	7 - 10
7.29 Fuel System	7 - 10
7.33 Brake System	7 - 12
7.37 Electrical System	7 - 13
7.39 Lighting Systems	7 - 17
7.43 Heating, Ventilating, Defrosting & Air Conditioning	7 - 18
7.51 Pitot Static System	7 - 18
7.53 Vacuum System	7 - 19
7.70 Emergency Locator Transmitter	7 - 20
7.71 Emergency Tool	7 - 21

### 7.1 General

This chapter contains the description of the airplane and its systems, operating instructions also being given for the latter. A few of the systems described here are special equipment and may not be included in your airplane. For details regarding additional special equipment systems or components please refer to section 9 of the airplane flight manual.

### 7.3 Airframe

The G 115C is an utility category airplane designed as a single-engine, two-seater low-wing aircraft with cantilever wings and a conventional empennage. The tricycle gear of the GROB G 115C is non-retractable. The G 115C is manufactured with newest knowledge to state-of-the-art requirements in industrial fiber reinforced plastic design, mainly involving glassfiber reinforced plastic.

The semi-monocoque fuselage comprises a self-supporting glass-fiber reinforced plastic shell with frame and web members. The one-part canopy has a two-part generous wrap-around glazing.

The cantilever wing of single-trapezoidal cross section has an I-beam main spar with spar caps of glass fiber roving. The wing shell is of honeycomb sandwich design, except the tank section, which consists of a PVC foam sandwich. Interconnection of the wings is made via the spar stubs, bolted together with splice metal sheets. Each wing is attached to the fuselage by two necked-down bolts. The wing trailing edge carries conventional ailerons and flaps.

The aileron shell has an aramide fiber glass plastic honeycomb sandwich structure, the web consists of glass fiber plastic honeycomb sandwich. The aileron are balanced by a horn which also holds the mass balancing lead. The structural configuration of the flaps is the same as that of the ailerons.

The conventional empennage comprises fin, rudder, tailplane, elevator and elevator trim tab. The fin integrated in the fuselage mainly comprises the main and end spar in honeycomb sandwich design and a fiber-reinforced full laminate shell. The structural configuration of the tailplane is similar to that of the wings. The tailplane is attached to the fuselage by three fittings. The structural configuration of elevator and rudder are similar to that of the ailerons. Elevator and rudder have horn balance.



The spin fin consists of a GRP-honeycomb-sandwich and is attached to the fuselage by means of screws. The installed grinding disk protects the spin fin from damage.

The complete airframe is protected from moisture and ultraviolet radiation by an UP gel-coat which is finished with a two-component-polyurethan-lacquer.

### 7.5 Flight Controls

The flight control system of the GROB G 115C comprises conventional ailerons, rudder and elevators. All flight control surfaces are mechanically actuated via push-pull rods, the ailerons and elevators being controlled by the control wheel (optional control stick) and the rudder via rudder toe brake pedals.


For each control wheel (optional control stick) a PTT-momentary-switch is installed.

The G 115C has manual elevator trim, the corresponding trim tab being controlled by means of a hand wheel on the center console. Turning the trim wheel forward produces nose-down trimming of the airplane, turning the trim wheel aft produces nose-up trimming.

In the G 115C the aileron control is connected to the rudder control via a spring device. The device is installed in the center console.

The correct functioning of the system may be checked on the ground by moving the rudder pedals; one should then note a small movement of the ailerons.

7.7 Instrument panel





Instrument panel layout for VFR equipment

- Airspeed indicator
- Altimeter
- Compass
- Alternator warning light
- Starter relay control lamp
- Engine instrumentation (fuel gauge, fuel pressure, oil temperature, oil pressure, voltage, amperemeter)
- Cabin vent
- Ignition switch
- Master switch
- Avionics master switch
- Toggle switch for alternate static
- Toggle switch line (for ACL-wing, beacon, position light, landing light, fuel pump switch)
- Parking brake
- Flap control
- Stall warning horn
- Stall warning lamp
- Flap position indicator
- Cabin heating
- Tachometer
- Flight hour meter
- Engine hour meter (standard only for Australia)
- Pitot heating control lamp
- Fuel pump control lamp
- Artificial horizon
- VOR indicator
- Suction gauge
- Clock
- Gyro
- Rate of climb indicator
- ADF indicator
- Turn coordinator
- Avionic support for:
  - Audio panel, COM I, COM II, NAV I, NAV II, ADF, Transponder, DME, GPS
- Dimmer for instrument lighting
- NAV II - indicator
- Dimmer for instrument panel lighting
- Toggle switch for instrument-/panel lighting
- Test button for pitot-static heating
- Toggle switch for pitot-static heating
- Exhaust gas temperature gauge (EGT)
- Cylinder head temperature gauge (CHT)
- Outside air temperature gauge (OAT)
- Push button primer system

### 7.11 Ground Control

The G 115C has a steerable, non-retractable nose gear. The nose wheel is connected to the rudder pedals thru a spring box. A conventional shimmy damper compensates any shimmying tendency. To assist steering the separate wheel brakes can be included. The maximum steering angle of the nose wheel is  $\pm 47^\circ$ . When towing the airplane by a towing vehicle make sure that this steering angle is not exceeded otherwise the nose gear could be damaged. The minimum turning circle is 6.50 m (21 ft) measured over the wing tips, for full steering angle, brake actuation and assistance by engine power.

### 7.13 Wing Flaps

Extension and retraction of the flaps is done by means of a flap control switch. The retracted, take off and landing positions ( $0^\circ$ ,  $15^\circ$  and  $60^\circ$ ) are clearly indicated by the indicator unit on the front center panel. All three positions can be pre-selected with the flap lever. Intermediate positions are possible during extension. Returning the flap control switch up results in full retraction of the flaps. Limit switches automatically interrupt the power to the electric motor, when the flaps attain the final position. Asymmetrical flap settings are eliminated by levers and pushrods interconnecting the flaps.

### 7.15 Landing Gear

The landing gear of the G 115C is a non-retractable tri-cycle landing gear with steerable nose wheel, two main wheels and fairings. Shock absorption is provided by the struts of the main gear and the gas strut of the nose gear.

Each main wheel has a hydraulically actuated single-disk brake on the inside. The hydraulic brakes are actuated by the toe brake pedals either by the pilot or the copilot.

The lever for actuating the parking brake is located at the LH side below the instrument panel on the pilot's side. To set the parking brake, move the parking brake lever to the "SET" position and pump both brake pedals until full resistance is felt. By positioning the parking brake lever to "RELEASE", the brakes are released.



The brake fluid reservoir is located on the RH fire wall side and is accessible by removing the upper cowling. The brake fluid level can be checked by means of the transparent reservoir. The brakes do not need adjusting. Brake lining wear is automatically compensated.

**NOTE**

Whenever the airplane is parked unsupervised, always chock the wheels and release the parking brake.

Temperature changes may cause a release of the brake or an excessive increase of the brake system pressure.

**7.17 Baggage Compartment**

The baggage area extends from the rear of the pilot and co-pilot seats to the aft cabin frame. Loading the baggage area must be in accordance with the values as stipulated in section 6 "Weight and Balance". All baggage must be safeguarded by the GROB approved baggage net included in each airplane. For this purpose the baggage net must be secured to the strapping eyebolts incorporated in the baggage area floor.

**WARNING**

Never accommodate children in the baggage area. Material which could be dangerous to the airplane or passengers must not be stowed in the airplane.  
Spin maneuvers are approved without baggage only !

**7.19 Seats and Safety Belts**

The G 115C is fitted out with comfortable seats, permitting even lengthy flights without tiring. Seats comprise the seatbacks, configured as a frame, four seat webs, the forward seat frame and the fully laminate seat buckets. All frames and webs are designed as glass-fiber reinforced plastic honeycomb sandwich structures and are firmly connected to the fuselage. Thus no seat adjustment feature is possible. Instead the pedals of the G 115C can be continuously adjusted by means of two hand wheels located on the floor. The adjustment controls of both pedal units operate independently of each other. Seats can be adapted to users by seat and seatback cushions available in different thickness. Both seats are fitted out with 4-point safety belts. A 5-point safety belt is optional equipment. For attaching the harnesses insert belt and harness fittings in the buckle. Turning the buckle all belts are released.



### 7.21 Canopy

The G 115C has a rear-opening sliding canopy with generous glazing permitting an excellent view all round. The canopy lock is provided by an overhead latch located in the center of the canopy. Due to the deadpoint safety of the canopy lock, automatic or accidental opening is not possible. The handles incorporated on the top of the canopy facilitate entry into / out of and opening the canopy.

#### **NOTE**

Before every takeoff, make sure the sliding canopy is correctly locked ! The canopy must not be opened in flight.

In the G 115C the canopy serves as an emergency exit. The canopy can be smashed in an emergency using a hammer. This is part of the standard equipment and is installed on the pilot's side of the center console.

### 7.23 Control Surface Lock

To protect the ailerons and the elevator from damage due to wind buffeting when the aircraft is parked, a hand-wheel locking feature is provided. This feature comprises a steel locking pin with a red warning sign reading "REMOVE LOCKING PIN BEFORE STARTING ENGINE". To attach the control lock, line up the hole in the top of the pilot's control wheel column guide (optional control stick) on the instrument panel so that the locking pin can be inserted. When the handwheel locking is correctly inserted the warning sign covers the ignition switch.

When the aircraft is parked in areas subject to heavy winds or gusting, a rudder locking device must be applied over the fin and the rudder.

#### **CAUTION**

Always remove control lock devices prior to starting the engine !

Only if control stick is optional installed:

#### **NOTE**

The guide groove of the control surface lock must be attached in the two mechanical sleeves of the lower support of the instrument panel.

### 7.25 Engine

The GROB G 115C is powered by a Lycoming O-320 D1A four-cylinder, direct drive, horizontally opposed engine rated at 160 horsepower at 2700 rpm (sea level).

Engine controls are grouped together on the center panel. The knobs are configured according to the design specifications so that they can be identified by gripping. The central arrangement of the engine control lever facilities its use by both the pilot and co-pilot. An adjustable friction brake on the lefthand side of the levers prevents them from moving.

The throttle control is used to set the manifold pressure which is a measure of engine output power at constant speed.

The mixture control lever permits adjustment of the air to fuel ratio. In the fully forward position a rich mixture is set. The engine is shut down by placing the mixture lever fully aft (LEAN CUT OFF).

The " Mixture-Lean-Stop - device " (optional according to SB 1078-45) will prevent an unintentional engine shut down. The mixture setting near the "stop" is below "best power mix". In this position the engine can be operated for short periods. In order to shut down the engine or to operate in the near of "Peak-EGT", the stop pin of the mixture lever is to be deactivated. The mixture-lean-stop - device is recommended for take-off, landing, climb, traffic pattern and the mixture lever is set according to the instructions in chapter 4.

The majority of the engine instruments is located to the right of the avionics instruments in the RH portion of the instrument panel.

The alternator warning light is located to the left of these instruments, the tachometer below.

Running-in of the engine was done at the manufacturing company. It is mandatory that you observe the instructions given in section 1 on page 1 - 5.



The oil necessary for lubricating the engine is furnished by the oil sump located underneath the engine. The oil sump capacity is 7.6 liters (8 quarts). The lube oil level can be checked by means of an access hole in the upper engine cowling. A dipstick as part of the filler cap indicates the lube oil level.

The ignition switch is located on the left hand side, bottom section of the instrument panel and has the following switch positions:

"OFF", "L" (magneto LH), "R" (magneto RH), "BOTH" (both magnetos) and "START".

When the starter has been operated, the spring-loaded switch returns to the "BOTH" position.

### 7.27 Propeller

The GROB G 115C has a Sensenich two-bladed propeller 74 DM7S-14-2-64.

### 7.29 Fuel System

The G 115C fuel supply consists of two wing tanks with a total capacity of 150 ltrs. (39.63 U.S.gal / 33.00 Imp.gal), 143 ltrs. (37.77 U.S.gal / 31.46 Imp.gal) are usable. The operating levers for the fuel cock and the tank selector valve are installed in the center console directly behind the trim control wheel. Refuelling is carried out through a filler neck integrated into the GRP structure on the top of the wing.


#### **WARNING**

**Before refuelling, electrically ground the aircraft using a ground connection (engine exhaust). There must be absolutely no potential difference !**












Observe the following when refuelling from canisters or similar containers:

- use a metal funnel (connect the ground)
- cancel out any electrical potential difference between the person refuelling and the aircraft potential (eg. touch the canopy frame with one hand for at least one sec.)

Fuel schematic system



- 1 ENGINE
- 2 INJECTOR ASSY
- 5 FILLER CAP
- 6 LH WING TANK
- 8 RH WING TANK

-  FUEL FILTER
-  DRAIN VALVE
-  FUEL QTY. X-MITTER
-  OVERBOARD VENT
-  FUEL SELECTOR VALVE
-  FUEL PUMP (MECH.)
-  BOOST PUMP (ELECT.)
-  SHUT OFF VALVE
-  C - VALVE (VERTICAL)
-  C - VALVE (HORIZONTAL)
-  FUEL STRAINER

Fuel flow to the engine passes from the wing tank via the fuel shutoff valve, via the auxiliary electric fuel pump to the engine-driven fuel pump. In each pump a fuel strainer is integrated.

The auxiliary electric fuel pump is actuated by a toggle switch located beside the ignition switch. This pump must always be ON during take off and landing.

The fuel level in the tank is monitored by a fuel quantity sensor which signals the fuel gauge on the instrument panel.

**NOTE**

Do not expect the fuel gauge to give a precise reading when the aircraft is in an unusual attitude (e.g. yawing, side-slipping or spinning) or in climb or descent attitude. The fuel gauge was calibrated with the aircraft on flat ground. Use the fuel quantity gauge only in level flight !

The fuel tank of the G 115C is vented via the filler neck. The vent opening is located on lower side of the wing at the aileron section and is configured so that the tank is always subject to slightly more than atmospheric pressure.

The fuel system features a drain valve at the bottom of the fuselage directly beneath the tank. Pushing the valve up is sufficient to drain water or sediment from the tank.

**NOTE**

In making a fuel check a slight dis-colouration of the fuel may be observed - this is quite normal in new aircraft and will clear after a short period.

### 7.33 Brake System

The two main gear wheels of the airplane are fitted out with single-disk brakes. Separate hydraulic lines connect the master brake cylinders on the pilot's side via the parking brake valve. These cylinders are connected to the brake cylinders on the co-pilot's side by two further hydraulic lines. From these brake cylinders two hydraulic lines run to the brake fluid reservoir on the fire wall. The brake cylinders are directly connected to the rudder pedals.

The following are indications of an imminent brake failure: gradual brake fading when the brakes are operated, noisy or rubbing brakes, soft or springy pedal action and excessive pedal travel and tired brake response. Should any of these signs occur, carry out brake system maintenance without delay. Should the brakes fade during taxiing or landing, briefly release the rudder pedals and then apply full foot pressure.



### 7.37 Electrical System

The electrical energy required for the 28 V DC system is generated by an engine-powered alternator. Max. current output is 35 A as of 1800 RPM.

The battery box with the 24 V lead-acid accumulator is located on the RH side of the rear main frame. The battery provides the current for starting and for all electrical consumers when the engine is OFF. Battery capacity is 10 Ah which is sufficient under normal flight conditions to provide emergency power (alternator failure and/or main bus failure) for a maximum of 45 min.

#### **CAUTION**

When the engine is OFF consumers must be switched off without delay to avoid discharging the battery. When the alternator is down all consumers which are not essential to safe continuation of flight should be switched off.

The power supply of all electric circuits is provided via busbars which are located in a circuit breaker panel in the instrument panel.

#### Master Switch

The master switch is a toggle switch located on the left-hand side of the instrument panel at the bottom, and the corresponding master switching relay located above the battery box. Switch positions are clearly identified. In addition the green lamp incorporated in the master switch will light up in the "ON" position. In the "OFF" position all consumers are isolated from aircraft power. The avionics master switch is located directly alongside the master switch, on the right. The positions "ON" and "OFF" are identified on the instrument panel.

#### **WARNING**


To avoid damage to the electronic equipment always switch off the avionics master switch during starting.

#### Starter

The starter is relay-controlled and is actuated by the ignition switch. To switch on the starter circuit, position the ignition switch to "START".

Only if a starter relay control lamp is equipped: After starting the STARTER RELAY CONTROL LAMP must go out, if it doesn't the MASTER SWITCH must be switched off and a check must be made of the STARTER RELAY and associated components.


Electric System Schematic for VFR-operation



AVIONIC MASTER SWITCH "ON" MEANS AVIONIC MASTER RELAY IS DE-ENERGIZED  
 AND AVIONIC BUS IS CONNECTED TO MAIN BUS  
 AVIONIC MASTER SWITCH "OFF" MEANS AVIONIC MASTER RELAY IS ENERGIZED  
 AND AVIONIC BUS IS DISCONNECTED FROM MAIN BUS

OPTION

Electric System Schematic for IFR-operation



Voltmeter, Ammeter and Alternator Warning Light

The voltmeter is integrated in the engine instruments. It indicates the charging level of the battery and proper functioning of the alternator. The charging current is indicated by the ammeter, which is also integrated in the engine instruments.

In the range 24.5 V - 28 V the alternator generates voltage. When the voltage drops below 24.5 V and the red alternator warning light is on, the generator is down. In this case, the ammeter show a negative current flow. If this happened, switch off all consumers not essential to safe continuation of flight.

**WARNING**

When the red alternator warning light is on, this means the alternator is not working.

Circuit breakers

All circuits are protected by circuit breakers, located in the circuit breaker panel.

The circuit breakers, located in LH lower instrument panel, are of a push/pull-design. To interrupt pull and to reset push the circuit breaker.

The circuit breakers, located in the RH instrument panel, should be reseted only. When interrupted a red-white ring at the circuit breaker is visible.

**NOTE**

Circuit breaker "ENGINE INSTR. I" is reserved for:

- Volt / Ampere      - Fuel quantity LH/RH tanks
- Oilpressure        - Oiltemperature

Circuit breaker "ENGINE INSTR. II" is reserved for:

- OAT      - EGT      - CHT      - Fuelpressure


Description of the Essential/Avionic Bus switch-over-from-system

In the case of a Main Bus failure (e.g. short circuit), the Essential Bus and the Avionic Bus I will be directly connected to the battery, without pilot's action.


In this case all important electrical systems and avionic equipments remain active.

The result of this switch-over-from-system is that the Main Bus and the Avionic Bus II are deactivated.

**Circuit Breaker Panels for VFR - operation**



**Circuit Breaker Panels for IFR - operation**



### External Power Supply (optional)

The connection for connecting an external power is located on the RH side of the fuselage near the wing root trailing edge section and is equipped for 24 V. The external power connection is suitable for carrying out ground tests or to assist starting.

When connecting the external power supply first connect the cable clamps of the jump cable to the external power supply, making sure of correct polarity. Then position the avionics master switch OFF. The jump cable plug can then be inserted into the connector receptacle and the external power supply switched on. For engine starting procedure see section 4.

## 7.39 Lighting Systems

### Interior Lighting

The toggle switch for activating the instrument lighting is located on the RH side of the switch panel.

The lighting consists of integrated lamps as well as lamps on the instrument panel cover bottom, which beam in "white light".

A lamp installed in each control wheel directs light to the fuel cock, and is actuated by a toggle switch situated in the center of each control wheel. These lamps also "double" as map-lights. These lamps are not standard, if a control stig is installed. Instead of this, a "swan neck lamp" is standard. This lamp is optional, if a control wheel is installed.

Two dimmers situated in the switch panel control the level of light given to the lamps in the instruments and the lamps on the instrument panel cover bottom. The integrated lamps in the control wheels are not adjustable.

To allow a safe operation of the aircraft also during failure of any lights, it is recommended to have a light source (i.e. flash light) on board which is independent of the airplane power supply.

### Exterior Lighting

The toggle switches for activating the exterior lights are located in the center of the lower instrument panel. Each circuit is protected by a circuit breaker.

The exterior lighting comprises:

- Navigation lights in each wing tip and at the rudder.
- Beacon on the top of the rudder (optional).
- Strobe light in each wing tip and at the rudder.
- Landing light (optional).
- Taxi light (optional).

### 7.43 Heating, Ventilating, Defrosting & Air Conditioning

When flying on cold days or at high altitudes the GROB G 115C can be operated with cabin heating. The exhaust heat exchanger supplies the warm air to the front area of the cabin thru three outlets. Two of the outlets provide a flow of warm air directly to the feet area of both seats, the third outlet furnishes warm air for the windshield defroster. During flight air is scooped via an opening on the cooling air inlet to the exhaust heat exchanger where it is warmed up for passing on to the warm air distribution box. As the mixing box is also supplied with cold air, it is possible to regulate the temperature of the air leaving this mixing box. From here the warm air is supplied to the outlets in the cabin and for windshield defrosting.

When heated air is to be supplied to the cabin outlet openings, push the heating slider control to the latch identified by an arrow. If windshield defrosting is required, push the heating control full right to latch (identified by an arrow pointing upwards). Intermediate positions are also possible.

From the air inlets (NACA inlets) at the base of the windshield on both sides of the fuselage, fresh air flows to the adjustable air nozzles. These nozzles are located on the left and right in the instrument panel frame and supply the cabin with fresh air.

To ventilate the baggage compartment two loudspeaker covers are installed in the rear cockpit frame.

### 7.51 Pitot Static System

The pitot static system supplies static and total pressure to operate the airspeed indicator, the altimeter and the optional vertical speed indicator.

The total pressure is sensed by a heatable pitot tube located at the left wing lower side. The heating equipment should only be operated in probable icing conditions. A functional check during preflight check is performed as follows:

- a) Push the annunciator panel TEST button which is also used for instrument lighting test for approx. 10 sec.. Pitot heat switch position has no effect on the test.
- b) Check current decrease on ammeter  $\approx$  5-10 ampere.
- c) Hand-check heated pitot tube immediately after the functional test.

The heating is being activated in flight via a switch which depends on the pitot pressure (built as a protection from overheating). The switch for activating the pitot heating is located on LH side of the lower instrument switches panel in the middle.

The static pressure is sensed at the LH and RH side of the fuselage via drilled plates. Included in delivery is a protective cap for the pitot tube. Make sure that this is in place to protect the pitot tube whenever the G 115C is moored outdoors or in a hangar for a longer period of time.

To drain the system there is no additional work necessary. The pitot tube is provided with a water baffle plate with drain holes, the plates for the static pressure are protected against rain by means of their configuration.

During each preflight check the pitot tube and the plates should be checked for cleanliness or blockage respectively.

#### NOTE

Partially or totally blocked pitot-static hoses will result in incorrect instrument readings.

#### Alternate Static System (optional)

If this system is equipped:

The use of this system is recommended if the normal static system is out of action. The pick-up is by means of combined and adjustable over and underpressure tubes in the engine compartment (attached to the fire wall).

The airspeed deviation of this system is less than  $\pm 5$  kts of the calibrated airspeed (refer to section 5 Fig. 5.3.2)

The alternate static system is operated by a toggle switch which is installed in the LH side of the instrument panel.

#### 7.53 Vacuum System

The vacuum system (optional) is designed to operate the air-driven gyro instruments. An engine-mounted suction pump generates the necessary vacuum pressure via a controller. This pressure can be monitored on the suction gauge located on the LH edge of the instrument panel. Instruments are protected from soilage by filters. Should the vacuum pressure slightly drop after being constant for a long period, dirty filters can be the cause. These filters are located on the equipment panel beneath the instrument panel.



7.70 Emergency Locator Transmitter Type ACK E-01

The Emergency Locator Transmitter (ELT), when installed, is mounted at the rear baggage bulkhead on the LH side in the direction indicated on the top of ELT (DIRECTION OF FLIGHT).

The ELT is a autonomous unit and operates on his own battery. It transmits signals on two emergency frequencies (121.5 MHz and 243.0 MHz) simultaneously with a transmitting range of 200 miles (320 km) line of sight via his antenna.

The ELT is operated by a 3 position selector switch:

- **OFF:** In the OFF position the transmitter is inactive. The ELT should be switched off during shipment, storage, changing the battery and after the rescue.
- **ARMED:** The ARM position allows the unit to be set to the automatic mode so that it will transmit after activation by impact.
- **ON:** This position is provided for the manual activation of the transmitter.

**WARNING**

To rearm the ELT after an activation the selector switch should be placed in the OFF position and then in the ARMED position.

The ELT should be checked during the preflight ground check to make sure that it has been not accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating sound, the locator may have been activated and should be turned off immediately (OFF).

**CAUTION** (if installed)

The " **REMOTE - TEST** " must be done every three months according to the Operation Manual E-01 ELT / Section 8. Position " **ARMED** ": Green lamp means normal operation / red lamp means transmission operation (emergency service !).


The battery replacement date is marked on the ELT label. The battery must be replaced on or before this date. The battery must also be replaced if the transmitter has been used in an emergency situation or if the accumulated test time exceeds one hour, or if the unit has been inadvertently activated for an undetermined time.

**NOTE**

The ELT has to be removed from the airplane if it is parked for long periods of time in a hot environment ( more than 40°C (104°F)) to avoid dimishing the battery shelf life.

NOTE


If for any reason a test transmission is necessary, the test transmission should be conducted only in the first five minutes of any hour and limited to three audio sweeps. If tests must be made at any other time the tests should be coordinated with the nearest FAA tower or flight service station.

Emergency Locator Transmitter (ELT)7.71 Emergency Tool

An emergency hammer with harness cutter is installed on the left side of the middle console which is near at hand for the pilot and which can be pulled out of the holding device, if required.

If it is not possible to open the sliding canopy in an emergency, the glass has to be smashed with the carbide tip of the emergency hammer.

A harness cutter is on the lower end of the emergency tool with which the harness can be cut through, in case harness buckle cannot be opened.






Table of Contents

Section 8

**Handling, Servicing and Maintenance**

	Page
8.1 Introduction	8 - 2
8.2 Ground Handling	8 - 3
Towing	8 - 3
Parking	8 - 4
Taxiing	8 - 4
Mooring	8 - 4
Jacking	8 - 4
8.3 Servicing	8 - 5
Engine Air Filter	8 - 5
Brakes	8 - 5
Tires	8 - 5
Oil	8 - 5
Fuel	8 - 5
Exterior Cleaning	8 - 6
Canopy	8 - 6
Engine	8 - 7
Painted Exterior Surface	8 - 7

### 8.1 Introduction

This section contains factory recommended procedures for proper ground handling, routine care and servicing of your GROB G115C.

It is recommended that all aircraft undergo a regular inspection each 50, 100 or 200 hours of operation. The scope of the respective inspection interval is given in chapter 05-20 of the G115C Maintenance Manual. In addition, a first inspection is necessary after 25 operating hours. Annual inspections must be performed according to the national requirements. All inspections must be performed by a designated representative of the FAA or the Aviation Authority of the country in which the aircraft is licensed.

The FAA or the Aviation Authority of the country in which the aircraft is licensed may require other inspections by the issuance of airworthiness directives applicable to the airplane, engine, propeller and other components. It is the responsibility of the owner/operator to ensure compliance with all applicable airworthiness directives and, when the inspections are repetitive, to take appropriate steps to prevent inadvertent noncompliance.

Scheduling of **ALL** maintenance is the responsibility of the aircraft operator. A general knowledge of the aircraft is necessary to perform day-to-day service procedures and to determine when unusual service or shop maintenance is needed.

Service information in this section of the manual is limited to service procedures which the operator will normally perform or supervise. For U.S. registered aircraft reference should be made to FAR Part 43 for information regarding preventive maintenance which may be performed by a U.S. licensed pilot.

It is wise to follow a planned schedule of lubrication and preventive maintenance based on climatic and flying conditions encountered in your locality.

Should an extraordinary or difficult problem arise concerning the repair or upkeep of your G115C, consult the GROB representative in your country or Burkhart Grob Luft- und Raumfahrt, Am Flugplatz, 86874 Tussenhausen-Mattsies, Germany.

All correspondence regarding your airplane should include the model and the serial number. These numbers can be found on the identification plate of the airplane.

## Publications

The following publications are available:

1. Flight Manual GROB G115C
2. Maintenance Manual GROB G115C
3. Service Bulletin
4. Service Information

### Note

Service and maintenance information of the GROB G115C is based on the civil aviation authority requirements of the Federal Republic of Germany. Therefore, airplanes which are registered in other countries must comply according to the authority requirements of that country.

## 8.2 Ground Handling

The scale down dimensions of the GROB G 115C can be seen from the three view (page 1 - 3).

### **Caution**

To ensure safe ground clearance of the propeller, care must be taken to the recommended maintenance procedure for the landing gear and correct tire pressures.

### Towing

When towing the aircraft with a towing vehicle exercise maximum care since turning the nose gear beyond its steering radius of  $\pm 47^\circ$  ( refer to chapter 7.11) will result in damage to the nose gear and steering mechanism.

The airplane can be moved on a flat, smooth surface by a single individual using the towbar which must be attached to the towing lugs on the nose gear.

**Never pull at the spinner.**

Where maneuvering space is limited, two persons can turn the airplane by the wheels of the main gear, this requiring one person to push the wing nose or to keep hold of the wing tip whilst the other person operates the towbar.

### **Caution**

Never use force on the propeller or on the control surfaces. Never apply weights to the tailplane for the purpose of lifting the nosewheel. Also note that towing is not good practice when landing gear movements are obstructed by snow and sludge.

### Parking

The parking brake lever is located on the RH side, below the LH control wheel (optional control stick). To set the parking brake, position the parking brake lever to the "ON" position and pump the toe brake pedals until solid resistance is felt. Positioning the parking brake lever to "OFF" releases the brakes.

### Note

If the airplane is parked unsupervised, instead of setting the park brake, chock the wheels, since a change in the weather could result in the brakes being released or being subjected to excessive high pressure.

### Taxiing

When taxiing the G 115C can easily be steered by means of the steerable nosewheel. To achieve a tight turn, the toe brake pedals can be used to brake the corresponding wheel of the landing gear.

To prevent propeller ground contact, take caution when taxiing over uneven ground.

Apart from this, loose stones, gravel or any loose material may cause damage to the propeller blades at high speeds.

### Mooring

To moor the airplane head it into the wind. Four tie-down rings are provided on the airplane: one each under the wings, one at the nosewheel fitting and one on the fuselage (in front of the tail skid). To moor the airplane proceed as follows:

1. Apply the control lock
2. Chock wheels fore and aft
3. Secure plastic or chain tie-down ropes of adequate strength to the aircraft at the tie-down rings on the nosewheel fitting and the wing adapters. In addition the tail skid may be used as a tie-down point.
4. Release parking brake

### Jacking

For wheel or tire change the G 115C must be jacked up at the prescribed locations. For a detailed description see G 115C maintenance manual.

### 8.3 Servicing

#### Engine Air Filter

An air filter is incorporated downstream of the air intake scoop in the bottom cowling half for easy replacement.

This filter should be changed every 200 hours. When the airplane is operated in dusty locations, check and replace the air filter more often.

#### Brakes

Both landing gear wheels of the GROB G 115C are equipped with Cleveland disk brakes. The brake system is filled with brake fluid as per MIL-H 5606. Check brake fluid level every 50 operating hours. The brakes do not require adjustment. Changing the disk brake linings is described in the maintenance manual.

#### Tires

Tire size for the main gear is 15x6.00-6 and for the nose gear 5.00-5/PR. The tire pressure for the main wheels is 3.0 bar (43.5 PSI) and for the nose wheel 2.5 bar (36 PSI).

#### Oil

The oil capacity of the Lycoming engine is 7.6 liters / 8 quarts, and the minimum quantity required is 5.7 liters / 6 quarts. Before long flights the oil should always be replenished up to the top level. Change oil every 50 hours of operation. Every 50 hours of operation the oil filter should be changed.

Engine oils must comply with AVCO LYCOMING specification No. 301 and AVCO LYCOMING Service Instruction No. 1014, latest issue (see also section 1, page 1 - 5).

#### Fuel

The G 115C fuel is stored in two wing tanks with a total capacity of 150 ltrs. (39.63 U.S.gal / 33.00 imp.gal), 143 ltrs. (37.77 U.S.gal / 31.46 Imp.gal) are usable. Draining the tank should be done before each first flight of the day and after fuelling, paying particular attention to dirt in the fuel. Drain until fuel emerges clean. Should dirty fuel still emerge from the drain valve after one minute, have the fuel system inspected.

**Caution**

After draining make sure that there is no danger of fire from fuel spillage when starting the engine.

Aviation grade fuel: Avgas 100 or 100 LL

**Exterior Cleaning**

As with any composite airplane having mainly laminar flow conditions, keeping these surfaces clean is of major importance to aircraft performance. For this reason all exterior surfaces of the aircraft, in particular the wing leading edges must always be clean.

Cleaning is best accomplished with an ample supply of water, admixed with a light solvent, if required. In order to remove especially heavy dirt from the wing leading edges due to insect splatter and the like, it is good practice to undertake cleaning immediately after the flight, since deposits of this kind are more difficult to remove when dry.

Roughly once a year the surface should be treated with a paint cleaner or a non-silicone car polish and repolished to high gloss.

**Caution**

Never use cleaning agents containing silicone!

**Canopy**

To clean the canopy plexiglass proceed in the same way as for exterior cleaning of the G 115C, but pay particular attention to using ample water applied with clean sponges and leathers, otherwise even the smallest dust particles will tend to scratch the glazing.

**Caution**

Never polish plexiglass dry!

Dull or scratched canopy sections can be returned to their transparent state by treating with specially formulated plexiglass cleaning agents.

**Caution**

Always keep canopy clean and remember that a dirty canopy impairs the view and thus flight safety.



Engine

Use a cold solvent to clean the engine and make sure that no solvent can enter the magnetos, alternator, starter, suction pump and air intakes.

**Caution**

Do not operate the engine until excess solvent has evaporated or otherwise been removed.

Painted Exterior Surfaces

Changing the paint coat is only permissible after prior approval by the manufacturer!




Table of Contents

Section 9

Supplements

	Page
9.1 General	9 - 2
9.2 Table of Contents	9 - 2

9.1 General

Section 9 of this manual contains information regarding optional equipment for the G 115C. Each supplement relates to a separate equipment item.

All approved supplements are listed in the list of contents of this section.

This manual contains only the supplements relating to the equipment actually installed.

Make sure that all supplements relating to installed equipment are included in this airplane flight manual.

9.2 Table of Contents

Supplement No.	Title	Pages	Issue	Revision	LBA approved
1	NAV/COM - System	21	1	Rev.2 / 10.10.94	
2	Acrobatic-Operat. acc. SB 1078-55	12	1	Rev.5 / 08.09.95	

**SUPPLEMENT 1****NAV / COM - System****Section 1  
GENERAL**

The GROB G 115C avionic instrumentation for VFR- and IFR-Flight conditions comprises the following instruments:

1. Audio Control Panel ACP 2700
2. COM / NAV - System KING KX 155
3. NAV - Indicator KING KI 208 (optional 203/204/209)
4. Transponder Equipment KING KT 76 with Encoder ACK 30
5. Marker Beacon Receiver KING KR 21
6. Audio Control Console KING KA 134
7. Audio Control System KING KMA 24
8. DME System KING KN 62A
9. DME System KING KN 63 with KDI 572
10. Digital ADF System KING KR 87 with KI 227
11. VHF Communications Transceiver KING KY 96A
12. Compass System with HSI KING KCS 55A  
incl. KI 525A / KI 229 / KA 51B

The operation instructions of the particulars are listed and described in Section 4.

**Section 2  
LIMITATIONS**

The installation of this instrumentation does not influence the operational limits of the aircraft.

**Section 3  
EMERGENCY PROCEDURES**

The emergency mode of action does not change with installation of this instrumentation.  
To transmit an emergency signal via the transponder, the appropriate code as shown below has to be selected:

7600 Comfailure  
7700 Emergency  
7500 Hijacking

## Section 4 NORMAL PROCEDURES


### 1. Audio Control Panel

#### GENERAL

The audio control panel has been designed as communications system controller for pilot and co-pilot radio communications and intercom operation in small aircraft. It may be operated in aircraft with a 12 VDC or 28 VDC electrical power system.

The audio control panel is equipped with:

- two power supplies
- two mic inputs
- two PTT inputs
- a priority logic
- two headset outputs
- one intercom circuit
- seven RX audio inputs
- one audio warning input
- two controlled modulation outputs for all com radios
- two time-controlled key outputs
- one RX mute circuit for all RX audio inputs
- one cockpit speaker output



The audio control panel front panel is provided with four toggle switches for audio selections and one toggle switch for intercom operation or cockpit speaker. By means of the automatic impedance adaption all commercial aviation standard headsets and hand mic systems, e.g. Avial, Black Hawk, David Clark, Sennheiser, Sony etc., may be connected. The audio control panel also contains two controlled output amplifiers (modulation adaption) for all commercial com radios. Two time-controlled key outputs for pilot and co-pilot independent transmitter keying are also integrated in the audio control panel.

#### POWER SUPPLY :

The audio control panel contains two independent power supplies, which may be supplied from separate DC busses via two circuit breakers. The power supplies are uncoupled by diodes and supply in common the audio control panel electronics. Each power supply is designed to be able to take over the supply on its own. It operates without limitations within a wide range of voltages from 10 to 32 VDC.

#### MIC INPUTS :

The two mic inputs are a separate pilot mic input and co-pilot mic input. Each mic input has its own mic amplifier with automatic impedance and signal levelling.

Every mic connected is provided with its own power supply. The mic inputs allow for the use of the most different commercial headset systems at the same time. Every time when operating one of the PTT switches the selected com radio is triggered interrupting the intercom operation. Everything spoken into the mics is audible in both headsets. The two mic inputs are also provided with audio filters. These filters, supporting only that frequency range in use for communications, considerably reduce disturbing squelch picked up by the mics in the cockpit. These filters contribute to an essential improvement of speech quality of cockpit intercommunication and radio communications.

#### **PTT INPUTS :**

The two PTT inputs are uncoupled from each other by diodes and combined via the priority logic, which also triggers the two time-controlled key outputs. The pilot and co-pilot inputs share equal priority.

#### **PRIORITY LOGIC :**

The priority logic controls all switch-over functions within the audio control panel. In case of a PTT signal it activates the proper mic input amplifier and output amplifier. During intercom operation it immediately inhibits at the same time the other mic input amplifier. The cockpit speaker amplifier in TX operation is also reduced in volume to prevent a feedback particular to hand mic operation.

#### **AUDIO INPUTS :**

The seven RX audio inputs are used for direct connection to existing COM and NAV equipment. There is also an audio input for aural warning signals available. The audio inputs each have a 600  $\Omega$  DC input impedance blocked against HF with a filter. The audio inputs are uncoupled from each other.

#### **HEADSET OUTPUTS :**

Each pilot has his own headset amplifier used for adaptation to the various headphone impedances. The input signals, after decoupling, are adapted by the pilot and co-pilot headset amplifier, amplified, and delivered to the headsets. The headset outputs are permanently protected against short circuit and to do not influence any other output in the event of a short circuit. Amplification and thus volume may be adjusted individually for pilot and co-pilot on the front panel by means of two volume controls.

**MODULATION OUTPUTS :**

The audio control panel has two controlled output amplifiers. These are used for audio processing of the transmit signals for all com radios. These output amplifiers provide for an optimum modulation of the com radios during TX operation.

**KEY OUTPUTS :**

The two key outputs each have a time-controlled output for transmitter keying to ensure that in case of a blocked PTT switch the transmitter does not transmit for longer than two minutes and that after this time the latest the frequency is available again with no interference. This function also meets the LBA requirement for an IFR clearance.

**RX MUTING :**

The RX muting circuit is activated by an external push button and is used to immediately mute all incoming audio signals by 6 dB after single push button operation. After release of the button all audio signals will be heard at the previously selected volume. This RX mute function is highly appreciated and used during training operation.

**INTERCOM OPERATION :**


Intercom operation is activated by means of a front panel integrated toggle switch labelled "INTERCOM". During intercom operation all pilot and co-pilot mic amplifiers are activated and the mic audio is applied to all head phone amplifiers. This enables an internal communication between pilot and co-pilot without the necessity of pressing a button. Should during intercom operation e.g. the PTT switch be pressed by the pilot, intercom operation will automatically be disabled. Then only the pilot mic audio will be routed to the selected com radio via the controlled output amplifier. The co-pilot also listens to the pilot mic audio. After release of the PTT switch the audio control panel will immediately revert to intercom operation. The same happens vice versa, when the co-pilot operates his PTT switch during intercom operation.

**COCKPIT SPEAKER OUTPUT :**

The cockpit speaker is activated by means of the front panel integrated toggle switch labelled "SPEAKER". The cockpit speaker output is provided with a speaker amplifier used to control a 4 W speaker with an impedance from 2 to 8  $\Omega$ . The cockpit speaker amplifier performance is adapted to the individual operating conditions by the priority logic.

This means that the cockpit speaker amplifier during RX operation is automatically reduced in volume by approx. 6 dB, in order to prevent a feedback particular to hand mic operation.

## 2. COM / NAV - System



### **OPERATION :**

#### TURN ON :

Rotate the ON/OFF/Volume Control knob clockwise from the de-tend "OFF"-position. Power will be activated and the unit will be ready to operate. No warm up time is required. A non-volatile memory stores the "active" (USE) and "standby" (STBY) frequencies during power shutdown. So, when turned on, the "USE" and "STBY" windows will display the same frequencies that were selected before shutdown.

### **NOTE**

As with all avionics, the KX 155 should be turned on only after engine start-up. In addition, the KX 155 should be turned off prior to engine shutdown.

### **TO COMMUNICATE :**

#### Frequency Selection :

By rotating the concentric COMM frequency selector knobs either clockwise or counterclockwise, the desired operating frequency can be entered into the "STBY" display window. A clockwise rotation of the knobs will increase the displayed frequency number, while a counterclockwise rotation will decrease it. The outer, larger selector knob is used to change the MHz portion of the frequency display; the smaller knob changes the kHz portion.



This smaller knob is designed to change the indicated frequency in steps of 50 kHz when it is pushed in, and in 25 kHz steps when it is pulled out. At either band-edge of the 118.000-136.975 MHz frequency spectrum, an off-scale rotation will wrap the display around to the other frequency band-edge (i.e. 136.000 MHz advances to 118.000 MHz).

#### COMM Channeling :

To tune the COMM transceiver to the desired operating frequency, the selected frequency must first be entered into the "STBY" display window and then activated by pushing the "flip-flop" transfer button. This will interchange the frequencies in the "USE" and "STBY" displays, and the transceiver will be turned to the operating frequency appearing in the "USE" display.

As you can see, this feature makes it possible to display two COMM frequencies - one each in the "USE" and "STBY" displays - and then switch back and forth between them just by pressing the transfer button. An additional transfer button may also be remote-mounted in the aircraft.

#### Transmit Indicator :

Whenever the microphone is keyed, a lighted "T" will appear between the "USE" and "STBY" displays to indicate that the transceiver is operating in the transmit mode.

#### Volume Adjustment Test :

To override the automatic squelch for audio test, or to aid in receiving a distant station, simply pull the volume control knob out and rotate to the desired listening level. Push the knob back in to activate the automatic squelch.

#### **TO NAVIGATE :**

#### NAV Frequency Selection :

By rotating the concentric NAV frequency selector knobs either clockwise or counterclockwise, the desired operating frequency can be entered into the "STBY" display window. A clockwise rotation will increase the displayed frequency number, while a counterclockwise rotation will decrease it. As with the COMM frequency selectors, an off-scale rotation of the NAV frequency band-edge (108.000 to 117.95) will wrap the display around to the other edge of the frequency band (i.e. 117.000 advances to 108.000 with MHz knob rotation). Remote DME and internal glideslope channeling are also controlled by these selector knobs.

#### NAV Frequency Operation :

To tune the NAV receiver to the desired operating frequency, the selected frequency is first entered into the "STBY" display and then "flip-flop" into "ACTIVE" status by pushing the transfer button. When the inner knob is pulled out, the active NAV frequency is turned directly.

Ident :

The NAV "IDENT" knob is activated by pulling it outward, so that both voice and ident can be heard. When this knob is pushed in, the ident tone is muted. Volume of voice/ident can be adjusted by turning this knob - clockwise to increase, counterclockwise to decrease.

3. NAV - IndicatorVOR Operation

Channel the NAV receiver to the desired VOR and monitor the audio to positively identify the station. To intercept a selected VOR radial, turn the OBS to set the desired radial under the lubber line. The left-right needle will now deflect in the direction of the desired radial. Flying toward needle deflection will bring the aircraft to the desired radial. To fly inbound toward the station, turn the OBS to center the left-right needle while the TO-FROM is indicating. Read the bearing under the lubber line and fly that magnetic course. When the aircraft passes over the station, the TO-FROM will momentarily disappear and then reappear as FROM. This indicates the aircraft is outbound from the station.

LOC Operation


Localizer circuitry is energized when the NAV receiver is channeled to an ILS frequency. The VOR/LOC flag will be out of view when the signal is usable. Corrections for approach should be made toward the needle, as in VOR, but due to increased sensitivity, corrections are smaller. When flying inbound on a back course, deflection of the needle will be reversed.

Glideslope Operation

Glideslope operation is much the same as the localizer just discussed. An UP deflection of the needle indicates the aircraft is below desired glidepath. The pilot must fly toward the needle for correction. A warning flag is provided to indicate usable signal conditions.

Unit Control Functions


The following figure displays the control functions for the KI 204/206/209. The KI 202/203/208 differs in not having a glideslope needle or flag. The KI 207 differs in not having an OBS or Azimuth card.



**4. Transponder Equipment**

**GENERAL**

The transponder is radio transmitter and receiver which operates on radar frequencies. Receiving ground radar interrogations at 1030 MHz, it returns a coded response of pulses to ground-based radar on a frequency of 1090 MHz.



**OPERATION :**

To operate the KT 76, first be sure that the function selector knob (1) [or the avionics master switch] is turned OFF before starting the aircraft's engine. Then, select the proper reply code by rotating the four control knobs (2). The reply code will be displayed in the code window (3). After engine start, turn the function selector to SBY (Standby), giving the transponder about 45-50 seconds to become operational. As soon as you are airborne, turn the function selector to ON, which places the KT 76 in normal mode A operation.

If the aircraft is equipped with an encoding altimeter, turn the function selector to the ALT (Altitude) position, for altitude reporting (Mode C) to ATC. Altitude reports are automatically updated in 100-foot increments, from -1.000 feet to 35.000 feet.

Squawk Ident


When you are asked to "Ident" by ATC, briefly press the Ident push-button (4). The aircraft will be positively identified to the Air Traffic Controller.

Reply Light

During normal operation, the flashing reply light (5) indicates that the KT 76 is functioning properly and replying to interrogations from ground radar. Interrogations occur at 10-15 second intervals, corresponding to each radar sweep. Frequently, the reply light will blink almost continuously, meaning that the transponder is responding to interrogations from several radar stations.

5. Marker Beacon Receiver**GENERAL**


The TSO'd KR 21 Marker Receiver provides marker beacon audio signals to the KMA 24H and has a marker light display similar to that in the KMA 24. It is all solid-state and has its own self-test and automatic dimming.



## 6. Audio Control Console

### OPERATION :

#### Transmitter / Receiver Control



Both microphone connection and audio distribution are controlled by means of 10 color-coded push buttons on the KA 134 console.

Automatic COMM switching matches the selected VHF transmitter with the audio of its corresponding receiver. The unit's Isolation/Speaker Amplifier automatically raises audio signals strength to the level necessary to drive the cabin speaker. Whenever headphones are used, the amplifier is bypassed to connect the headphone directly to the selected receiver.

The three yellow buttons on the left side of the KA 134 are the microphone select switches. These buttons are interlocked, so only one can be pressed at a time. The two buttons marked (COMM) 1 and (COMM) 2 control the active VHF transceiver. The third button of this group, marked EXIT, can be wired to provide an additional microphone input for such as a cabin address system, ramp hailer, pilot-copilot intercom, or a third transceiver such as HF or radio telephone.

The six white buttons to the right of the MIC group are individual audio select switches. To listen to a specific receiver, simply press the corresponding button to the "IN" position. Press again so the button returns to the "OUT" position to mute the receiver. The switch marked BOTH can be used to monitor the audio channel of the unselected COMM 1 or COMM 2 transceiver. Speaker or phone operation is controlled by the yellow SPKR switch on the far right side. When this button is depressed, the audio is heard over the cabin speaker. If not depressed, the audio is routed directly to the headphones.

Some audio sources, such as Radar Altimeter alert or the ring signal from a radio telephone, may be wired directly into the isolation amplifier. Thus, these sources will always be routed through the cabin speaker, regardless of the position of the SPKR switch.

All speaker outputs are electronically muted whenever the microphone button is keyed, to prevent undesirable cockpit feedback in transmission.

## 7. Audio Control System

### OPERATION :

#### Auto Receiver Audio Select

For KMA 24 models equipped with the "AUTO" Receiver select feature, the transmitter selected with the microphone selector switch will be matched automatically with the appropriate COMM receiver audio on either headphone or speaker, or both, by simply pressing the desired headphone and/or speaker "AUTO" push button. (COMM 1 and COMM 2 push buttons should be disengaged unless it is desired to additionally listen to a COMM receiver other than the one selected with the microphone selector switch).

Thus, on "AUTO" you may change the rotary microphone switch back and forth, as needed, without having to reselect the corresponding COMM, TEL, or HF receiver buttons in order to hear the receiver.

Both models of the KMA 24H have "AUTO COMM" capability and always provide automatic headphone audio selection to match the transceiver in use. The selection of speaker audio can either be made automatically by pulling out the speaker "AUTO" switch or manually with the row of speaker audio select push buttons.

#### Marker Beacon Receiver KMA 24

The complete TSO'd 3-light marker beacon receiver built into the KMA 24 gives you an accurate visual and aural signal when you pass over a 75 MHz beacon. The blue, amber, and white lights on the faceplate - as well as the audio tone - identify the beacon type (outer, middle or airway/inner marker).

Either the speaker or headphone MKR buttons or both must be "in" for the marker beacon receiver to provide an audio signal at beacon passage.

The horizontal push button labeled SENS on the lower left side of the console gives you the choice of two receiver sensitivities. When the button is "in", the sensitivity is on HI. During an approach, this setting should permit you to hear the outer marker tone about one mile out. At this point you may select LO to dampen the tone. It will start to sound again when you are closer to the marker, giving you a more precise indication of its location.


Pressing the top horizontal button marked "TST" simply applies voltage to all three lamps to show that they are functioning.

#### NOTE:

The "TST" button should not be pressed to test the lamps when autopilot coupled on an ILS approach inside the outer marker. This is due to the fact that some autopilots (including BEN-DIX/KING autopilots) use marker annunciation to change the sensitivity of the autopilot.

A photocell in the console automatically dims the lamps for night operation.


The "INT" position on the KMA 24 permit the flight crew to address cabin occupants over the cabin speaker. To do this, select "INT" with the microphone switch. When the mike is keyed, the receiver audio is muted and you may talk normally into the microphone to broadcast over the speaker. The KMA 24 also has an "EXT" position on the microphone selector switch which connects the microphone to an external ramp hailer speaker, if installed.



**8. DME System KING KN 62A**

**GENERAL**

The KN 62A fits right into your avionics stack, operating on any DC voltage from 11 to 33 volts without adapters or power converters. And since it draws only 15 watts of power, no external cooling is required (stack cooling is recommended whenever the KN 62A is installed in a stack configuration with other avionics).



**OPERATION :**

Turn on the KN 62A only after engine start-up. Also, turn avionics off prior to engine shut-down.

The 3-position function switch determines both the information displayed and the channeling source. Place the function switch on Frequency (FREQ). The KN 62A is channeled internally with its own two concentric frequency selection knobs. The smaller of the two knobs has an "in" and an "out" position. When in the "in" position, this smaller knob changes the 0.1 MHz digit (0.0, 0.1, 0.2 etc.). When pulled "out", it adds 0.05 MHz to the frequency and tunes in 0.1 MHz steps (0.05, 0.15, 0.25, etc.). Pushing the smaller knob "in" subtracts 0.05 MHz from the displayed frequency. The outer, larger knob changes the larger digits (1 MHz, 10 MHz). In FREQ mode, the KN 62A will displays distance and the selected frequency. (See Figure 1.)

Now move the function switch to the Groundspeed/Time-to-station (GS/T) position. The KN 62A will hold the internally selected frequency and will display distance, groundspeed and time-to-station. (See Figure 2.)

Rotating the frequency selector will have no effect on the display, because the DME is in "Frequency Hold". This frequency hold feature in the GS/T mode prevents accidental rechanneling of the DME when the frequency is not displayed.

Place function switch in the Remote (RMT) position, and your DME will be channeled when you select your NAV frequency on the NAV receiver. Search time is usually about one second. When the KN 62A locks on a ground station, it will display distance, groundspeed and time-to-station. (See Figure 3.)

Prior to lock on, "dashes" will be displayed. (See Figure 4.)

Note that you may have two frequencies available at all times (one remotely selected on the NAV receiver and one internally selected with the KN 62A controls).




Figure 1. Distance/Frequency. FREQ mode.




Figure 3. Distance/Groundspeed/TTS. RMT mode.



Figure 2. Distance/Groundspeed/TTS. GS/T mode.




Figure 4. Prior to lock on.




**9. DME System KING KN 63 with KDI 572****GENERAL**

The TSO'd KN 63 is a complete 100 watt, 200-channel remote DME system utilizing the latest state-of-art Large Scale Integrated (LSI) circuit technology.

Distances up to 389 Nm (at line-of-sight altitude), ground-speeds up to 999 kts, and time-to-station up to 99 minutes are computed digitally and displayed simultaneously on the easy-to-read KDI 572 panel display.

The KN 63 Receiver/Transmitter unit can be remotely mounted in any position such as behind the instrument panel.

The KN 63 will operate on any DC voltage from 11 to 33 volts.



KDI 572 Master Indicator

**OPERATION :****Turn-on-procedure:**

As with all avionics, power to the KN 63 should be turned on only after engine start-up. In addition, the KN 63 should be turned off prior to engine shut down.

The rotary function switch on the KDI 572 master unit is used to turn on the system and select the desired NAV channelling source. The KDI 572 master unit functions the same as a KDI 572, but without a rotary function switch, thus allowing for a remote-mounted function switch. DME tuning is then accomplished automatically through the selected NAV 1 or NAV 2 receiver frequency controls. Prior to station lock-on, "dashes" will appear in the window of the DME panel display. Search time is usually one second or less. Once the system has locked on, the distance readout will appear - followed quickly by groundspeed and time-to-station computations.

**DME operation:**

After the KN 63 has locked on to the selected VORTAC station, DME distance will be displayed in 0.1 Nm increments up to 99.9 Nm; then in increments of 1 Nm to 999 kts and time-to-station up to 99 minutes are displayed simultaneously.

The effective range of a DME system depends on several factors, including the altitude of the aircraft. Other contributing factors are the location and elevation of the ground station, DME transmitter power output, and receiver sensitivity. As a standard operating practice it is desirable to positively identify the selected VORTAC station frequency by listening to its coded identification audio signal through the aircraft headphone or speaker.

In order to generate precise DME data, The KN 63 electronically converts into distance the elapsed time required for signals to travel to and from the ground station. The resulting computation is then presented in nautical miles on the DME panel display. This distance, commonly referred to as "slant range" distance, should not be confused with actual along-the-ground distance. The difference between actual ground and slant range distance is smallest at low altitude and long range and greatest at close range to the VORTAC facility. However, if the range is 3 times the altitude or greater, slant range error is negligible.

Groundspeed calculations are based on the rate of change in DME slant range distance with time. Time-to-station is computed by dividing the slant range distance by the computed groundspeed. To obtain accurate groundspeed and time-to-station readouts, the aircraft must be tracking directly to or from a selected station or RNAV waypoint.

### Channeling:

The KN 63 DME can be channeled automatically from most NAV receivers. When the function switch on the KDI 572 indicator is turned to the "N1" position, the DME will be channeled from NAV 1 frequency selector. In "N2" position, the DME channels from the NAV 2 receiver.

Thus, whenever the NAV receiver in use is turned to a new frequency - or a different NAV receiver is selected on the DME function switch - The KN 63 will retune itself immediately to the newly selected VORTAC station.

However, when the DME function switch is placed in the "HOLD" position, the KN 63 will remain channeled to the last selected frequency, even though the NAV frequency selectors are subsequently changed.

This feature is most useful during instrument approaches when both NAV receivers may need be tuned to an ILS frequency without DME. The KN 63 can be tuned to a nearby VORTAC station before the approach is begun, and then placed in the "HOLD" mode to provide DME information throughout the approach.

When the KDI 572 function switch is placed in "HOLD" position, a "1H" or "H2" annunciation will be displayed to indicate the channeling source being held. An "RNV" annunciation will appear whenever the displayed readouts are based on waypoint data derived from some area navigation systems.


10. ADF System KING KR 87 with KI 227

**GENERAL**


The basic KR 87 system includes the KR 87 receiver, the KI 227 indicator with rotatable compass card and the aerodynamically designed KA 44B combined loop and sense antenna, plus mounting racks and connectors.

The all solid-state KR 87 receiver will operate on any DC voltage from 11 to 33 volts. It draws only 12 watts power, so no external cooling is required.

The standard KI 227 ADF indicator has an optically coated, non-reflecting glass lens that can be cleaned without scratching and has a manually rotated compass card.



NOTE: All mode annunciation shown for illustration only actual operation will vary.



KI 227  
KS 227-00 shown, non-slaved, standard

**OPERATION :**

**Turn-on-procedure:**

Rotate the ON/OFF/VOL knob clockwise from the detented "OFF" position. The unit will be activated and will be ready to operate. Rotation of this control also adjusts audio volume. The KR 87 has "audio muting" which causes the audio output to be muted unless the receiver is locked on a valid station.

**Frequency selection:**

The active frequency (to which the ADF is tuned) is displayed in the left side of the window at all times. A standby frequency is displayed in the right side when "FRQ" is annunciated. The standby frequency is placed in "blind" memory when either FLT (Flight Time) or ELT (Elapsed Time) mode is selected. With "FRQ" annunciated, the standby frequency is selected using the frequency select knobs which may be rotated either clockwise or counter clockwise. Pull the small knob out to tune 1's. Push the smaller inner knob in to tune 10's. The outer knob tunes the 100's and the 1000's up to 1799.

The standby frequency selected may then be put into the active window by pressing the "FRQ" button. The standby and active frequencies will be exchanged (flip-flopped), the new frequency will become active, and the former active frequency will go into standby.

**Operating modes:**

Antenna (ANT) mode is selected and annunciated when the "ADF" button is in the "out" position. ANT provides improved audio reception from the station tuned and is usually used for identification. The bearing pointer in the Ki 227 indicator will be deactivated and immediately turn to the 90° relative position and remain there during ANT position.

The ADF mode is selected and annunciated when the "ADF" button is in the depressed position. ADF activates the bearing pointer in the KI 227 indicator, causing it to move without hesitation to point in the direction of the station relative to the aircraft heading. The compass card on the KI 227 may be rotated as desired by using the heading knob.

The BFO mode, activated and annunciated when the "BFO" button is depressed, permits the carrier wave and the associated Morse code identifier broadcast on the carrier wave to be heard.

**ADF test (Pre-flight or in-flight):**

Select ANT mode. This will cause the bearing pointer to move directly to the parked 90° position. Make sure the units is tuned to a usable frequency. Now select ADF mode and the needle should move without hesitation to the station bearing. Excessive sluggishness, wavering or reversals indicate a signal that is too weak or a system malfunction.

**Operating the times:**

The flight timer will always be automatically reset to 0:00 whenever power is interrupted either by the avionics master switch or the unit's ON/OFF switch. An optional external switch may be installed which, when activated, will stop or start the flight timer.


This switch would be of use during a non-refueling stop when resetting the flight timer is not desired. On some aircraft it may be desirable to use the aircraft strut switch instead of a manual switch to stop and start the flight timer. It should be emphasized that the start/stop function will only operate with power applied to the unit. Always read flight time prior to power shutdown.

Flight time or elapsed time are displayed and annunciated alternatively by depressing the FLT/ET button. The flight timer continues to count up until the unit is turned off or stopped with an external switch. The elapsed timer may be reset back to :00 by pressing the SET/RST button. It will then start counting up again. (NOTE: pressing the SET/RST button will reset the elapsed timer whether it is being displayed or not).

## 11. VHF Communications Transceiver

### GENERAL

The KING KY 96A operates at 28 volts. With the anticipation of additional frequency allocations, the KY 96A operate on 760 frequencies from 118.00 MHz to 136.975 MHz.



### OPERATION :

#### Power up:

When turn the ON/OFF/VOLUME knob clockwise to the "on" position, the KY 96A will display the last used frequencies in the "USE" and "STBY" (Standby) windows.

To verriede the automatic squelch, pull the ON/OFF/VOLUME knob out and rotate it for the desired listening level on the noise being produced by the receiver. Push the volume knob back in to activate the automatic squelch.

#### NOTE:

As with all avionics, the KY 96A should be turned on only after engine start-up.

**Transmitting:**

During COMM transmissions, a "TX" appears to indicate the keying of the microphone.

**The frequency mode (normal operation):**

1. Select a new frequency in the "STBY" window using the frequency selection knobs. The larger knob offers changes of 1 MHz. The smaller knob provides changes of 50 kHz when pushed in and 25 kHz when pulled out. at outside limits of the band the display will wrap around to the other end of the band - going from 136 MHz to 118 MHz.
2. press the transfer button to activate the new frequency. The newly entered frequency in the "STBY" window flip-flops with the frequency in the "USE" window. This new frequency tunes the radio for operation. An optional remote-mounted frequency transfer button may also be used to perform this "flip-flop" function.

**Programm mode:**

The Programm mode is used to set memory locations for use in the channel mode.

1. Depress the channel (CHAN) button for longer than two seconds, until "PG" is annunciated on the display. The last used active frequency will remain tuned in the "USE" window and the last channel number will flash.
2. Turning either frequency selection knob changes the channel number.
3. Once you have selected the desired channel number, pressing the transfer button will cause the frequency corresponding to that channel number to flash. You may then select the frequency for the displayed channel number simply by turning the frequency selection knobs.
4. To programm additional channels, push the transfer button again to make the channel number flash and repeat step three above.
5. If you wish to programm less than 9 channels and have certain channel numbers skipped over when operating in the channel mode, proceed as follows: Rotate the MHz frequency knob left or right beyond 136 or 118 MHz. Dashes "---" will appear in the "STBY" window. This indicates that the affected number will be skipped when operating in the channel mode.
6. To exit the programm mode, momentarily press the channel (CHAN) button. The unit will also automatically exit the programm mode if approx. 20 seconds elapse with no programming.

**The programm secure mode:**

The programm secure mode may be used to lock a desired frequency to a channel number, prohibiting programm changes by the pilot from the front of the unit. The KY 96A should be taken to your BENDIX/KING dealer for programming of the programm mode.

**Channel mode:**

The channel mode is used to recall preset channels stored in memory.

1. push the channel (CHAN) button while in the frequency mode to enter the channel mode. The last active frequency remains displays in the "USE" window. The last used channel number is displayed in the channel window. If no channels have been programmed, channel 1 automatically appears and dashes are displayed in the "STBY" window.
2. Turn either tuning knob to change the channel number and the channel's corresponding frequency in the "STBY" window.
3. If there is no activity for five seconds the radio will return to the frequency mode with the channel frequency remaining in the "STBY" window.
4. You can also return to the frequency mode by pressing the transfer button while in the channel mode. The channel frequency will become the "USE" frequency and the last "USE" frequency will become the "STBY" frequency.

NOTE: If the optional remote channel increment switch is installed, each activation of the switch will put the unit in the channel mode and cause the next higher channel number and its corresponding frequency to be displayed.

**12. Compass system with HSI****GENERAL**

The KCS 55A Pictorial Navigation System is composed of five units: KI 525A Pictorial Navigation Indicator / KG 102A Directional Gyro / KMT 112 Magnetic Azimuth Transmitter / KA 51B Slaving Accessory / KA 52 Autopilot Adapter, if required.

**FUNCTIONAL OF THE KCS 55A SYSTEM**

When power is first applied to the KCS 55A System, and the system is in the slaved gyro mode, the heading display will automatically fast slave at the rate of 180 degrees per minute to align the slaving control transformer in the KI 525A with the magnetic heading transmitted by the KMT 112. The system will remain in this fast slave mode until the slaving error is reduced to zero and then revert to the normal slaving mode and slave at a constant rate of 3 degrees per minute to keep the system aligned with the earth's magnetic field. If the system is cycled from the free gyro mode to the slaved gyro mode by means of actuating the "slave in" button on the KA 51A (toggle switches on the KA 51B), the "fast slave" will automatically be repeated.


Stabilized heading information is supplied to the KI 525A by the KG 102A. When in the slaved gyro mode this heading signal, which may vary at rates up to 30 degrees per second, is summed with the normal slaving signal from the KMT 112 to provide the final drive signal for the heading display.

When the system is in free gyro mode the heading signal from the KG 102A is the only input to the heading display drive. While in the free gyro mode the pilot may command changes in the displayed heading by means of depressing the clockwise or counterclockwise pushbuttons on the KA 51A (toggle switches on the KA 51B).

The KI 525A HSI is the panel display for the KCS 55A Compass System. It combines the functions of the standard directional gyro and the VOR/LOC/Glideslope deviation indicator. The Indicator displays the complete navigation situation at a glance:

- Slaved gyro magnetic heading
- Selected heading
- Selected VOR/RNAV or LOC course
- RNAV/VOR/Localizer deviation
- TO/FROM RNAV or VOR indicator
- Glideslope deviation

The KA 51B Slaving Control and Compensator Unit is panelmounted. It provides selection of "slaved gyro" modes for the system and manual slaving when the system is in "free gyro" mode. The meter indicates proper slaving operation. 14 and 28 volt lighting options available. The compensator may be remote-mounted for ease of installation.



KI 525A Indicator Display

**Section 5  
PERFORMANCE**

The installation of this instrumentation does not influence the performance of the aircraft.







**SUPPLEMENT 2**

**ACROBATIC - OPERATION**

**Section 1  
GENERAL**

**1.1 General**

The GROB G 115C may be operated in the Airworthiness category " Acrobatic " according to SB 1078-55 for simple acrobatic maneuvers. The following instructions are additional informations to the Flight Manual G 115C and describe the acrobatic-operation and the additional equipment.

**1.15 Maximum Weights**

max. takeoff weight (acrobatic category) 920 kg (2028 lbs)  
max. landing weight (acrobatic category) 920 kg (2028 lbs)

Standard empty weight 660 kg (1455 lbs)

1) at standard empty weight

**Acrobatic**

Wing loading 75,35 kg/m<sup>2</sup>  
at max. takeoff weight (15.43 lbs/sq.ft.)

Power loading 5,75 kg/HP  
at max. takeoff weight (12.68 lbs/HP)

**Section 2  
LIMITATIONS**

The Kinds of Operation Limits of the aircraft are extended with the Airworthiness category " Acrobatic ".

**2.13 Weight Limits**

Maximum take-off and Acrobatic 920 kg (2028 lbs)  
landing weight

**Acrobatic and spin maneuvers are approved without baggage only!**



2.15 Center of Gravity Limits

Acrobatic		Distance from Datum [mm] (ft)
forward limit		
at 920 kg (2028 lbs)	17.60 % $l_{\mu}$	219 (.718)
at 750 kg (1653 lbs)	15.90 % $l_{\mu}$	197 (.646)
aft limit		
at 920 kg (2028 lbs)	23.77 % $l_{\mu}$	295 (.968)
at 750 kg (1653 lbs)	23.20 % $l_{\mu}$	288 (.945)

Datum: Wing leading edge = QE 2480  
 $l_{\mu}$ : Mean aerodynamic chord = 1,242 m (4.075 ft)  
 Horizontal reference : Canopy sill

2.17 Maneuver Limits

The approved flight maneuvers for the **Acrobatic-Category** are detailed listed in Chapter 4 " Normal Procedures ".  
 Entry speed according to flight maneuver !

**WARNING**

At airspeeds in excess of  $V_A$  do not apply abrupt and full control inputs! Snap roll maneuvers are not approved !

**Utility Category :**

Flight maneuver : Lazy Eight / Chandelle / Steep turns  
 Entry Speed: 245 km/h [132 kts]  
 Intentional spins with flap setting at 0° are approved only.  
 Spins without wheel fairings are not approved.  
 Recommended entry speed:  $\approx$  100 km/h [54 kts]

2.19 Flight Maneuvering Load Factors

Acrobatic (920 kg) [2028 lbs]	Maximum load factor
Flaps retracted	+ 6,00 g - 3,00 g
Flaps extended	+ 3,80 g

2.41 Placards

On baggage compartment:

Baggage max. 55 kg (121 lbs)  
 -----  
 No baggage during acrobatics and spin maneuvers !

On LH cabin wall:

L i m i t a t i o n s	
Category	Acrobatic airplane
Max. weight	920 kg (2028 lbs)
Max. flight maneuvering load factors (flaps UP)	+6,00 g -3,00 g
(flaps DOWN)	+3,80 g
Never exceed speed $V_{NE}$ [IAS]	341 km/h (184 kts)
Max. structural cruising speed $V_{NO}$ [IAS]	248 km/h (134 kts)
Design maneuvering speed $V_A$ [IAS]	237 km/h (128 kts)
Max. flaps extended speed $V_{FE}$ [IAS]	208 km/h (112 kts)
Intentional spins without wheel fairings or with extended flaps are not approved !	

On right hand cabin wall:

The markings and placards installed in this airplane contain operating limitations which must be complied with when operating this airplane in the ACROBATIC category. Other operating limitations which must be complied with when operating this airplane in this category or in the UTILITY category are contained in the Airplane Flight Manual.

On instrument panel:

**Design maneuvering speed  $V_A$**   
 Acrobatic: 237 km/h IAS  
 (128 kts)

On red emergency lever:

**CANOPY JETTISON :**  
 1. PULL RED HANDLE  
 2. CANOPY HANDLE  
FULLY BACK  
 3. PUSH CANOPY TO  
 THE REAR TOP

On left canopy frame:

Acrobatic airplane	Entry Speed [kts]
Spin	54 - 97
Loop (positive)	119 - 132
Turn	119 - 132
Immelmann	132
Split-S (nose raise 45°)	132
Aileron Roll	127
Barrel Roll (positive)	132
Lazy Eight	132
Chandelle	132

### Section 3 EMERGENCY PROCEDURES

#### 3.5 Emergency Procedures Check List

##### **ABANDONING THE AIRCRAFT BY PARACHUTE / CANOPY EMERGENCY JETTISON**

1. Engine SHUT OFF
2. Red locking lever PULL
3. Open canopy handle and move it backwards and up through the 90° position as far as the stop (approx. 170° position). This releases the two front attachment points on the guide rail.
4. Push the canopy simultaneously backwards and upwards.
5. Safety harness RELEASE
6. Cockpit ABANDON

#### 3.7 Amplified Emergency Procedures

##### **ABANDONING THE AIRCRAFT BY PARACHUTE / CANOPY EMERGENCY JETTISON**

The first action should be to close the throttle fully, then set the ignition to "OFF" and set the mixture lever to "FULL LEAN". The flaps can be used to reduce the air-speed if the speed is not too high. The actual jettisoning of the canopy and the subsequent abandonment of the aircraft is initiated by pulling the red locking lever.



The canopy handle is then opened and pushed backwards and up through the 90° position as far as the stop (approx. 170° position). This releases the two front attachment points on the guide rail. The canopy must now be pushed backwards using some force and at the same time pushed up and away. The safety harness must then be released and the cockpit abandoned.

Section 4
NORMAL PROCEDURES

4.4 Approved Maneuvers

Table with 3 columns: Acrobatic, Entry Speed (km/h), and Entry Speed [kts]. Rows include Spin, Loop positive, Turn, Immelmann, Split-S (nose raise 45°), Aileron Roll, Barrel Roll (positive), Lazy Eight, and Chandelle.

WARNING

Do not make full or abrupt control movements above VA ! Snap roll maneuvers are not approved ! Observe RPM limit (2700 RPM) during acrobatic maneuvers ! At airspeeds in excess of 180 km/h (97 kts) do not apply combined full control inputs (i.e. full rudder deflection combined with full elevator deflection).

NOTE

The attitude indicator will show an incorrect or false indication during flight maneuvers ( e.g. spinning ). To achieve a faultless function of the instrument, a level flight of approx. 20 min. will be recommended. Check that the attitude indicator is stabilized. During this period of time use only the turn coordinator and/or the directional indicator. This is advisable during abnormal flight maneuvers ( e.g. high rate of roll during turbulence ).



#### 4.5 Normal Procedures Checklist

##### Preflight Inspection

###### I. Cockpit

**CAUTION**

During acrobatic maneuvers the control lock and the towbar do not take up in plane !

#### 4.9 Amplified Normal Procedures

##### Preflight Inspection

If acrobatics are envisaged, remove all loose objects etc. also from the passenger's person.

##### Approved Maneuvers

The airplane is approved for certain maneuvers, provided it is loaded within the approved weight and center of gravity limits (See Section 2 - Limitations).

The approved maneuvers are:

Spin / Loop positive / Turn / Immelmann / Split-S (nose raise 45°) / Aileron Roll / Barrel Roll positive / Lazy Eight / Chandelle.

Before performing maneuvers, check for:

Baggage : NO BAGGAGE IN BAGGAGE COMPARTMENT !

#### **ACROBATIC - MANEUVERS**

##### General

Prior to intentional spinning the maximum weight of 920 kg (2028 lbs) (ACROBATIC- and UTILITY category) must not be exceeded!

Before starting acrobatic maneuvers, tighten the safety harnesses and make sure that all loose objects are securely stowed. Start the maneuvers at a safe height. The electrical fuel pump must be switched off and the flaps retracted.

During airspeed built-ups by throttle lever the RPM limit (red radial at 2700 RPM) must be observed.

If there is a danger of exceeding the max. allowable speed, close the throttle fully. Control surface deflections should be adapted to the situation.

The following rule applies for all pull-out radii up to  $V_A$ :  
 Leave the engine at high power settings to keep the pull-out radii as small as possible.  
 (This is required to maintain higher load factors).

### 1. LOOP (positive)

Entry speed : approx. 245 km/h (132 kts)  
 Load factor : approx. + 3,5g

### 2. STALL TURN

Entry speed : approx. 245 km/h (132 kts)  
 Load factor : approx. + 3g - 5g  
 Start attitude : approx. 70° - 80°

Hammerhead stall turns can only be performed cleanly to the left (due to propeller vortex). When the first signs of instability due to lack of engine power occur, quickly apply full left rudder.

As the aircraft turns, apply full opposite aileron and push the stick firmly forwards. The engine may lose power for a short time during hammerhead stall turns in the vertical. Therefore you should make the stall turn at an angle of 10° - 20° from the vertical. This applies to both climbing and diving phases of the hammerhead stall turn.

### 3. IMMELMANN

Entry speed : 245 km/h (132 kts)  
 Load factor : approx. + 4g

### 4. SPLIT "S" FROM A 45° CLIMB

Entry speed : 245 km/h (132 kts)  
 Load factor : approx. + 4g

Pull the aircraft quickly into a 45° climb and apply full aileron until inverted. Recover to normal attitude.

### 5. AILERON ROLL

Entry speed : 235 km/h (127 kts)  
 Load factor : approx. + 1,5g to 0g

Lift the nose into a 20° climb, then apply and hold full aileron until the wings are again level.



**6. BARREL ROLL positive**

Entry speed : 245 km/h (132 kts)  
Load factor : approx. + 3g

For this maneuver, make sure the nose is lifted sufficiently. If there is a danger of exceeding max. allowable speed, close the throttle and adapt the control deflections to the situation.

**7. LAZY EIGHT**

Entry speed : 245 km/h (132 kts)  
Load factor : approx. + 3g

**8. CHANDELLE**

Entry speed : 245 km/h (132 kts)  
Load factor : approx. + 3g

**CAUTION**

During all flight maneuvers negative accelerations should be avoided. If negative accelerations appear, the engine can intermitently stop. Additionally remarkable loss of oil by the crankcase ventilation must be considered under this condition.

**Section 5  
PERFORMANCE**

There are no changes in the performance of the airplane.

Section 6  
WEIGHT AND BALANCE

6.7 Weight and Balance Determination for Flight

Fig. 6.3 Center of Gravity Limits





Fig. 6.4 Massmoment Limits





7.25 Engine

Optional a second throttle-lever is located in the LH side of the instrument panel. The bowden control cable of this lever is in synchronism with the "main throttle lever".